

[Manuals.plus](#) /

› [RUIZU](#) /

› RUIZU 64GB MP3 Player Bluetooth 5.3 User Manual

RUIZU X02 64GB

RUIZU 64GB MP3 Player Bluetooth 5.3 User Manual

Model: X02 64GB

1. INTRODUCTION

Thank you for purchasing the RUIZU 64GB MP3 Player with Bluetooth 5.3. This portable music player is designed for high-quality audio playback and offers a range of features including FM radio, voice recording, e-book reading, and video playback. This manual provides detailed instructions to help you get started and make the most of your device.

2. PACKAGE CONTENTS

Please check the package for the following items:

- RUIZU MP3 Player (Bluetooth compatible) x1
- 3.5mm Stereo Earphones x1
- USB Type-C Cable (for charging and data transfer) x1
- Instruction Manual (English/Japanese) x1

多機能MP3プレーヤー HiFiロスレス音質

録音

電子書

音楽

ロック画面

ビデオ

FMラジオ

歩数計

Bluetooth

フォルダ

アラーム

A-B ループ

ストップウォッチ



Image: RUIZU MP3 Player with its included accessories, including earphones and a USB-C cable.

3. PRODUCT OVERVIEW

Familiarize yourself with the device's buttons and ports.



Image: Front view of the RUIZU MP3 Player, showing the 1.8-inch LCD screen and control buttons.

MP3プレーヤー Bluetooth 5.3
より高速な伝送、より安定した接続
絡まないBluetoothイヤホンやBluetoothスピーカー



Image: Side view of the RUIZU MP3 Player, highlighting the power switch, volume controls, and other functional buttons.

128GB拡張可能容量

より多くの音楽とファイルも保存できます



Image: Bottom view of the RUIZU MP3 Player, showing the USB Type-C port and the 3.5mm headphone jack.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the MP3 player. Connect the included USB Type-C cable to the player's USB-C port and the other end to a USB power adapter (not included) or a computer's USB port. The device features a 420mAh rechargeable lithium polymer battery, providing up to 80 hours of playback on a full charge.

4.2 Transferring Music and Files

Connect the MP3 player to your computer using the provided USB Type-C cable. The device will appear as a removable disk. Drag and drop your music files (MP3, WMA, APE, FLAC, WAV, DRM, ACELP, OGG), videos (128*160 AMV only), e-books (TXT only), or image files into the appropriate folders on the player.

The player has 64GB of internal memory. You can expand storage up to 128GB using a microSD card (not included).



Image: The RUIZU MP3 Player showing its microSD card slot for memory expansion.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Slide the power switch located on the side of the device to the 'ON' position.
- **Power Off:** Slide the power switch to the 'OFF' position.

5.2 Music Playback

1. From the main menu, select "Music".
2. Browse through your music library by artist, album, or folder.
3. Select a song to begin playback.
4. Use the volume buttons on the side to adjust the sound level.
5. The player supports various equalizer settings. Navigate to the music settings to customize the audio output.

長持ちバッテリー

80時間再生可能



Image: The music playback interface on the RUIZU MP3 Player's screen.

5.3 Bluetooth Connection

The RUIZU MP3 Player features Bluetooth 5.3 for stable and fast wireless connections.

1. Ensure your Bluetooth headphones or speaker are in pairing mode.
2. On the MP3 player, navigate to the "Bluetooth" menu.
3. Select "Search for devices" to find available Bluetooth devices.
4. Choose your device from the list to pair. Once paired, audio will stream wirelessly.

5.4 FM Radio

To use the FM radio function, ensure wired earphones are connected as they act as the antenna.

1. Connect the included 3.5mm earphones to the player.
2. From the main menu, select "FM Radio".
3. Use the navigation buttons to scan for stations or manually tune to a frequency.

5.5 Voice Recording

The device includes a built-in voice recorder.

1. From the main menu, select "Voice Recorder".
2. Press the appropriate button to start recording.
3. Press again to stop and save the recording.



Image: An icon representing the voice recording function on the RUIZU MP3 Player.

5.6 E-book Reader

The player supports TXT format e-books.

1. Transfer TXT files to the "E-book" folder on the player.
2. From the main menu, select "E-book".
3. Choose a file to open and read.

5.7 Video Playback

The player supports video playback for 128*160 AMV format files only. Other formats are not supported.

1. Ensure your video files are converted to 128*160 AMV format.
2. Transfer AMV files to the "Video" folder on the player.
3. From the main menu, select "Video".
4. Choose a video to play.

5.8 Image Viewer

View your images directly on the device's 1.8-inch screen.

1. Transfer image files to the "Pictures" folder on the player.
2. From the main menu, select "Pictures".
3. Browse and select images to view.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

- **Software Updates:** Check the official RUIZU website for any available firmware updates to ensure optimal performance.

7. TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the battery is charged. Connect the player to a power source using the USB-C cable. Check the power switch is in the 'ON' position.
Cannot transfer files to the player.	Verify the USB-C cable is securely connected to both the player and the computer. Try a different USB port or cable. Ensure the player is recognized as a removable disk by your computer.
No sound from earphones.	Check if the earphones are properly plugged in. Adjust the volume. Test with another pair of earphones to rule out faulty earphones.
Bluetooth device not pairing.	Ensure the Bluetooth device is in pairing mode and within range. Restart both the MP3 player and the Bluetooth device.
FM Radio not working.	Ensure wired earphones are connected, as they serve as the antenna for FM reception.
Video files not playing.	Confirm that video files are in 128*160 AMV format. Other formats are not supported.

8. SPECIFICATIONS

Brand	RUIZU
Model Number	X02 64GB
Memory Storage Capacity	64 GB (expandable via microSD card up to 128GB)
Connectivity Technology	AUX, Bluetooth 5.3, USB Type-C
Screen Size	1.8 inches
Display Technology	LCD
Supported Audio Formats	MP3, WMA, APE, FLAC, WAV, DRM, ACELP, OGG
Supported Video Formats	128*160 AMV only
Supported E-book Formats	TXT only
Battery Life	Up to 80 hours (audio playback)
Features	FM Radio, Equalizer, Voice Recorder, Video Playback, E-book Reader, Image Viewer
Color	Black

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included in your package or visit the official RUIZU website. Keep your purchase receipt as proof of purchase for warranty claims.

Online Support: [RUIZU Official Store on Amazon](#)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question