

**B0C2TPPLHN**

# Generic Portable Electric Coffee Bean Grinder User Manual

MODEL: B0C2TPPLHN

## 1. Introduction

Thank you for choosing the Generic Portable Electric Coffee Bean Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

### Intended Use

This electric grinder is designed for grinding dry and solid food materials such as coffee beans, grains, beans, cereals, chili powder, medicinal materials, and spices. It is suitable for home, travel, and cafe use. Do not use it for wet, oily, or liquid ingredients.

## 2. Important Safety Instructions

**Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.**

- Read all instructions before using the appliance.
- This appliance is for household use only. Do not use outdoors.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Ensure the lid is securely in place before operating the grinder.
- Keep hands and utensils out of the grinding chamber while operating to prevent injury.
- Unplug from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate continuously for more than 60 seconds. Allow the motor to cool down between uses.
- Do not use the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.

- This grinder is only suitable for grinding dry and solid food materials.
- The filling amount of the grinding bowl should not exceed the maximum fill line.

### 3. Product Overview

#### Components

The Portable Electric Coffee Bean Grinder consists of the following main parts:

- **Motor Unit:** The base containing the powerful all-copper motor.
- **Grinding Bowl:** Stainless steel bowl where ingredients are placed.
- **Grinding Blade:** 304 stainless steel willow double-rotation grinding knife.
- **Transparent Top Cover:** Allows visibility of the grinding process and acts as a safety lock.
- **Point Pressure Switch:** Button to initiate and stop grinding.



Image: The Portable Electric Coffee Bean Grinder displayed with various ingredients like coffee beans, spices, and ground powders, showcasing its versatility.

## Dimensions



Image: A diagram showing the dimensions of the grinder, with a height of 163mm and a base diameter of 90mm.

## Key Features

- **One-Button Operation:** Simple point pressure switch for easy grinding.
- **Versatile Grinding:** Suitable for coffee beans, grains, beans, cereals, chili powder, medicinal materials, and spices.
- **Durable Construction:** All-copper motor and 304 stainless steel willow double-rotation grinding knife.
- **Safety Features:** Includes a safety lock and overheat protection.
- **Visibility:** Transparent top cover allows monitoring of the grinding process.
- **Compact Design:** Mini and delicate shape, saving counter space.

## 4. Setup

---

### Before First Use

1. Unpack the grinder and all its components.
2. Wash the grinding bowl and lid with warm, soapy water. Rinse thoroughly and dry completely. Do not wash the motor unit.
3. Wipe the exterior of the motor unit with a damp cloth.
4. Ensure all parts are dry before assembly and use.

### Charging (USB Rechargeable Model)

If your model is USB rechargeable, ensure it is fully charged before first use for optimal performance. Connect the provided USB cable to the grinder's charging port and a suitable USB power adapter (not included). The indicator light will show charging status and turn off or change color when fully charged.

## 5. Operating Instructions

---

### Grinding Process

Follow these steps for effective grinding:

1. **Prepare Ingredients:** Ensure your ingredients are dry and solid. Do not overfill the grinding bowl; the filling amount should not exceed the maximum fill line.
2. **Load Ingredients:** Pour the desired amount of ingredients into the stainless steel grinding bowl.
3. **Secure Lid:** Place the transparent top cover onto the motor unit and twist or press down until it is securely locked. The grinder will not operate if the lid is not properly secured due to the safety lock feature.
4. **Start Grinding:** Press and hold the point pressure switch button to begin grinding.
5. **Monitor Fineness:** Observe the grinding process through the transparent lid. Release the button once the desired fineness is achieved. For optimal results and to prevent overheating, pause once every 10 seconds during longer grinding sessions.
6. **Retrieve Ground Product:** Once grinding is complete, release the button, unplug the grinder (if corded), and carefully remove the lid. Pour out the freshly ground product.



1. Pour the right amount of beans into the mill.



2. Close the top cover to ensure locking;



3. Press the switch, pause once every 10 seconds;



4. Turn off the power and pour out the finished product.

Image: A four-panel image illustrating the grinding process: 1. Pouring beans into the mill. 2. Closing the top cover to ensure locking. 3. Pressing the switch, pausing every 10 seconds. 4. Turning off power and pouring out the finished product.

### Grinding Time and Fineness Guide

The grinding time directly influences the fineness of your ground product. Adjust the grinding duration to achieve your preferred consistency:

- **6 seconds:** Suitable for French press extraction (coarse powder).
- **8 seconds:** Suitable for siphon pot, hand flush, Belgian pot (medium powder).
- **10 seconds:** Suitable for moka pot (fine powder).
- **12 seconds:** Suitable for espresso machines (ultra-fine powder).

# COFFEE

*It only takes 20 seconds for coffee beans to turn into coffee powder*



Image: A visual guide showing coffee beans before grinding and the resulting coffee powder fineness at 5, 10, 15, and 20 seconds of grinding time.

## 6. Maintenance

### Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Unplug:** Always unplug the grinder before cleaning.
2. **Remove Residue:** Use the provided brush to remove any remaining ground particles from the grinding bowl and around the blades.
3. **Wash Components:** The grinding bowl and lid can be washed with warm, soapy water. Rinse thoroughly and dry completely.
4. **Clean Motor Unit:** Wipe the exterior of the motor unit with a clean, damp cloth. Do not immerse the motor unit in water or any other liquid.

5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing the grinder.

## Storage

Store the grinder in a cool, dry place, away from direct sunlight and moisture. Ensure it is clean and dry before storing. Keep out of reach of children.

## 7. Troubleshooting

If you encounter any issues with your grinder, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Grinder does not start.	Lid not securely closed. No power (if corded) or low battery (if rechargeable). Overheat protection activated.	Ensure the lid is properly locked. Check power connection or charge the battery. Allow the grinder to cool down for 15-20 minutes.
Inconsistent grinding results.	Overfilling the grinding bowl. Ingredients are not dry.	Do not exceed the maximum fill line. Ensure ingredients are completely dry before grinding.
Grinder stops during operation.	Overheat protection activated. Lid became loose.	Allow the grinder to cool down. Ensure the lid is securely locked.
Unusual noise during grinding.	Foreign object in grinding bowl. Loose components.	Immediately stop and unplug. Check for and remove any foreign objects. Ensure all parts are correctly assembled.

## 8. Specifications

Product specifications are subject to change without notice for product improvement.

Feature	Detail
Brand	Generic
Model	B0C2TPPLHN
Material	Stainless Steel
Voltage	220V
Power Source	Battery (USB Rechargeable)

Feature	Detail
Specific Uses	Grinding Coffee Beans, Spices, Grains
Manufacturer	King20220921416
GTIN/UPC	717522306878

## 9. Warranty and Support

---

### Warranty Information

This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal use. The specific terms and duration of the warranty may vary. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, neglect, accident, alteration, or unauthorized repair.

### Customer Support

For technical assistance, warranty claims, or any questions regarding your Generic Portable Electric Coffee Bean Grinder, please contact your retailer or the manufacturer directly. Refer to your purchase documentation for specific contact details.