

[Manuals.plus](#) /

› [Ordilend](#) /

› Ordilend 10-in-1 Keyboard and Electronics Cleaning Kit (Model GW013) User Manual

Ordilend GW013

Ordilend 10-in-1 Keyboard and Electronics Cleaning Kit (Model GW013) User Manual

1. INTRODUCTION

Thank you for choosing the Ordilend 10-in-1 Keyboard and Electronics Cleaning Kit. This comprehensive kit is designed to help you maintain the cleanliness and longevity of your electronic devices, including keyboards, laptops, computer screens, mobile phones, earbuds, and camera lenses. This manual provides detailed instructions for the proper use and care of your cleaning kit.

2. PRODUCT COMPONENTS

The Ordilend 10-in-1 Cleaning Kit includes the following tools:



Image: The Ordilend 10-in-1 Cleaning Kit showing all included tools and accessories.

- **Retractable Large Brush:** For general dusting of keyboards and larger surfaces.
- **Polishing Cleaning Cloth (x2):** For streak-free cleaning of screens.
- **Keycap Puller:** For safe removal of keyboard keycaps.
- **Metal Pen Tip:** For precise cleaning of small crevices and stubborn dirt.
- **Flocking Sponge:** Ideal for cleaning earbud charging cases and other delicate interiors.
- **Thin Soft Brush:** For detailed cleaning of small gaps and sensitive areas.
- **Soft Plastic Lens Cleaning Pen:** Specifically designed for camera lenses and delicate screens.
- **Replacing Lens Pen Cloths (x5):** Replacements for the lens cleaning pen.
- **Cleaning Spray Bottle (empty):** For use with a suitable cleaning solution (not included).

3. SETUP

Before first use, ensure all components are present and undamaged.

1. **Unpack:** Carefully remove all tools from the packaging.
2. **Prepare Spray Bottle:** The included spray bottle is empty. Fill it with a suitable electronic device

cleaning solution or distilled water. Do not use harsh chemicals or abrasive cleaners.

3. **Familiarize:** Identify each tool and its intended purpose as described in Section 2.

4. OPERATING INSTRUCTIONS

4.1. Keyboard Cleaning

1. **Keycap Removal:** Use the **Keycap Puller** to gently lift and remove keycaps from mechanical keyboards. Insert the puller under the keycap and pull upwards evenly.



Image: Demonstrating the use of the keycap puller to safely remove a keyboard key.

2. **Dust Removal:** Extend the **Retractable Large Brush** and sweep across the keyboard surface to remove loose dust and debris. For deeper cleaning between keys, use the **Thin Soft Brush**.

Right-angle Design Compatible with Four Corners of Computer Screen.

Widened & Thicken Cloth Clean the Dust More Effectively



Image: The retractable brush effectively removing dust and dirt from a keyboard.

3. **Crevice Cleaning:** For stubborn dirt in tight spaces, use the **Metal Pen Tip**. Apply gentle pressure to dislodge debris.

4.2. Screen Cleaning (Laptops, Monitors, Phones, Tablets)

1. **Spray Application:** Lightly mist the **Cleaning Spray Bottle** onto the **Polishing Cleaning Cloth**. Do not spray directly onto the screen.
2. **Wiping:** Gently wipe the screen surface with the damp polishing cloth in a single direction, then use a dry part of the cloth or the second polishing cloth to buff dry. The cloth's right-angle design helps reach screen corners.



Image: A laptop screen being cleaned using the spray bottle and polishing cloth, showing effective removal of fingerprints and smudges.

4.3. Earbuds and Charging Case Cleaning

1. **Case Interior:** Use the **Flocking Sponge** to clean the interior of earbud charging cases, removing dust and lint.
2. **Earbud Grilles/Ports:** Use the **Thin Soft Brush** or the **Metal Pen Tip** for delicate cleaning of earbud grilles, ports, and crevices.

WIDE APPLICATION

Cleaning All Your Electronic Devices



Computer & Keyboard



Laptop



Phone & iPad



Earphones & Earbud

Image: Detailed cleaning of earbuds and their charging case using the flocking sponge and metal pen tip.

4.4. Camera Lens Cleaning

1. **Dust Removal:** Use the **Soft Plastic Lens Cleaning Pen** to gently brush away dust from camera lenses.
2. **Smudge Removal:** If necessary, use the soft tip of the lens cleaning pen to gently remove smudges. Replace the cleaning cloth on the pen as needed with the provided replacements.



Image: The soft plastic lens cleaning pen being used to clean a camera lens.

4.5. General Device Cleaning

The various brushes and the metal pen tip can be used for cleaning ports, buttons, and other hard-to-reach areas on various electronic devices.



Image: A collage showing the kit's tools being used to clean lenses, speakers, screens, and buttons on various devices.

5. MAINTENANCE AND CARE

- **Cleaning Cloths:** The polishing cleaning cloths can be hand-washed with mild soap and water, then air-dried.
- **Brushes:** Gently clean the brushes by tapping out debris or using a soft cloth. Avoid harsh chemicals.
- **Spray Bottle:** Refill the spray bottle as needed with appropriate cleaning solution.
- **Storage:** Store all components in the provided compact case to prevent damage and keep them clean. Keep the kit in a cool, dry place away from direct sunlight.

6. TROUBLESHOOTING

- **Streaks on Screen:** Ensure the polishing cloth is clean and dry. Use a minimal amount of cleaning solution. Wipe in one direction and buff with a dry section.
- **Brush Not Cleaning Effectively:** Ensure the brush is free of accumulated debris. For heavy dirt, use the metal pen tip first to loosen, then brush.
- **Keycap Puller Not Working:** Ensure the keycap puller is correctly positioned under the keycap. Apply even, gentle pressure. Avoid excessive force to prevent damage.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.8 x 2.5 x 1.48 inches
Item Weight	4.2 ounces
Model Number	GW013
Brand	Ordilend
Material	Plastic
Liquid Volume (Spray Bottle)	1 Fluid Ounce (empty, for user-supplied solution)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the purchase documentation or contact your retailer. Keep your proof of purchase for any warranty claims.

For additional assistance or inquiries, please visit the official Ordilend store or contact their customer service department.