

hofstein Victorine H3663585

Hofstein Victorine Pendant Lamp with Shelf - Instruction Manual

Model: Victorine H3663585

Brand: Hofstein

INTRODUCTION

Thank you for purchasing the Hofstein Victorine Pendant Lamp with Shelf. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- **Electrical Safety:** Always disconnect power at the main circuit breaker before installation, maintenance, or bulb replacement. Installation should be performed by a qualified electrician if you are unsure.
- **Voltage:** This fixture is designed for 230 Volt electrical systems. Ensure your household voltage matches this requirement.
- **Bulb Type:** Use only E27 base bulbs. Do not exceed the maximum wattage of 60 Watts per bulb.
- **Indoor Use Only:** This product is rated IP20 and is intended for indoor use in dry locations only. Do not expose to moisture or direct water.
- **Handling:** Handle the lamp with care. Avoid dropping or subjecting it to strong impacts.
- **Cleaning:** Clean only with a dry, soft cloth. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Please verify that all components are present and undamaged before beginning installation.

- 1x Hofstein Victorine Pendant Lamp fixture (metal frame with shelf, 5 E27 sockets)

- Mounting hardware (ceiling bracket, screws, wall anchors)
- Instruction Manual
- *Note: E27 bulbs are not included and must be purchased separately.*



Image: All components of the Hofstein Victorine Pendant Lamp laid out, including the metal frame, electrical wiring, ceiling rose, and mounting bracket. This image helps to identify all parts included in the package.

INSTALLATION INSTRUCTIONS

Tools Required (not included): Screwdriver, wire strippers, drill, pencil, measuring tape, ladder.

1. Prepare for Installation:

- **Safety First:** Turn off the power supply at the main circuit breaker before starting any electrical work.
- Unpack all components and inspect for any damage.

2. Mark Mounting Position:

- Determine the desired location for the lamp on the ceiling.
- Hold the ceiling bracket (part of the mounting hardware) against the ceiling and mark the drilling points with a pencil.

3. Install Ceiling Bracket:

- Drill holes at the marked positions. Insert wall anchors if necessary (e.g., for plasterboard ceilings).
- Secure the ceiling bracket to the ceiling using the provided screws. Ensure it is firmly attached.

4. Adjust Height (if desired):

- The lamp's height is adjustable up to a maximum of 137 cm. Adjust the suspension cables to your preferred length before wiring.
- The adjustment mechanism is typically located at the ceiling rose or where the cables enter the fixture.



Image: A diagram illustrating the dimensions of the Hofstein Victorine Pendant Lamp, including its length (120cm), width (20cm), and maximum adjustable height (137cm). The ceiling rose diameter is also shown as 10cm.

5. Electrical Connection:

- Connect the household electrical wires to the corresponding wires of the lamp (Live to Live, Neutral to Neutral, Earth to Earth). If unsure, consult a qualified electrician.
- Ensure all connections are secure and properly insulated.

6. Attach Fixture to Ceiling:

- Carefully lift the lamp fixture and attach it to the installed ceiling bracket, securing it with the provided screws or fasteners.

- Ensure the fixture is stable and flush against the ceiling.

7. Install Bulbs:

- Screw E27 base bulbs (not included) into the five sockets. Do not overtighten.
- Ensure the bulbs do not exceed 60 Watts each.

8. Restore Power:

- Once installation is complete, turn the power supply back on at the main circuit breaker.
- Test the lamp to ensure it functions correctly.



Image: The Hofstein Victorine Pendant Lamp installed above a dining table, showcasing its black metal frame, five exposed E27 bulbs, and integrated shelf decorated with small plants and decorative items. This image demonstrates the lamp's appearance in a typical home setting.

OPERATING INSTRUCTIONS

The Hofstein Victorine Pendant Lamp is operated via a standard wall switch connected to your household electrical system. It does not feature an integrated switch.

- **Turning On/Off:** Use the wall switch to turn the lamp on or off.
- **Dimming Functionality:** This lamp is dimmable if connected to an external dimmer switch (not

included) and if dimmable E27 bulbs are used. Consult a qualified electrician for dimmer installation.

- **Shelf Use:** The integrated shelf can be used for lightweight decorative items. Do not overload the shelf to avoid damage to the fixture or injury.

MAINTENANCE

- **Cleaning:**
 - Always disconnect power before cleaning.
 - Wipe the metal surfaces with a soft, dry, lint-free cloth.
 - Do not use abrasive cleaners, solvents, or polishes as these may damage the finish.
- **Bulb Replacement:**
 - Ensure the lamp is turned off and has cooled down before replacing bulbs.
 - Carefully unscrew the old E27 bulb and screw in a new one.
 - Use only E27 base bulbs with a maximum of 60 Watts.
- **Periodic Inspection:**
 - Periodically check all connections and mounting points to ensure they remain secure.
 - Inspect the electrical cord for any signs of wear or damage. If damage is found, discontinue use and consult a qualified electrician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not light up.	<ul style="list-style-type: none">• No power supply.• Loose electrical connection.• Faulty bulb.	<ul style="list-style-type: none">• Check circuit breaker and wall switch.• Ensure all electrical connections are secure (consult electrician if unsure).• Replace bulb(s) with new, working E27 bulbs.
Flickering light.	<ul style="list-style-type: none">• Loose bulb.• Incompatible dimmer (if applicable).• Faulty bulb.	<ul style="list-style-type: none">• Tighten bulb securely.• Ensure dimmer is compatible with LED/incandescent bulbs.• Replace bulb.
Lamp is unstable after installation.	<ul style="list-style-type: none">• Mounting screws are loose.• Improper ceiling bracket installation.	<ul style="list-style-type: none">• Tighten all mounting screws.• Re-evaluate ceiling bracket installation; ensure it is securely fastened to a suitable ceiling structure.

SPECIFICATIONS

Model Name	Victorine
Model Number	H3663585 (4058383663585)
Brand	Hofstein
Type	Pendant Lamp with Shelf
Dimensions (L x W x H)	120 cm x 20 cm x 137 cm (max. height)
Material	Metal (Fixture and Shade)
Color	Chrome, Black
Number of Lights	5
Socket Type	E27
Max. Wattage per Bulb	60 Watts
Bulbs Included	No
Dimmable	Yes, with external dimmer (not included) and dimmable bulbs
Power Supply	230 Volt
Protection Class	IP20 (Indoor Use Only)
Installation Type	Ceiling Mount / Semi-flush mount
Adjustable Height	Yes, during installation

WARRANTY AND SUPPORT

Hofstein products are manufactured with quality and durability in mind. For information regarding warranty terms and conditions, please refer to the documentation provided with your purchase or visit the official Hofstein website.

If you encounter any issues or require technical assistance, please contact Hofstein customer support. Contact details can typically be found on the product packaging or the brand's official website.

Online Resources: [Visit the Hofstein Store on Amazon](#)