

[Manuals.plus](#) /

› [ELEVON](#) /

› Elevon FAGYJ001WH Compact Clothes Dryer User Manual

ELEVON FAGYJ001WH

Elevon FAGYJ001WH Compact Clothes Dryer User Manual

Model: FAGYJ001WH

INTRODUCTION

Thank you for choosing the Elevon FAGYJ001WH Compact Clothes Dryer. This manual provides important information for the safe and efficient operation of your new appliance. Please read it thoroughly before use and keep it for future reference.

This compact front-load dryer features a stainless steel drum and is designed for small living spaces such as apartments, condominiums, or RVs. It offers multiple drying modes to suit various fabric types and drying needs.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they emit vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the drying compartment.
- Do not reach into the appliance if the drum is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.
- Do not use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- Do not use heat to dry articles containing foam rubber or similarly textured rubber-like materials.

- Clean the lint screen before or after each load.
- Keep the area around the exhaust opening and adjacent surrounding areas free from the accumulation of lint, dust, and dirt.
- The interior of the appliance and exhaust duct should be cleaned periodically by qualified service personnel.
- Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.
- Do not use this appliance for purposes other than its intended use.
- Always disconnect the appliance from the power supply before servicing.

PRODUCT OVERVIEW

The Elevon FAGYJ001WH dryer is designed for efficient and quiet operation. Key features include:

- **Auto Stop When Door Opened:** For safety, the dryer automatically pauses operation if the door is opened during a cycle.
- **Stainless Steel Inner Drum:** Durable and gentle on clothes.
- **Wall Mounted Option:** Can be installed on a wall to save floor space.
- **See-Through Window:** Allows monitoring of the drying process.
- **Minimal Noise Design:** Engineered for quiet operation.
- **Air Intake Filter:** Helps maintain air quality and dryer efficiency.

About our product



Figure 1: Overview of the Elecon FAGYJ001WH Compact Clothes Dryer highlighting its main features.

SETUP AND INSTALLATION

The Elecon FAGYJ001WH dryer comes with necessary accessories for installation. Ensure you have adequate space and proper ventilation before beginning.

Unpacking

- Carefully remove the dryer from its packaging.
- Check for any shipping damage. If damaged, do not operate and contact customer support.
- Ensure all included components are present: 1 x Laundry Dryer, 1 x Instruction Manual, 1 x Exhaust Vent, 1 x Wall Mounting Kit.

Placement

- Place the dryer on a firm, level surface.

- Ensure there is sufficient clearance around the dryer for proper air circulation and maintenance.
- The dryer can also be wall-mounted using the provided kit. Refer to the wall mounting instructions included with the kit for detailed steps.

Ventilation

- Connect the exhaust vent to the dryer and direct it to an outdoor vent or a suitable lint trap system.
- Ensure the exhaust path is clear and not obstructed to prevent lint buildup and ensure efficient drying.



Figure 2: Product dimensions and included accessories for installation.

OPERATING INSTRUCTIONS

Follow these steps for optimal drying performance.

Loading the Dryer

- Open the dryer door and load clothes into the stainless steel drum.
- Do not overload the dryer. For quick drying, do not exceed 5.5 pounds of clothes at a time. The maximum capacity is 10 pounds (wet clothes).
- Close the dryer door securely.

Famliy Dependable Companion

- Tangle Free, Shorter Drying Time
- Energy Saving, Extend Product Life




Figure 3: Clothes being dried in the stainless steel drum, demonstrating efficient and tangle-free drying.

Control Panel and Drying Modes

The control panel allows you to select different drying modes and set the timer.



Figure 4: Control panel with various drying modes and their recommended uses.

Adjust the timer and heat settings according to the fabric type and desired dryness:

- **Cool (0-20 minutes):** Used to cool down the temperature of clothes after a hot cycle or for delicate items that require no heat.
- **Warm (30-120 minutes):** For general drying and to help reduce wrinkles. Suitable for most everyday garments.
- **Hot (120-200 minutes):** Ideal for drying large quantities or bulky items that require higher heat and longer drying times.
- **Air Dry (0-80 minutes):** Runs with cool air to freshen clothes without heat.

Select the appropriate mode and time, then start the dryer. The dryer will automatically stop when the cycle is complete or if the door is opened.

Double Sterilization Feature

This dryer incorporates a high-temperature cycle system designed to achieve a 99% sterilization rate, providing an extra layer of hygiene for your laundry.

DOUBLE STERILIZATION

High --temperature-cycle system to achieve 99%sterilization rate



Figure 5: Visual representation of the dryer's double sterilization capability.

MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your dryer.

Cleaning the Lint Filter

- The lint filter should be cleaned before or after every load.
- Locate the lint filter inside the dryer drum.
- Remove the filter and gently pull off any accumulated lint.
- Rinse the filter with water if necessary and ensure it is completely dry before reinserting.

Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.

- Do not use abrasive cleaners or solvents.

Exhaust Vent Maintenance

- Periodically check the exhaust vent for lint buildup and obstructions.
- Clean the exhaust duct as needed to maintain proper airflow and prevent fire hazards. This should ideally be done by qualified service personnel.

TROUBLESHOOTING

If you encounter issues with your dryer, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Dryer does not start.	Power cord unplugged; Door not closed properly; Circuit breaker tripped.	Ensure power cord is securely plugged in; Close door firmly; Check and reset circuit breaker.
Clothes are not drying completely.	Overloaded dryer; Lint filter clogged; Incorrect drying mode/time selected; Restricted exhaust vent.	Reduce load size; Clean lint filter; Select appropriate drying mode and time; Check and clear exhaust vent.
Dryer is noisy.	Foreign objects in drum; Dryer not level; Loose parts.	Check drum for foreign objects; Ensure dryer is on a level surface; Contact customer support if noise persists.
Dryer stops during cycle.	Door opened; Overheating protection activated.	Close door securely; Allow dryer to cool down, then restart. Check for blocked vents if overheating is frequent.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	ELEVON
Model Number	FAGYJ001WH
Capacity	1.5 Cubic Feet
Form Factor	Front Load
Material	Drum Stainless Steel
Color	White/Black
Product Dimensions (D x W x H)	41.9D x 49.5W x 61.7H Centimetres
Manufacturer	ROCSUMOO

Feature	Detail
UPC	810127325227
Included Components	1 x Laundry Dryer, 1 x Instruction, 1 x Exhaust Vent, 1 x Wall Mounting Kit

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact Elevon customer service. Keep your purchase receipt as proof of purchase.

Customer Support: For assistance, please visit the official Elevon website or contact the retailer where the product was purchased.

© 2023 ELEVON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C2XYHL81>

More documents and user manuals: <https://manuals.plus/>