

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Mattel](#) /

> [Fisher-Price Little People Farm Animal Friends Playset Replacement White Cow Figure \(Model GFL21\) Instruction Manual](#)

Mattel GFL21

Instruction Manual for Fisher-Price Little People Farm Animal Friends Playset Replacement White Cow Figure

Brand: Mattel | Model: GFL21

1. INTRODUCTION

This document provides essential information for the Fisher-Price Little People Farm Animal Friends Playset Replacement White Cow Figure, Model GFL21. It covers product overview, setup, operating instructions, care, specifications, and safety guidelines to ensure proper use and longevity of the figure.

2. PRODUCT OVERVIEW

The replacement white cow figure is an authentic component designed for the Fisher-Price Little People Farm Animal Friends Playset, Model GFL21. It features a black and white cow design with a yellow bell around its neck, crafted for durability and safe play for young children.




Image: Front-side view of the Fisher-Price Little People white cow figure, showing its black spots, brown snout, and yellow bell.



Replacement Cow Figure Only

Image: Direct front view of the Fisher-Price Little People white cow figure, highlighting its facial features and bell.



Replacement Cow Figure Only

Image: Rear view of the Fisher-Price Little People white cow figure, showing its tail and additional black spots.

3. SETUP

This replacement figure requires no assembly. It is ready to use directly out of its packaging.

4. OPERATING INSTRUCTIONS

The white cow figure is designed for imaginative play. It can be used as a standalone toy or integrated with the Fisher-Price Little People Farm Animal Friends Playset (GFL21) to enhance storytelling and interactive play scenarios. No specific operational steps are required beyond placing the figure in desired play environments.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the figure with a damp cloth and mild soap if necessary. Rinse thoroughly with clean water and air dry. Do not immerse in water for extended periods.
- **Storage:** Store the figure in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspection:** Periodically inspect the figure for any signs of wear or damage. Discontinue use if any parts are broken or detached to prevent choking hazards.

6. SPECIFICATIONS

Product Dimensions	2 x 1 x 1 inches
Item Weight	1.92 ounces
Model Number	GFL21
Manufacturer	Mattel
Recommended Age	36 months - 12 years

7. SAFETY INFORMATION

- This product is intended for children aged 36 months to 12 years.
- Adult supervision is recommended during play.
- Keep away from open flames or heat sources.
- Do not allow children to put the toy in their mouth if there is a risk of small parts detaching.

8. WARRANTY AND SUPPORT

For warranty information or product support, please contact Mattel customer service. Details can typically be found on the official Mattel website or product packaging. Please retain your proof of purchase for any warranty claims.

Mattel Customer Service: Please visit service.mattel.com for contact options and support resources.