

## LIVINGTON M34868

# Livington Steam Twister Rotary Steam Cleaner User Manual

Model: M34868

## 1. INTRODUCTION

Thank you for choosing the Livington Steam Twister. This innovative rotary steam cleaner is designed to provide efficient and chemical-free cleaning for various surfaces in your home. With its unique Duopad system and versatile handheld function, it offers a powerful solution for maintaining a hygienic environment. Please read this manual carefully before first use to ensure safe and optimal operation of your device.

## 2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- Do not use the appliance on unsealed wooden floors or floors that are sensitive to heat and moisture.
- Always ensure the water tank cap is securely closed before operation.
- Do not direct steam at people, animals, or electrical outlets.
- Use only manufacturer's recommended attachments.
- Store the appliance indoors in a cool, dry place.

## 3. PACKAGE CONTENTS

Carefully unpack your Livingston Steam Twister and check that all items are present:

- 1 Livingston Steam Twister Main Unit
- 2 Microfiber (MF) Pads
- 1 Large Round Plastic Brush
- 1 Corner Nozzle
- 1 Squeegee
- 1 Jet Nozzle
- 1 Small Metal Brush
- 1 Measuring Cup



Image 1: The Livingston Steam Twister main unit shown with all its included accessories, such as microfiber pads, various brushes, nozzles, a squeegee, and a measuring cup.

## 4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Steam Twister:

- **Handle:** Ergonomic grip for comfortable use.
- **Water Tank:** Reservoir for filling with water.
- **Steam Control Buttons:** Buttons to select desired steam level.
- **Main Unit:** Houses the heating element and motor.
- **Rotating Duopads:** Two microfiber pads that rotate for cleaning, polishing, and drying.
- **Handheld Release Button:** Allows conversion to a handheld steam cleaner.



Image 2: A full view of the Livingston Steam Twister, highlighting its sleek design and the rotating cleaning pads at the base.

## 5. SETUP

### 5.1 Assembly

1. Attach the handle to the main unit until it clicks securely into place.
2. Securely attach the two microfiber pads to the rotating base of the steam cleaner. Ensure they are centered and firmly attached.

### 5.2 Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Locate the water tank cap, usually on the main unit.
3. Open the cap and use the provided measuring cup to fill the tank with clean tap water. Do not overfill. The tank volume is 350 ml.
4. Securely close the water tank cap.

## 6. OPERATING INSTRUCTIONS

### 6.1 Using as a Steam Mop

1. Plug the power cord into a suitable electrical outlet (230 Volts).
2. The appliance will begin to heat up. It is ready for use in approximately 15 seconds.
3. Select one of the 3 automatic steam levels suitable for your floor type using the steam control buttons.
4. Begin cleaning by moving the Steam Twister across the floor. The rotating Duopads will clean, polish, and dry the surface simultaneously.



Image 3: A person operating the Livingston Steam Twister on a wooden floor, demonstrating its ease of use for floor cleaning.




Image 4: A close-up view of the Steam Twister's rotating pads, illustrating the steam and rotation action for effective cleaning.

## 6.2 Using as a Handheld Steam Device

1. Unplug the appliance. Press the handheld release button to detach the main unit from the handle and floor head.
2. Attach the desired accessory (e.g., large round plastic brush, corner nozzle, jet nozzle, small metal brush, or squeegee) to the handheld unit.
3. Plug the handheld unit into a power outlet.
4. Once heated, direct the steam towards the surface you wish to clean. This mode is ideal for kitchen countertops, windows, bathroom tiles, shower walls, and other hard-to-reach areas.






Image 5: A person using the Livingston Steam Twister in its handheld configuration to clean a glass surface, demonstrating its versatility.



Image 6: The handheld steam unit being used with an attachment to clean a kitchen sink faucet, showing its utility for detailed cleaning.

### 6.3 Surface Recommendations

The Livingston Steam Twister is suitable for various sealed hard floor surfaces, including:

- Tiles
- Linoleum
- Sealed Hardwood
- Laminate

Always test on a small, inconspicuous area first to ensure compatibility. Do not use on unsealed or delicate surfaces.



Image 7: A collage displaying various floor types such as tiles, sealed wood, and linoleum, indicating surfaces suitable for the Steam Twister.

## 7. MAINTENANCE

---

### 7.1 Cleaning the Microfiber Pads

The microfiber pads can be machine washed with similar colors. Do not use bleach or fabric softener. Air dry or tumble dry on low heat.

### 7.2 Emptying and Cleaning the Water Tank

After each use, unplug the appliance and allow it to cool completely. Empty any remaining water from the tank. Periodically, clean the tank with a mild descaling solution if mineral buildup occurs, following the solution's instructions.

### 7.3 Storage

Store the Livingston Steam Twister in an upright position in a cool, dry place. Ensure the power cord is neatly wrapped. Do not store with water in the tank for extended periods.





Image 8: The Livingston Steam Twister stored upright in a corner, demonstrating its compact storage capability.

## 8. TROUBLESHOOTING

If you encounter issues with your Livingston Steam Twister, refer to the following common problems and solutions:

- **No Steam:**

- Check if the appliance is properly plugged in.
- Ensure the water tank is filled.
- Allow sufficient time for the appliance to heat up (approx. 15 seconds).
- Check if the steam control is set to an active level.

- **Poor Cleaning Performance:**

- Ensure microfiber pads are clean and properly attached.
- Increase the steam level if necessary.
- Pre-treat heavily soiled areas if needed.

- **Water Leaking:**

- Ensure the water tank cap is securely closed.
- Do not overfill the water tank.

If the problem persists after trying these solutions, please contact customer support.

## 9. SPECIFICATIONS

Feature	Specification
Brand	LIVINGTON
Model Number	M34868
Color	White
Product Dimensions (L x W x H)	24 x 18 x 51 cm
Item Weight	3 Kilograms

Voltage	230 Volts
Material	ABS, Plastic, Aluminum
Special Feature	Handheld Steam Device
Surface Recommendation	Tile, Linoleum
Tank Volume	350 Milliliters
Form Factor	Portable




## 10. WARRANTY AND SUPPORT




Specific warranty details for the Livingston Steam Twister are not provided within this manual. For warranty information, spare parts availability, or further support, please refer to the documentation included with your purchase or contact Livingston customer service directly.

You may also visit the official Livingston website for additional resources and contact information.

© 2023 LIVINGTON. All rights reserved.

### Related Documents - M34868

	<p><a href="#">Livingston PRIME EVERYDAY Cordless Vacuum Cleaner Manual</a></p> <p>This comprehensive manual provides detailed instructions for the Livingston PRIME EVERYDAY cordless vacuum cleaner, covering setup, operation, maintenance, troubleshooting, and safety guidelines.</p>
	<p><a href="#">Livingston PRIME® Steam Mop Bedienungsanleitung</a></p> <p>Entdecken Sie den Livingston PRIME® Steam Mop, ein vielseitiges Reinigungsgerät für Ihr Zuhause. Diese Anleitung bietet detaillierte Informationen zur Verwendung, Sicherheit und Wartung.</p>
	<p><a href="#">Livingston Deeper Sweeper: User Manual &amp; Instructions for Use</a></p> <p>Comprehensive user manual for the Livingston Deeper Sweeper. Find detailed instructions on safety, assembly, operation, maintenance, and technical specifications for this cordless electric sweeper.</p>

 <p>Livingston <b>Mini-Tischsauger</b></p> <p>851116 Livingston_Mini Tischsauger_Manual_85117_20200322085800 15.07</p>	<p><a href="#">Livingston Mini Table Vacuum Cleaner Manual</a></p> <p>User manual and safety instructions for the Livingston Mini Table Vacuum Cleaner. Learn how to operate, clean, and maintain your device.</p>
 <p>Livingston <b>CHILLTOWER</b> TURBO REPLACEMENT FILTER &amp; CLEANING GUIDE</p> <p>851116 Livingston_ChillTower_Turbo_Manual_85117_20200322085800 15.07</p>	<p><a href="#">Livingston ChillTower Turbo Replacement Filter &amp; Cleaning Guide</a></p> <p>Instructions for replacing and cleaning the filter for the Livingston ChillTower Turbo air cooler. Includes maintenance tips and importer contact information.</p>
 <p>LIVINGSTON <b>MultiScrubber</b></p> <p>851116 Livingston_MultiScrubber_Manual_85117_20200322085800 15.07</p>	<p><a href="#">Livingston MultiScrubber User Manual</a></p> <p>This manual provides instructions for the Livingston MultiScrubber, covering assembly, usage, cleaning, and troubleshooting. It details the product's features, technical specifications, and safety precautions for optimal performance and user safety.</p>