

[Manuals.plus](#) /

› [SENCKIT](#) /

› SENCKIT Bluetooth Tracker User Manual

SENCKIT S1 (Black - 2 pack)

SENCKIT Bluetooth Tracker User Manual

Model: S1

1. INTRODUCTION

The SENCKIT Bluetooth Tracker is a smart item finder designed to help you locate your valuable belongings quickly and efficiently. Utilizing Apple's Find My network, it allows you to track items both nearby and far away. This device is ideal for keys, bags, wallets, pets, and more.

Key features include:

- **Find Nearby and Far:** Use the Find My app to ring your tracker when it's within Bluetooth range or locate it using the vast Apple Find My network.
- **Free Left-Behind Alerts:** Receive notifications on your iOS device if you leave your tracker behind.
- **Privacy Protection:** All communication within the Find My network is anonymous and encrypted, ensuring your location data remains private.
- **Easy Pairing:** Simple setup with the pre-installed Apple Find My app.
- **Portable and Durable:** IP65 water resistant design with a loud 90dB ring and up to 1 year of battery life.

2. WHAT'S IN THE BOX

Your SENCKIT Bluetooth Tracker package includes:

- 2 x SENCKIT Bluetooth Trackers
- Instruction Manual



Image: Two SENCKIT Bluetooth trackers, black, square-shaped with rounded corners, attached to keyrings. A smartphone on the right displays the Apple Find My app interface, showing a map and item locations. This image illustrates the product and its primary function.

3. PRODUCT OVERVIEW

The SENCKIT Bluetooth Tracker is compact and designed for easy attachment to various items. It features a replaceable battery for extended use.

Wearable

Wearable on kids/pets/items



Can't find pet



Key not found



Can't find wallet



Can't find backpack

Image: A technical diagram of the SENCKIT Bluetooth Tracker, showing its square shape with dimensions of 38mm by 38mm and a thickness of 7mm. Below the diagram, a table lists product specifications including model (iTag), weight (8.7g), battery type (CR2032 Replaceable), buzzer (90dB), standby time (Up to 1 year), wireless range (10-20M Indoor, 20-30M Outdoor), and compatibility (iOS, iPadOS, macOS).

4. SETUP

4.1. Battery Installation

The SENCKIT Bluetooth Tracker comes with a pre-installed CR2032 battery. If you need to replace it, follow these steps:

1. Gently open the tracker casing.
2. Remove the old CR2032 battery.
3. Insert a new CR2032 battery with the positive (+) side facing up.
4. Close the casing securely.

Automatically Contact The Owner

Turn on "Lost Mode",
and if there is an Apple mobile phone nearby,
the tracker will display your contact number




Image: The SENCKIT Bluetooth Tracker is shown disassembled, with its back cover removed to expose the internal circuit board and a CR2032 coin cell battery. A smartphone screen next to it displays the 'Power Display' section of the Find My app, indicating battery status. This image demonstrates how to access and replace the battery.

4.2. Pairing with Apple Find My App

To pair your SENCKIT Bluetooth Tracker with your iOS device, ensure your device is running the latest version of iOS, iPadOS, or macOS.

1. Open the pre-installed **Find My** app on your Apple device.
2. Tap the **Items** tab at the bottom of the screen.
3. Tap **Add Item**, then select **Other Supported Item**.
4. Follow the on-screen prompts to connect your SENCKIT tracker. This usually involves pressing a button on the tracker to initiate pairing.
5. Once detected, tap **Connect**.
6. Link the tracker to your Apple ID and agree to the terms.
7. Give your tracker a name (e.g., "Keys," "Wallet," "Backpack") and assign an emoji if desired.
8. Tap **Finish**. Your tracker is now paired and visible in the Find My app.

Pet**Bag****Luggage****Keys****Wallet****Backpack**

Image: A sequence of three smartphone screenshots illustrating the initial steps to add an item to the Apple Find My app. The first screen shows the Find My app icon, the second shows the 'Items' tab with an 'Add Item' button, and the third shows the option to select 'Other Supported Item'.




**4. Tap "Connect"****5. Link to your Apple ID****6. Finish**

Image: A sequence of three smartphone screenshots illustrating the final steps to add an item to the Apple Find My app. The first screen shows a 'Connect' prompt for the iTag, the second shows a privacy warning and an 'Agree' button, and the third shows the successfully added item (Key) on the map with options like 'Play Sound' and 'Directions'.

5. OPERATING INSTRUCTIONS

5.1. Finding Nearby Items

When your SENCKIT Bluetooth Tracker is within Bluetooth range of your Apple device, you can make it play a sound to help you locate it.

1. Open the **Find My** app.
2. Go to the **Items** tab.
3. Select the SENCKIT tracker you wish to find.
4. Tap **Play Sound**. The tracker will emit a loud sound (up to 90dB) to guide you to its location.
5. Tap **Stop Sound** once you've found your item.

Voice Prompt

When near the tracker, click "play sound",
the tracker will beep



Image: A smartphone displays the Apple Find My app, showing a map and options for a selected item. A speech bubble points to 'Stop sound playing...' indicating the sound feature. Next to the phone, a SENCKIT tracker attached to a set of keys is shown, with sound waves emanating from it, illustrating the 'Play Sound' function.




Image: A hand holds a smartphone displaying the Find My app, with a prominent 'Call Device' icon. On a table in the foreground, a SENCKIT tracker is shown next to a set of keys, with sound waves indicating it is ringing. This image demonstrates how to trigger the tracker's alarm from the app to find nearby items.

5.2. Finding Far-Away Items

If your item is out of Bluetooth range, the Apple Find My network can help you locate it. Hundreds of millions of Apple devices around the world anonymously detect your tracker's signal and relay its location to you.

1. Open the **Find My** app.
2. Go to the **Items** tab.
3. Select the SENCKIT tracker you are looking for.
4. The app will display its last known location on a map. If it's detected by another Apple device, its current location will be updated.
5. You can get directions to the tracker's location directly from the app.



GPS BT Tracking Not Afraid Of Losing Items

When you can't find it,
open the APP and enter the map to view the location



Image: A smartphone displays the Apple Find My app, showing a detailed map with a pin indicating the location of an item. The text overlay reads "GPS BT Tracking Not Afraid Of Losing Items" and "When you can't find it, open the APP and enter the map to view the location." This illustrates the tracker's ability to show its location on a map.

5.3. Left-Behind Alerts

To receive notifications when you leave your SENCKIT tracker behind:

1. In the **Find My** app, select your SENCKIT tracker.
2. Under the **Notifications** section, enable the **Notify When Left Behind** toggle.
3. You can also set exceptions for specific locations where you don't want to be notified (e.g., your home).

5.4. Lost Mode

If your SENCKIT tracker is lost, you can enable Lost Mode to display a message and contact information to anyone who finds it.

1. In the **Find My** app, select your SENCKIT tracker.
2. Scroll down to the **Lost Mode** section and tap **Enable**.

3. Follow the prompts to enter a phone number or email address where you can be contacted.
4. You can also choose to be notified when your item is found.

Power Display

Check the power at any time,
detachable and install the battery




Image: A smartphone displays the Apple Find My app's 'Lost Mode' screen. It shows a circular radar-like graphic and a placeholder for contact information (an email address). Below, options like 'Notify When Found', 'Find My Lock', and 'Leave a Message' are visible, indicating features for a lost item. The text overlay states "Automatically Contact The Owner" and explains that if an Apple mobile phone is nearby, the tracker will display your contact number.

5.5. Usage Scenarios

The SENCKIT Bluetooth Tracker is versatile and can be attached to a variety of items:

- **Keys:** Attach to your keyring to easily find misplaced keys.
- **Bags/Backpacks:** Secure to your luggage or backpack for peace of mind while traveling or commuting.
- **Wallets:** Slip into your wallet to prevent losing it.
- **Pets:** Attach to your pet's collar to help locate them if they wander off.

Product Size



Model: iTag

Product Size: 38*38*7mm

Product Weight: 8.7g

Battery: CR2032 Replaceable

Buzzer: 90Db≤

Standby: Up to 1 year

Wireless Range: 10–20M(Indoor) 20–30(Out door)

Supports: To use the Apple Find My app to locate your Item Locator, the latest version of iOS, iPadOS, or macOS is recommended.

Image: A collage of four images demonstrating the versatility of the SENCKIT Bluetooth Tracker. It shows the tracker attached to a dog's collar, a set of car keys, inside a wallet, and inside a backpack, with captions like "Can't find pet," "Key not found," "Can't find wallet," and "Can't find backpack." The main title is "Wearable: Wearable on kids/pets/items."



Image: A grid of six circular images, each depicting the SENCKIT Bluetooth Tracker attached to a different item: a pet's collar, a handbag, a piece of luggage, a set of keys, a wallet, and a backpack. This visually demonstrates the wide range of applications for the tracker.

6. MAINTENANCE

6.1. Battery Replacement

The SENCKIT Bluetooth Tracker uses a replaceable CR2032 coin cell battery, which typically lasts up to one year. When the battery is low, you will receive a notification on your paired Apple device. Refer to section 4.1 for detailed battery replacement instructions.



Image: A white SENCKIT Bluetooth Tracker is centered within a large circular graphic resembling a clock face, with '365 day' prominently displayed. The text above reads "Replaceable battery for long-term use." This image highlights the tracker's long battery life and the ease of battery replacement.

6.2. Cleaning

To clean your SENCKIT Bluetooth Tracker, wipe it gently with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the device.

7. TROUBLESHOOTING

- Tracker not connecting to Find My app:

Ensure Bluetooth is enabled on your Apple device. Make sure the tracker's battery is not depleted. Try restarting your Apple device and re-initiating the pairing process (refer to section 4.2).

• **Tracker not playing sound:**

Check if the tracker is within Bluetooth range of your device. Ensure the battery is not low. If the issue persists, try re-pairing the device.

• **Location not updating:**

The tracker's location updates when it comes within range of any Apple device on the Find My network. If it's in a remote area with no Apple devices nearby, its location may not update frequently. Ensure your own device has an active internet connection to receive location updates.

• **Left-behind alerts not working:**

Verify that 'Notify When Left Behind' is enabled for your tracker in the Find My app settings. Check if you have set any 'Notify Me Except At' locations that might be preventing alerts.

8. SPECIFICATIONS

Model Number	S1 (Black - 2 pack)
Product Dimensions	1.45 x 1.45 x 0.27 inches (38 x 38 x 7 mm)
Item Weight	1.44 ounces (approx. 8.7g per tracker)
Battery Type	CR2032 (replaceable, included)
Battery Life	Up to 1 year
Connectivity	Bluetooth
Water Resistance	IP65
Buzzer Volume	Up to 90dB
Wireless Range	10-20 meters (Indoor), 20-30 meters (Outdoor)
Compatibility	iOS (Apple Find My app), iPadOS, macOS

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact SENCKIT customer service. Refer to the packaging or the official SENCKIT website for the most up-to-date contact details.

Manufacturer: SENCKIT