

[Manuals.plus](#) /

› [BUFFBEE](#) /

› Buffbee Sound Machine & Alarm Clock BK11 User Manual

BUFFBEE BK11

Buffbee Sound Machine & Alarm Clock BK11 User Manual

Model: BK11

1. INTRODUCTION

The Buffbee Sound Machine & Alarm Clock BK11 is a versatile 2-in-1 device designed to enhance sleep and provide a reliable alarm function. It features 18 soothing sounds, a precise 30-level volume control, an adjustable clock face brightness, a sleep timer, and a bottom colored light for ambient illumination.

2 IN 1



SOUND MACHINE

Sleep Better with 18
Soothing Sounds



ALARM CLOCK

Wake Up with
5 Alarm Sounds



Image 1.1: The Buffbee Sound Machine & Alarm Clock, highlighting its dual functionality as a sound machine and an alarm clock.

2. SAFETY INFORMATION

- Do not use the device near water or in excessively humid environments to prevent the risk of electric shock.
- Avoid prolonged exposure to high volume levels to prevent potential hearing damage.
- This product is not intended for use as a toy and should be kept out of reach of children.

3. PRODUCT COMPONENTS & CONTROLS

Familiarize yourself with the device's layout and controls for optimal operation.




Image 3.1: Top and side view of the Buffbee Sound Machine, illustrating the location of the alarm, sound machine, volume control, night light buttons, and the adapter port with display dimmer switch.

Control Functions:

- **Alarm Button:** Used to set and manage alarms.
- **Sound Machine Button:** Cycles through available soothing sounds.
- **Volume Control Buttons (+/-):** Adjusts the sound output level.
- **Night Light Button:** Controls the bottom colored light.
- **Adapter Port (DC 5V):** For power connection.
- **Display Dimmer Switch:** Adjusts the brightness of the clock face (0-100%).

4. SETUP

4.1 Power Connection

1. Locate the DC 5V adapter port on the back of the device.
2. Plug the provided power adapter into the port.
3. Connect the power adapter to a standard electrical outlet. The device will power on automatically.

4.2 Initial Clock Setting

Upon first power-on or after a power interruption, you may need to set the correct time. Refer to the operating instructions for setting the clock and alarm.

5. OPERATING INSTRUCTIONS

5.1 Sound Machine Functions

The device offers 18 soothing sounds to aid sleep and relaxation.

Sleep Better with 18 Soothing Sounds




Image 5.1: Visual representation of the 18 soothing sounds available, including 5 white noises, 3 fan sounds, and 10 nature sounds.

Sound Selection:

- Press the **Sound Machine** button to cycle through the 18 available sound options.
- The sounds include 5 white noises, 3 fan sounds, and 10 nature sounds (ocean, lullaby, waves, rain, thunderstorm, brook, croaking, bird chirping, summer night, and campfire).

Volume Control:

- Use the **Volume +/-** buttons to adjust the sound output. There are 30 levels of precise volume control.

Sleep Timer:

- Press the **Timer** button to set an auto-off timer.
- Available timer options range from 15 to 120 minutes (15, 30, 60, 90, 120 minutes) or continuous play.

Auto-Off Timer

15,30,60,90,120 mins
or continuous play



30-Level Precise Volume Control

Image 5.2: Close-up of the device's top controls, illustrating the auto-off timer and 30-level precise volume control features.

5.2 Alarm Clock Functions

The integrated alarm clock provides a reliable wake-up function.

Digital Alarm Clock

- ✓ 5 wake up sounds
- ✓ 30 levels volume control
- ✓ 0-100% dimmer of clock face



Image 5.3: The device functioning as a digital alarm clock, highlighting its 5 wake-up sounds, 30-level volume control, and 0-100% dimmer for the clock face.

Setting the Alarm:

- Press and hold the **Alarm** button to enter alarm setting mode.
- Use the **Volume +/-** buttons to adjust the hour and minute.
- Press the **Alarm** button again to confirm each setting.

Alarm Sounds:

- The alarm clock features 5 distinct wake-up sounds.
- Cycle through alarm sounds during alarm setting or by pressing a dedicated button (if available, refer to specific button labels).

Alarm Volume:

- The alarm volume can be adjusted using the **Volume +/-** buttons, offering 30 levels of control.

5.3 Clock Display Brightness Adjustment

The clock face brightness can be adjusted from 0% (completely dark) to 100% (full brightness).

0-100% DISPLAY DIMMER

Clock Face can be dimmed completely or brightened to your preference.



Image 5.4: The device's clock display at various brightness levels, demonstrating the 0-100% dimmer functionality.

- Use the **Display Dimmer Switch** located on the side of the device to adjust the clock face brightness to your preference.

5.4 Bottom Colored Light Operation

The device includes a bottom colored light to create a relaxing ambiance.

7 Colors Night Light

With turn ON/OFF options



Image 5.5: The device with its bottom colored light illuminated, showing the availability of 7 color options.

- Press the **Night Light** button to turn the light on/off and cycle through the 7 available color options.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the device in a cool, dry place.
- **Avoid Obstructions:** Ensure the speaker grille and ventilation openings are not blocked to maintain optimal performance.

7. TROUBLESHOOTING

7.1 No Power / Device Not Turning On

- Ensure the power adapter is securely plugged into both the device and a working electrical outlet.

- Verify that the power outlet is functional by testing it with another device.

7.2 No Sound Output

- Check the volume level using the **Volume +/-** buttons. Ensure it is not set to the lowest level (0).
- Confirm that a sound is selected and playing.

7.3 Clock Display Too Bright/Dim

- Adjust the **Display Dimmer Switch** on the side of the device to your desired brightness level.

7.4 Alarm Not Sounding

- Ensure the alarm is set correctly and activated.
- Check the alarm volume level.

8. SPECIFICATIONS

Feature	Specification
Model Number	BK11
Product Dimensions	3.9 x 1.5 x 2.3 inches
Item Weight	11.68 ounces
Power Source	Battery Powered (<i>Note: Typically refers to backup battery, main power is adapted</i>)
Material	Plastic, ABS, Silicone or Soft Cloth
Sound Options	18 (5 white noises, 3 fan sounds, 10 nature sounds)
Volume Levels	30
Sleep Timer	15, 30, 60, 90, 120 minutes, or continuous
Clock Face Brightness	0-100% adjustable
Bottom Light Colors	7 options

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official BUFFBEE brand store.

BUFFBEE Brand Store: <https://www.amazon.com/stores/BUFFBEE/page/2F15B3A3-35EC-4504-B948-68616D178EE8>

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C32YF1RK>

More documents and user manuals: **<https://manuals.plus/>**