

[Manuals.plus](#) /

› [ION](#) /

› ION Block Rocker Portable Bluetooth Speaker User Manual

ION BLCKRCKR2023XUS

ION Block Rocker Portable Bluetooth Speaker User Manual

Model: BLCKRCKR2023XUS

INTRODUCTION

The ION Block Rocker is a high-power portable Bluetooth speaker designed for both indoor and outdoor use. It features a robust sound system, long-lasting battery, and water-resistant construction, making it ideal for parties, gatherings, and various activities. This manual provides essential information for setting up, operating, and maintaining your speaker.



Image: Front view of the ION Block Rocker portable speaker, showcasing its robust design and control panel.

WHAT'S IN THE BOX

- Block Rocker Portable Speaker
- IEC Power cable (4.9ft / 150cm)
- Microphone with cable (7.5ft / 230cm)
- Quick Start Guide

KEY FEATURES

- **120W High-Power Sound:** Delivers dynamic audio through an 8" woofer, 2" tweeter, and two 4" full-range drivers for wide-range sound.
- **Bluetooth 5.3 Connectivity:** Stream music wirelessly up to 100 ft from any Bluetooth-enabled device.
- **Long-Lasting Battery:** Rechargeable battery provides up to 35 hours of continuous playback.
- **IPX5 Water-Resistant:** Designed to withstand splashes and light rain, suitable for outdoor environments.
- **Portability:** Features built-in handles and wheels for easy transport.
- **Integrated FM Radio:** Enjoy your favorite radio stations with presets.
- **Microphone Input:** Includes a high-quality microphone and cable for public speaking or karaoke.
- **ION Sound Control App:** Customize audio, lighting, and radio presets via iOS/Android devices.
- **Backlit Control Buttons:** Ensures easy operation in low-light conditions.
- **BOOM Button:** Instantly boosts bass, volume, and light effects.
- **USB Charge/Playback Port:** Charge your mobile devices or play music from a USB thumb drive.
- **Wireless Stereo-Link:** Connect to another Block Rocker for stereo sound.



**120
WATTS**

4 PREMIUM SPEAKERS



EQ CONTROL



PLAY YOUR MP3



WIRELESS STEREO-LINK



FM RADIO



BLUETOOTH 5.3

Image: Overview of key features including 120W power, 4 speakers, EQ control, USB playback, wireless stereo-link, FM radio, and Bluetooth 5.3.



HIGH-POWER SOUND SYSTEM

8"
WOOFER

2x4"
DRIVERS

2"
TWEETER

FOR PREMIUM WIDE-RANGE SOUND

Image: Diagram showing the 8" woofer, two 4" drivers, and 2" tweeter for wide-range sound.

GRAB AND GO



35-HOUR BATTERY



BACK-LIT BUTTONS



MIC & CABLE



IPX5 WATER-RESISTANT



**EASY GRAB HANDLES
+ WHEELS**



BOOM BUTTON

Image: Demonstrates the speaker's portability with a 35-hour battery, backlit buttons, included mic & cable, IPX5 water-resistance, easy grab handles + wheels, and BOOM button.

IPX5 WATER-RESISTANT



Image: The speaker is shown near a pool, highlighting its IPX5 water-resistant feature.

SETUP

Initial Charging

Before first use, ensure the Block Rocker is fully charged. Connect the included IEC Power cable to the speaker's power input and then to a power outlet. The battery indicator on the display will show charging status.

Powering On/Off

Press and hold the **Power button** on the control panel to turn the speaker ON or OFF.



Image: Top view of the speaker's control panel with various buttons for power, volume, and mode selection.

OPERATION

Bluetooth Pairing

1. Ensure your Block Rocker is powered ON.
2. Activate Bluetooth on your mobile device.
3. On your device, select "ION Block Rocker" from the list of available Bluetooth devices.
4. Once paired, the Bluetooth icon on the speaker's display will illuminate steadily.

Playing Music

- **Bluetooth:** Stream audio directly from your paired device.
- **USB Playback:** Insert a USB thumb drive into the USB Charge/Playback Port. The speaker will automatically play compatible audio files (MP3 format supported).
- **AUX Input:** Connect external audio sources using a 1/8" (3.5mm) AUX cable to the AUX In port.
- **FM Radio:** Press the **Radio button** to switch to FM mode. Use the **Tune/Track buttons** to scan for stations or select presets.



CONVENIENT CONTROL ON THE GO



BASS EQ



LIGHTS



VOLUME



**OVER-THE-AIR
UPDATES**

Image: A person using the ION Sound Control app on a smartphone to manage speaker functions, including EQ, lighting, and volume.

CONNECTIVITY COVERED



Image: Close-up of the speaker's connectivity options: 1/4" Mic In, USB Charge/Playback Port, and 1/8" AUX In.

Microphone Usage

Connect the included microphone to the 1/4" Mic In port. Adjust the microphone volume using the **MIC +/- buttons** on the control panel.

Lighting Effects

Press the **Light button** to cycle through different multi-colored LED light modes. The lights can be synchronized with the music.

BOOM Button

Press the **BOOM button** to instantly enhance bass, increase overall volume, and activate dynamic light effects for a more impactful audio experience.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Battery Care:** For optimal battery life, fully charge the speaker before extended storage. Avoid completely draining the battery frequently.
- **Storage:** Store the speaker in a cool, dry place away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Problem	Solution
No power	Ensure the power cable is securely connected and the outlet is functional. Check battery charge level.
No sound	Check volume levels on both the speaker and the connected device. Ensure correct input source is selected (Bluetooth, AUX, USB, FM).
Bluetooth not connecting	Ensure Bluetooth is enabled on both devices. Move devices closer. Try unpairing and re-pairing.
Microphone not working	Ensure microphone is securely plugged in. Adjust MIC volume.

SPECIFICATIONS

- **Model Name:** iPA163A
- **Item Model Number:** BLCKRCKR2023XUS
- **Output Wattage:** 120 Watts
- **Speaker Type:** Outdoor
- **Connectivity Technology:** Bluetooth, USB
- **Bluetooth Range:** 100 Feet
- **Battery Life:** Up to 35 hours
- **Water Resistance:** IPX5
- **Dimensions (D x W x H):** 8.13" x 14.49" x 17.87"
- **Item Weight:** 20.5 Pounds
- **Included Components:** Block Rocker, IEC Power cable, Microphone with cable, Quick Start Guide

SAFETY INFORMATION

Please read all safety instructions before using the product. Do not expose the speaker to extreme temperatures, direct sunlight, or excessive moisture beyond its IPX5 rating. Do not attempt to disassemble or modify the speaker. Keep out of reach of children.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the Quick Start Guide included in your package or visit the official ION Audio website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question