

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UpBright 12V AC/DC Adapter User Manual for KEiiD KD-C01 KD-C02 Speakers

UPBRIGHT KD-C01, KD-C02

UpBright 12V AC/DC Adapter User Manual

For KEiiD KD-C01 and KD-C02 Bluetooth Computer Speakers

INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright 12V AC/DC Adapter. This adapter is designed to provide power to compatible devices, specifically KEiiD KD-C01 and KD-C02 Bluetooth Computer Speakers. Please read this manual thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS


- **Read all instructions:** Before using the adapter, read all safety and operating instructions.
- **Keep away from water:** Do not expose the adapter to rain, moisture, or extreme humidity.
- **Proper ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space that restricts airflow.
- **Avoid extreme temperatures:** Do not operate the adapter near heat sources or in excessively hot environments.
- **Use correct voltage:** Connect the adapter only to power sources within the specified input voltage range (100-240VAC).
- **Protect the cord:** Route the power cord to prevent it from being walked on or pinched.
- **Unplug when not in use:** Disconnect the adapter from the power outlet when not in use for extended periods.
- **Do not disassemble:** Do not attempt to open or repair the adapter yourself. Refer all servicing to qualified service personnel.
- **Compatibility:** Use this adapter only with devices specified as compatible, such as KEiiD KD-C01 and KD-C02 speakers. Using it with incompatible devices may cause damage.

SETUP

Follow these steps to set up your UpBright 12V AC/DC Adapter:

1. **Inspect the adapter:** Before connecting, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Identify the correct plug:** If your package includes multiple outlet adapters for international use, select the one appropriate for your region.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® LIMITED WARRANTY



This image displays various international plug adapters (AU, EU, UK) that may be included with your product, along with a warranty certificate. Choose the adapter suitable for your country's electrical outlets.

3. **Connect to device:** Insert the DC output plug of the adapter firmly into the power input port of your KEiiD KD-C01 or KD-C02 Bluetooth Computer Speaker.





These images show the UpBright 12V AC/DC adapter. The first image displays the adapter with its US plug and the DC output cable. The second image provides a side view of the adapter's power brick and coiled cable, illustrating its compact design.

4. **Connect to power outlet:** Plug the AC input plug of the adapter into a standard wall power outlet (100-240VAC, 50/60Hz).
5. **Verify power:** Once connected, your device should receive power. Refer to your device's manual for specific power indicators.

OPERATING INSTRUCTIONS

The UpBright 12V AC/DC Adapter is designed for continuous operation within its specified limits. It provides a stable 12V DC output to power your compatible devices.

- **Continuous Power:** Once connected, the adapter supplies constant power to your device.
- **Overload Protection:** The adapter features Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard both the adapter and your connected device from electrical anomalies.
- **Temperature:** The adapter may become warm during operation. This is normal. If it becomes excessively hot, disconnect it immediately and contact support.

MAINTENANCE

Proper care ensures the longevity and reliable performance of your adapter.

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Inspection:** Periodically check the power cord and connectors for any signs of wear, cuts, or damage. Replace the adapter if any damage is found.

TROUBLESHOOTING

If you encounter issues with your UpBright 12V AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	• Adapter not properly plugged in. • Power outlet is not active. • Adapter or cable is damaged. • Device is incompatible or faulty.	• Ensure both ends of the adapter are securely connected. • Test the power outlet with another device. • Inspect the adapter and cable for damage. If damaged, discontinue use. • Verify your device is compatible with a 12V DC power supply.
Adapter feels excessively hot.	• Poor ventilation. • Overload or short circuit.	• Ensure the adapter is in a well-ventilated area. • Disconnect the adapter immediately. Check the connected device for faults.
Intermittent power to device.	• Loose connection. • Damaged cable.	• Check all connections for tightness. • Inspect the cable for any breaks or fraying.

If these solutions do not resolve the issue, please contact UpBright customer support.

SPECIFICATIONS

Brand	UPBRIGHT
Model Compatibility	KEiID KD-C01, KD-C02, KDC01, KDC02 Bluetooth Computer Speakers
Input Voltage	100-240VAC, 50/60Hz

Output Voltage	12 Volts (DC)
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	3 x 3 x 1 inches
Item Weight	4 ounces
Power Source	Corded Electric
Main Power Connector Type	2 Pin

WARRANTY AND SUPPORT

Warranty Information

Your UpBright 12V AC/DC Adapter comes with a**30-day refund policy** and a **24-month exchange warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product is in good working condition. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact UpBright customer support. Refer to the retailer's website or your purchase documentation for contact details. You can also visit the [UPBRIGHT Store](#) for more information.

© 2023 UpBright. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C33CT6KB>

More documents and user manuals: <https://manuals.plus/>