

[Manuals.plus](#) /

› [Ancable](#) /

› TSA007 TSA002 Multifunction Keys User Manual

Ancable TSA002+007

Ancable TSA007 & TSA002 Multifunction Keys User Manual

Model: TSA002+007

INTRODUCTION

This user manual provides essential information for the proper use and care of your Ancable TSA007 and TSA002 multifunction keys. These keys are designed to provide emergency access to luggage and other items secured with TSA-compatible locks, particularly when the combination is forgotten or inaccessible. Please read this manual thoroughly to understand the functionality and limitations of these keys.



Image: The Ancable TSA002 and TSA007 multifunction keys, accompanied by a keyring for convenient attachment.

PRODUCT OVERVIEW AND FEATURES

The Ancable TSA007 and TSA002 keys are crafted for durability and ease of use, offering a reliable solution for accessing your TSA-compatible luggage locks.

- **Convenience:** These keys provide an emergency bypass for forgotten lock combinations, preventing the need for destructive entry methods.
- **Premium Material:** Constructed from high-quality steel and die-cast material, the keys are thick, durable, and resistant to bending.
- **User-Friendly Design:** Featuring a large key handle for improved grip and a keychain hole for easy portability, reducing the risk of loss.
- **Wide Compatibility:** Designed to open most locks marked with TSA 002/007. However, it is important to note that not all locks bearing these markings may be compatible.

**Hergestellt aus hochwertigem
Stahlmaterial**



Knackiger Druckguss-Schriftzug



Großer Schlüsselgriff



Tragbares Schlüsselloch

Image: Detail of the TSA 007 key, showcasing its robust steel construction and clear numbering.

**Clé Ancable TSA Libérez vos
inquiétudes facilement**



Image: An illustrative diagram highlighting key features such as clear numbering, a convenient keyhole for attachment, and the high-quality stainless steel composition. It also advises users to match the key number with the number on their TSA lock.

OPERATING INSTRUCTIONS

These keys are designed for straightforward operation. Follow these steps to use your Ancable TSA keys:

1. **Identify Your Lock:** Locate the TSA marking on your luggage lock. It will typically display a number, such as "TSA002" or "TSA007".
2. **Select the Correct Key:** Choose the Ancable key that corresponds to the number on your lock (e.g., use the TSA002 key for a TSA002 lock).
3. **Insert and Turn:** Gently insert the key into the keyhole of the TSA lock. Turn the key clockwise or counter-clockwise until the lock mechanism disengages.
4. **Open the Lock:** Once unlocked, you can open your luggage.
5. **Remove the Key:** After opening, remove the key. The lock will re-engage when closed, and the combination will remain unchanged.

Important Note:

These keys are for bypassing the combination to open the lock. They cannot be used to find, reset, or change the existing combination of your lock. Always keep your keys in a secure location if you rely on them for access.



Image: Demonstrations of the TSA keys in use, unlocking different types of luggage locks.

MAINTENANCE

The Ancable TSA keys require minimal maintenance due to their durable construction. To ensure their longevity and proper function:

- **Keep Clean:** Wipe the keys with a dry, soft cloth to remove any dust or debris. Avoid using abrasive cleaners or solvents.
- **Store Properly:** Store the keys in a dry place, away from extreme temperatures and corrosive materials. Attaching them to a keychain (as included) helps prevent misplacement.
- **Avoid Force:** Do not force the key into a lock or apply excessive pressure when turning. If the key does not turn easily, ensure you are using the correct key for the lock and that the lock mechanism is not obstructed.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Key does not fit into the lock.	Incorrect key for the lock; debris in keyhole.	Ensure the key number (002 or 007) matches the lock's marking. Check for and remove any obstructions in the keyhole.
Key turns but lock does not open.	Lock mechanism jammed or damaged; key not fully inserted.	Ensure the key is fully inserted. Gently jiggle the key while turning. If the lock is damaged, professional repair or replacement may be necessary.
Key feels loose or wobbly in the lock.	Normal play for TSA keys; worn lock mechanism.	A slight wobble is normal. If the lock still functions, there is no issue. If the lock fails to open, refer to the "Key turns but lock does not open" solution.

SPECIFICATIONS

Attribute	Detail
Manufacturer	Ancable Electronic
Product Dimensions (L x W x H)	3.4 x 2.1 x 0.5 cm
Weight	10 grams
Model Reference	TSA (TSA002+007 variant)
Color	Silver (TSA 002+007)
Style	Luggage Keys
Finish	Polished
Material	Alloy Steel
Shape	Rectangular
Number of Pieces	2
Special Features	Password Bypass Unlock
Included Components	Keys, Keychain
Batteries Required	No
Recommended Use	Unlocking suitcases or other items locked with TSA-compatible padlocks

Produkt Größe



Image: Detailed product dimensions for both TSA 002 and TSA 007 keys, including the keyring.

WARRANTY AND SUPPORT

All Ancable products, including these TSA multifunction keys, are backed by a **12-month warranty**. This warranty covers manufacturing defects and ensures that you receive a high-quality product that meets your needs. If you encounter any issues, you are protected by our 100% no-questions-asked guarantee for either a replacement or a refund.

For support or warranty claims, please contact Ancable customer service through the retailer where you purchased the product or visit the official Ancable website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C33KP1Y5>

More documents and user manuals: <https://manuals.plus/>