

[Manuals.plus](#) /

› [Foxtop](#) /

› Foxtop 24 Hour Wall Clock Instruction Manual

Foxtop Foxtop 24 Hour Wall Clock (Black)

Foxtop 24 Hour Wall Clock Instruction Manual

Model: Foxtop 24 Hour Wall Clock (Black)

INTRODUCTION

Thank you for choosing the Foxtop 24 Hour Wall Clock. This analog wall clock features a unique 24-hour dial, making it ideal for environments where military time or a full-day cycle is preferred, such as classrooms, offices, or homes. Its quartz movement ensures accurate timekeeping, and the classic design with large, easy-to-read numbers makes it a functional and stylish addition to any room.

This manual provides essential information for the proper setup, operation, and maintenance of your new clock. Please read it thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Keep the clock away from direct sunlight and extreme temperatures to prevent damage to the movement and casing.
- Avoid exposing the clock to excessive moisture or water. This product is designed for indoor use only.
- Do not attempt to disassemble or repair the clock yourself. Refer to the troubleshooting section or contact customer support for assistance.
- Use only the specified battery type (1 AA zinc carbon battery). Alkaline or rechargeable batteries may affect the clock's lifespan and accuracy.
- Keep batteries out of reach of children. If swallowed, seek immediate medical attention.
- Dispose of used batteries responsibly according to local regulations.
- Ensure the clock is securely mounted when hanging to prevent it from falling and causing injury or damage.

PACKAGE CONTENTS

Please check the package to ensure all items are present and in good condition:

- 1 x Foxtop 24 Hour Wall Clock (Black)
- 1 x Wall Hook (for hanging)
- 1 x Instruction Manual (this document)

Note: 1 AA zinc carbon battery is required and not included in the package.

SETUP

1. **Insert Battery:** Locate the battery compartment on the back of the clock. Insert one (1) AA zinc carbon battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.



Image: Rear view of the clock, highlighting the battery slot and the quartz movement mechanism.

2. **Set Time:** Turn the time adjustment knob located on the back of the clock's movement mechanism. Rotate the knob clockwise until the clock displays the correct 24-hour time. The hour hand on this clock completes one full rotation (360 degrees) in 24 hours.




Image: Detailed view of the clock hands, illustrating their position on the 24-hour dial.

3. **Mounting:** The clock comes with a wide slot on the back for easy hanging. Use the included wall hook or a suitable nail/screw to securely mount the clock on a wall. Ensure the mounting surface is stable and can support the clock's weight.



Image: The clock displayed on a wall in a living room, demonstrating its appearance when mounted.

OPERATING INSTRUCTIONS

The Foxtop 24 Hour Wall Clock operates continuously once the battery is installed and the time is set. It features a unique 24-hour dial where the hour hand completes one full rotation in 24 hours, unlike standard 12-hour clocks where it rotates twice a day.

- **Reading the Time:** The large black numbers from 00 to 23 represent the hours in a 24-hour format. The smaller dashes and numbers (00, 05, 10, etc.) indicate minutes.
- **Movement:** The clock utilizes a quartz movement with a ticking second hand. The ticking sound is designed to be very subtle and hardly audible in a typical environment.




Image: Front view of the clock, showcasing its 24-hour dial and clear numbering.

Product Overview Video

Your browser does not support the video tag.

Video: A brief overview of the Foxtop 24 Hour Wall Clock, demonstrating its features and design.

MAINTENANCE

- **Cleaning:** To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or the clock mechanism.
- **Battery Replacement:** Replace the AA battery annually or when the clock starts losing time. Always use a fresh AA zinc carbon battery.
- **Storage:** If storing the clock for an extended period, remove the battery to prevent leakage and potential damage to the movement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working / Hands not moving	Battery is dead or incorrectly inserted.	Check battery polarity (+/-). Replace with a new AA zinc carbon battery.
Clock losing or gaining time	Low battery power; incorrect battery type; clock mechanism issue.	Replace battery with a fresh AA zinc carbon battery. Ensure no alkaline or rechargeable batteries are used. If problem persists, contact support.
Ticking sound is too loud	This clock uses a jump second movement which produces a subtle ticking sound.	The ticking sound is inherent to the design but is generally very low decibel. Ensure the clock is not placed directly next to an ear or in an extremely quiet room if this is a concern.
Hands are loose or stuck	Physical impact or manufacturing defect.	Do not attempt to fix the hands yourself. Contact customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Foxtop
Model	24 Hour Wall Clock (Black)
Color	Black frame, White dial
Display Type	Analog, 24-hour format
Movement Type	Quartz, Jump Second
Power Source	1 x AA Zinc Carbon Battery (not included)
Product Dimensions	12 inches (Diameter) x 1.54 pounds (Weight)
Material	Plastic frame, Glass cover
Indoor/Outdoor Usage	Indoor only
Mounting Type	Wall Mount
Country of Origin	China




Image: Diagram illustrating the 12-inch dimensions of the clock.

WARRANTY AND SUPPORT

Foxtop is committed to providing high-quality products. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact Foxtop customer service through the retailer's platform where you purchased the product or visit the official Foxtop brand store:

[Visit the Foxtop Store on Amazon](#)

We are dedicated to ensuring your satisfaction and are here to help with any questions or concerns you may have.

