

[Manuals.plus](#) /

› [Adoolla](#) /

› Adoolla 8000 BTU Portable Air Conditioner User Manual

Adoolla 8000 Btus PAC

Adoolla 8000 BTU Portable Air Conditioner User Manual

Model: 8000 Btus PAC

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your Adoolla 8000 BTU Portable Air Conditioner. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image: The Adoolla 8000 BTU Portable Air Conditioner unit, white with black front grille, shown with its remote control.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this appliance.
- Do not operate any appliance with a damaged cord or plug.

- Do not use the appliance near water or in wet conditions.
- Ensure the unit is placed on a stable, level surface.
- Unplug the unit from the power outlet when not in use or before cleaning.
- Keep the air intake and exhaust vents clear of obstructions.
- This appliance is for indoor use only.

PACKAGE CONTENTS

Verify that all components are present in the package:



Image: A visual representation of the Adoolla portable air conditioner's included accessories, such as the remote control, exhaust hose, window kit components, drain pipe, and user manual.

- 1x Portable Air Conditioner Unit
- 1x Remote Control
- 1x Exhaust Hose
- 1x Hose Connector
- 1x Window Kit Adapter
- 1x Window Kit (Slide Bar)
- 1x Drain Pipe
- 1x Fixing Screws
- 1x User Manual

SETUP AND INSTALLATION

The Adoolla portable air conditioner is designed for quick setup. Follow these steps for proper installation:

1. **Prepare the Exhaust Hose:** Rotate the two ends of the exhaust pipe to connect them.
2. **Connect to Unit:** Attach one end of the exhaust hose to the air conditioning vent on the unit.
3. **Connect to Window Kit:** Attach the other end of the exhaust hose to the window kit adapter.
4. **Install Window Kit:**
 - Extend the adjustable window kit (slide bar) to fit your window opening.
 - Secure the window kit in place using the provided fixing screws.
 - Ensure a tight seal to prevent air leakage.
5. **Insert Exhaust Hose into Window Kit:** Insert the exhaust hose adapter into the opening of the installed window kit.

Cool Your Room Quick & Comfort



Image: A six-step visual guide demonstrating how to connect the exhaust hose and install the window kit for the portable AC unit.

The extendable exhaust hose can be adjusted from 11 inches to 59 inches to accommodate various window sizes and setups.

OPERATING INSTRUCTIONS

Control Panel and Remote Control

Your Adoolla portable air conditioner can be operated using the LED touch panel on the unit or the included remote control.

LED Touch Panel with Remote Control




Image: A detailed view of the unit's LED touch panel and the remote control, highlighting various function buttons.

Operating Modes

The unit features three primary operating modes:

- **Cool Mode:** Provides effective cooling for rooms up to 350 sq. ft. Temperature range: 61°F-88°F.
- **Dry Mode (Dehumidifier):** Removes up to 45 pints of moisture per day, reducing humidity.
- **Fan Mode:** Circulates air with two fan speeds (Low, High) and an airflow of 300m³/h.

3-in-1 Modes & 2 Wind Speed



Image: Visual representation of the three operating modes: Cool, Dry (dehumidify), and Fan, showing their respective functions.

Additional Features

- **Automatic Horizontal Swing:** The unit can swing at 80° to distribute cool air evenly.
- **Manual Vertical Wind:** Adjust the vertical louvers manually to direct airflow.
- **24-Hour Timer:** Set the unit to turn on or off automatically.
- **Sleep Mode:** Operates at a quieter setting for comfortable overnight use.

4 Directions Cool Wind Blowing

Direct where you want the airflow to go by using the Directional Louvers



Image: Illustration of the unit's airflow direction capabilities, including automatic horizontal swing and manual vertical adjustment.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air conditioner.

Cleaning the Air Filter

The air filter should be cleaned regularly (e.g., every two weeks) to maintain efficiency.

1. Unplug the unit from the power outlet.
2. Locate and remove the air filter from the back or side of the unit.
3. Wash the filter with warm, soapy water. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it into the unit.



Image: A close-up of a hand demonstrating the removal of the washable filter from the air conditioner for cleaning.

Draining Condensed Water

The unit features self-evaporation technology, but manual drainage may be required, especially in high humidity or when using Dry mode. The unit has a drainage hole at the bottom.

New Upgraded Automatic Dehumidify Technology

After

Before

45

pints

Drainage Hole

*Self-evaporation technology, automatic atomizing of condensed water.

Image: A visual explanation of the unit's dehumidifying capability, showing the collection of 45 pints of water and the location of the drainage hole.

1. Turn off the unit and unplug it.
2. Place a shallow pan or tray under the drainage hole at the bottom of the unit.
3. Remove the drain plug to allow water to flow out.
4. Once drained, replace the drain plug securely.

TROUBLESHOOTING GUIDE

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; power cord not plugged in; circuit breaker tripped.	Ensure the unit is plugged into a working outlet. Check the circuit breaker.

Problem	Possible Cause	Solution
Unit does not cool effectively.	Air filter is dirty; exhaust hose not properly installed; room size too large; windows/doors open.	Clean the air filter. Ensure exhaust hose is securely connected and sealed. Close all windows and doors. Verify room size is within 350 sq. ft.
Water leakage from the unit.	Drain plug is loose or missing; internal water tank is full (in high humidity).	Ensure the drain plug is securely in place. Manually drain the unit if the internal tank is full.
Unit is noisy.	Unit not on a level surface; fan speed is high; normal operating noise.	Place the unit on a flat, stable surface. Reduce fan speed if possible. Some operating noise is normal (52 dB).

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Adoolla
Model Number	8000 Btus PAC
Cooling Power	8000 BTU
Floor Area Coverage	Up to 350 Square Feet
Product Dimensions (D x W x H)	11.7" x 11.3" x 27.4"
Item Weight	48 pounds
Voltage	115 Volts
Noise Level	52 dB
Dehumidification Capacity	45 Pints/day
Special Features	3-in-1 Multi-function Mode (Cool, Dry, Fan), Fast Cooling, Portable & Compact Design, Self-evaporation & Manual Drainage
Included Components	Window Kit, Hose Connector, Window Kit Adapter, Exhaust Hose, Drain Pipe, Remote Control, Fixing screws, User Manual

WARRANTY INFORMATION

This Adoolla portable air conditioner comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, please refer to the warranty card included in your package or contact Adoolla customer support.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue that is not covered in the troubleshooting guide, please contact Adoolla customer support.

Please have your model number (8000 Btus PAC) and purchase information ready when contacting support.

Contact information can typically be found on the product packaging, the official Adoolla website, or your purchase receipt.

