

GENGQIANSI A5202304016B63

GENGQIANSI Replacement Remote Control User Manual

For Fujitsu Wall AC Units (Models ASU9RLQ to ASU36RLXB)

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your GENGQIANSI replacement remote control for Fujitsu Wall AC Air Conditioners. This remote is designed to be compatible with various Fujitsu models, including ASU9RLQ, ASU12RLQ, ASU15RLQ, ASU18RL, ASU18RLQ, ASU24RLQ, ASU24RLB, ASU30RLXB, ASU36RLXB, ASU18RLXS, and ASU24RLXS. Please read this manual thoroughly to ensure proper use and longevity of your remote control.

SETUP

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the cover back into place until it clicks securely.



Image: Back view of the remote control, illustrating the battery compartment.

2. Initial Use

This replacement remote control is pre-programmed and typically requires no additional setup or pairing. Once batteries are installed, it should be ready for immediate use with compatible Fujitsu AC units. Point the remote directly at the indoor unit of your air conditioner.

OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and display on your remote control to effectively operate your Fujitsu AC unit.





Image: Front view of the remote control, showing the LCD display and various control buttons.

Basic Functions

- **START/STOP (Orange Button):** Powers the AC unit on or off.
- **MASTER CONTROL:** Cycles through operating modes (e.g., Auto, Cool, Dry, Fan, Heat).
- **FAN CONTROL:** Adjusts the fan speed (e.g., Auto, Low, Medium, High).
- **SET TEMP. (Up/Down Arrows):** Increases or decreases the desired temperature setting.
- **SWING (Left/Right Arrows):** Controls the louver swing direction for air distribution.

Advanced Functions

- **AIR CLEAN:** Activates the air purification function (if available on your AC model).
- **COIL DRY:** Initiates a coil drying cycle to prevent mold and odors.
- **SLEEP:** Activates sleep mode, which adjusts temperature and fan speed for comfortable sleep.
- **TIMER MODE:** Sets or cancels the on/off timer for the AC unit. Use the '+' and '-' buttons to adjust timer settings.
- **CLOCK ADJUST:** Sets the current time on the remote's display.
- **TEST RUN:** Used for service and diagnostic purposes. Avoid using during normal operation.
- **RESET:** Resets the remote control to factory default settings.

Temperature Unit Conversion (°C / °F)

This remote supports both Fahrenheit and Celsius temperature displays. To switch between units, locate the small button or combination of buttons (often involving the 'SET' or 'TEMP' buttons) that allows for this conversion. Refer to the image below for visual guidance.




Image: Comparison of the remote's display showing temperature in Fahrenheit (76°F) and Celsius (16°C), highlighting the conversion capability.

Special Heat Functions (10°C HEAT, 50°F HEAT, MINI.HEAT, ECONOMY)

Certain advanced heating functions, such as "10°C HEAT", "50°F HEAT", "MINI.HEAT", or "ECONOMY", are only available if your original Fujitsu remote control also featured these buttons. To activate these functions, press and hold the designated button (often the "START/STOP" or "MASTER CONTROL" button in conjunction with other buttons) for approximately 4 seconds. Refer to the image below for visual cues.

**“10°C.HEAT”
“50°F.HEAT” “MINI.HEAT” or “ECONOMY”
functions are available only when your
old remote control have these buttons.**

**10°C.HEAT
50°F.HEAT
MINI.HEAT
ECONOMY**

**Press and hold this
button for 4 seconds**




Image: Remote control illustrating the activation of special heat functions like "10°C HEAT" by pressing and holding a button for 4 seconds.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are correctly installed with proper polarity.
 - Replace old batteries with new ones.
 - Make sure there are no obstructions between the remote and the AC unit's receiver.
 - Ensure you are within the effective operating range (up to 10 meters).
- **Display is dim or blank:**
 - Batteries may be low. Replace them.
- **AC unit not responding to specific functions:**
 - Some advanced functions (e.g., "AIR CLEAN", "COIL DRY", "10°C HEAT") are dependent on the specific features of your Fujitsu AC model. If your original remote did not have these functions, or your AC unit does not support them, the replacement remote will not be able to activate them.

SPECIFICATIONS

Brand	GENGQIANSI
Model Number	A5202304016B63
Compatible Devices	Fujitsu Wall AC Air Conditioners (ASU9RLQ, ASU12RLQ, ASU15RLQ, ASU18RL, ASU18RLQ, ASU24RLQ, ASU24RLB, ASU30RLXB, ASU36RLXB, ASU18RLXS, ASU24RLXS)
Connectivity Technology	Infrared
Maximum Range	10 meters
Battery Type	AAA Alkaline (x2)
Color	Black
Special Feature	Ergonomic design, Fahrenheit and Celsius display

WARRANTY

This GENGQIANSI replacement remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or battery leakage. Please retain your proof of purchase for warranty claims.

SUPPORT

For any questions, concerns, or technical assistance regarding your GENGQIANSI replacement remote control, please refer to the seller's contact information provided at the point of purchase. Ensure you have your product model number (A5202304016B63) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question