

## SOONBOX S26

# WIRELESS BLUETOOTH SPEAKER SOONBOX S26 INCH WIRELESS SPEAKER User Manual

Model: SOONBOX S26 | Brand: Generic

## 1. INTRODUCTION

---

Thank you for purchasing the SOONBOX S26 Wireless Bluetooth Speaker. This manual provides important information on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and keep it for future reference.

## 2. SAFETY INFORMATION

---

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and other liquids.
- Use only the specified charging cable and power adapter.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

## 3. PACKAGE CONTENTS

---

Please check the package for the following items:

- SOONBOX S26 Wireless Bluetooth Speaker
- Charging Cable (USB)
- User Manual (this document)
- (Optional: Microphone, if included with your specific model)



Image: The SOONBOX S26 Wireless Bluetooth Speaker shown next to its retail packaging. The speaker features a black casing with colorful LED lights around the main speaker cone and a smaller light at the top. The box displays the "SOONBOX" logo and "WIRELESS SPEAKER" text, along with an image of the speaker and a microphone.

## 4. PRODUCT OVERVIEW AND FEATURES

---

The SOONBOX S26 is a versatile wireless Bluetooth speaker designed for various audio needs. Key features include:

- **Wireless Connectivity:** Bluetooth technology for seamless audio streaming from compatible devices.
- **Tabletop Mounting:** Designed for stable placement on flat surfaces.
- **Portable Design:** Battery-powered for on-the-go use.
- **Wide Compatibility:** Connects with laptops, smartphones, and tablets.
- **Integrated Lighting:** Features dynamic LED lights for an enhanced audio-visual experience.

## 5. SETUP

---

### 5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged.

## 5.2 Powering On/Off

To power on the speaker, press and hold the Power button for a few seconds until you hear an audible prompt or see the indicator lights activate. To power off, press and hold the Power button again.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (usually indicated by a flashing blue LED).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "SOONBOX S26" from the list of found devices.
4. Once paired, the speaker will provide an audible confirmation, and the Bluetooth indicator light will become solid.
5. You can now play audio from your device through the speaker.

### 6.2 Basic Controls

- **Volume Up/Down:** Use the dedicated volume buttons on the speaker or control volume from your connected device.
- **Play/Pause:** Press the Play/Pause button to control audio playback.
- **Next/Previous Track:** Use the skip buttons to navigate between tracks.
- **Mode Button:** If available, press to switch between different input modes (e.g., Bluetooth, AUX, USB, TF Card).

## 7. MAINTENANCE

---

Proper maintenance ensures the longevity of your SOONBOX S26 speaker:

- **Cleaning:** Wipe the speaker's surface with a soft, dry, lint-free cloth. Do not use liquid cleaners or sprays.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far apart.	Ensure speaker is in pairing mode. Turn device Bluetooth off/on. Move devices closer.
No sound.	Volume too low; incorrect input mode; device not playing.	Increase volume on speaker and device. Check input mode. Ensure device is playing audio.
Sound distortion.	Volume too high; weak Bluetooth signal.	Lower volume. Move speaker closer to the device.

## 9. SPECIFICATIONS

---

Feature	Detail
Model Name	SOONBOX S26
Brand	Generic
Connectivity Technology	Bluetooth
Color	Blue
Mounting Type	Tabletop
Power Source	Battery Powered
Recommended Uses	For computers, for music players, for smartphones or tablets
Package Dimensions	50.2 x 15.2 x 10.2 cm
Item Weight	2.1 kg
Manufacturer	China

## 10. WARRANTY AND SUPPORT

---

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer.

For technical support, troubleshooting assistance, or inquiries about spare parts, please contact the customer service department of your retailer or the brand's official support channels. Please have your model number (SOONBOX S26) and purchase details ready when contacting support.