Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

cudinham AM0170001

Cudinham Fruit and Vegetable Purifier Cleaner Washing Machine

Model: **AM0170001**

Brand: **Cudinham**

Introduction

The Cudinham Fruit and Vegetable Purifier Cleaner utilizes high-energy ion purification technology to effectively clean various food items. This device is designed to degrade harmful substances and residues, providing a new approach to food safety and preparation.



Image: The Cudinham Fruit and Vegetable Purifier demonstrating its electrolytic ion purification process in water.

Key features include efficient purification, a wide range of applications for various foods, ease of use and cleaning, and a portable, durable design with an IPX7 waterproof rating.



Image: A visual comparison showing food items before and after purification with the device.

Safety Information

- The device has an IPX7 waterproof rating, allowing for wireless use in water.
- Avoid direct contact with strong electricity for safety.
- Ensure the device body and charging dock are completely dry before charging to prevent short circuits and charging failures.
- Do not charge the purifier when it is wet.
- Do not use the fruit and vegetable cleaner if there is no water in the container or if the water level is insufficient.
- The charging bottom of the machine is not waterproof; do not immerse it in water.
- It is recommended not to exceed 3 liters of water at a time and the water temperature should not exceed 40°C (104°F).
- Make sure the water completely covers the fruit and vegetable purifier during operation.




Image: Important safety tips and usage precautions, particularly concerning charging the device.

Setup

Before first use, ensure the device is fully charged. Connect the charging base to a standard USB charger using the provided cable. Place the purifier onto the charging base. The button light will indicate charging status.



Image: The purifier placed on its charging base, ready for charging.

Once charged, the device is ready for use. Ensure the device is completely dry before placing it on the charging dock.

Operating Instructions

1. Place the fruit and vegetable washing machine into a container filled with water, ensuring the device is fully submerged.
2. Add the food items you wish to purify (fruits, vegetables, meat, seafood, grains, etc.) to the water.
3. Press the power switch on the device. The green light will turn on and flash, indicating the purifier has started working.
4. Allow the device to operate for approximately 10 minutes. For best results, gently stir the food occasionally during this period.
5. After 10 minutes, the purification cycle is complete. Remove the food and enjoy.



Image: Step-by-step guide on how to use the Cudinham Fruit and Vegetable Purifier.

Applicable Food Types:

The purifier is suitable for a wide range of food items, including:

- Fruits and Vegetables
- Meat and Aquatic Products
- Rice and Grains
- Tableware, Cookware, and Milk Bottles

Your browser does not support the video tag.

Video: An official Cudinham video demonstrating the fruit and vegetable purifier in action, cleaning various food items.

Maintenance

The Cudinham Fruit and Vegetable Purifier is designed for easy maintenance. It is detachable and washable.

- After each use, rinse the device thoroughly with clean water.
- The integrated electrolytic plate module design allows for 360° cleaning. The removable outer casing can be detached for deeper cleaning.
- Always ensure the device body and charging dock are completely dry before charging. Charging a wet device may cause a short circuit and charging failures.
- If the purifier is not completely dry before being placed on the charging dock, it may shut down or fail to start after use. To resolve this, air dry the purifier in a well-ventilated area for two days, after which it should function normally.



Image: Demonstrating the cleaning process for the purifier's components.

Troubleshooting

Charging Issues:

- **Device won't charge, indicator doesn't change, or device won't turn on after charging:**
  - Use a standard charger. This device does not support fast-charging adapters.
  - Ensure the device body and charging dock are completely dry before charging. Wet charging can cause a short circuit.
  - If the purifier was not wiped dry before charging, it might shut down or fail to start. Air dry the purifier in a well-ventilated area for two days; it should then function normally.

General Usage Notes:

- For fruits and vegetables with smooth skins, it is normal if no visible changes are apparent after washing; harmful substances have still been broken down.
- For leafy greens, grapes, nectarines, waxed fruits, and ingredients with higher levels of harmful substances, the water may appear cloudy or foamy. This indicates the electrolyzed water is generating hydroxyl radicals and microbubbles, which oxidize and remove harmful substances, fruit wax, and impurities. It also reacts with natural ingredients like saponins and proteins to form foam.

Specifications

Feature	Detail
Brand	cudinham
Model Number	AM0170001
Color	Blue
Handle Material	Plastic

Specific Uses	Fruit and Vegetable Cleaning
Product Dimensions (L x W x H)	3.4" x 3.4" x 6"
Included Components	Charging Base, Charging Cable
Waterproof Rating	IPX7
Other Special Features	Cordless use, Portable, Detachable, Washable, Easy to Clean, OH-ion Purification Technology



Image: Product dimensions and key features overview.

Support

For any questions or support regarding your Cudinham Fruit and Vegetable Purifier, please contact customer service through Amazon.

How to Contact Us on Amazon:

1. Scroll to the bottom of the Amazon page and click "Customer Service" / "Help".
2. Click "Need More Help?".
3. Select "Contact Us".
4. Click "Get product support" or "Problem with order" next to your order, or click the "Contact seller" button.




Image: Visual guide for contacting support via Amazon.

© 2026 Cudinham. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C36R5QSH

More documents and user manuals: **https://manuals.plus/**