

Nils Dining Armrest Chair Velvet Replacement Cover B0C376Y252

Generic Nils Dining Armrest Chair Velvet Replacement Cover Instruction Manual

Model: Nils Dining Armrest Chair Velvet Replacement Cover (B0C376Y252)

INTRODUCTION

This manual provides detailed instructions for the installation, care, and maintenance of your Generic Nils Dining Armrest Chair Velvet Replacement Cover. Designed to fit the IKEA Nils chair, this velvet cover offers a comfortable and protective layer for your furniture, helping to guard against daily wear, spills, and pet hair.

The cover is crafted from high-quality velvet fabric, providing an elegant appearance and a soft touch. Please read this manual thoroughly before proceeding with installation or maintenance.



Image: Close-up view of the luxurious black velvet fabric, highlighting its soft texture and sheen.

SETUP AND INSTALLATION

Before installing the replacement cover, ensure your chair is clean and free of any debris. It is crucial to verify the dimensions of your IKEA Nils chair against the cover's specifications to ensure a proper fit.

1. Measure Your Chair

Refer to the diagram below to measure your chair's dimensions. The cover is designed for chairs with approximate dimensions:

- **Height:** 31.49 inches (80 cm)
- **Width:** 23.62 inches (60 cm)
- **Depth:** 22.44 inches (57 cm)

Note: Please measure the chair size before purchasing!




Image: A line drawing illustrating the key dimensions of the Nils dining armrest chair, including height, width, and depth, to assist with accurate measurement before purchasing the cover.

2. Install the Cover

1. Carefully remove any existing cover from your IKEA Nils chair.
2. Begin by aligning the top of the new velvet replacement cover with the backrest of the chair.
3. Gently pull the cover down over the backrest and seat, ensuring the armrest sections are properly aligned.
4. Smooth out any wrinkles and adjust the cover until it fits snugly and evenly over the entire chair. The elastic closure will help secure the cover in place.



Image: A black velvet chair cover fully installed on a dining armrest chair, showcasing its tailored fit and appearance within a decorative room.

OPERATING INSTRUCTIONS

Once installed, the velvet replacement cover is ready for use. Ensure the cover is properly smoothed and adjusted to prevent shifting during use. The cover is designed to protect your chair from spills, stains, and general wear. In case of minor spills, blot immediately with a clean, dry cloth.

CARE AND MAINTENANCE

Proper care will extend the life and maintain the appearance of your velvet chair cover. Follow these guidelines for cleaning:

Machine Wash: Wash at or below 40°C (110°F) with similar colors. Use a mild detergent.

Do Not Wring: Avoid twisting or wringing the fabric to prevent damage.

Do Not Bleach: Bleaching agents can damage the fabric color and texture.

Drip Dry: Hang to drip dry in the shade.

Do Not Dryclean: Dry cleaning is not recommended.

Ironing: Iron at a maximum temperature of 110°C (230°F) using low steam.



How to clean polyester covers?

 **Machine wash warm (at or below 40°C/110°F)**

 **Do not wring**

 **Do not bleach**

 **Drip dry in the shade**

 **Do not dryclean**

 **Iron at max. temp. 110°C/230°F**

Image: A visual guide detailing the recommended cleaning instructions for polyester covers, including machine wash temperature, drying methods, and ironing limits.

TROUBLESHOOTING

Cover Does Not Fit Properly

If the cover does not fit your chair correctly, please re-verify your chair's dimensions against the specifications provided in the 'Setup and Installation' section. This cover is specifically designed for the IKEA Nils dining armrest chair. If your chair is a different model or has significantly different dimensions, the cover may not fit as intended.

Wrinkles After Washing

Minor wrinkles are normal after washing. Follow the ironing instructions provided in the 'Care and Maintenance' section to smooth out the fabric. Ensure ironing is done at a low temperature (below 110°C/230°F).

PRODUCT SPECIFICATIONS

Feature	Detail
Product Name	Nils Dining Armrest Chair Velvet Replacement Cover
Model Number (ASIN)	B0C376Y252
Brand	Generic
Color	Black
Material	Velvet (100% Polyester)
Product Dimensions (D x W x H)	22.44" x 23.62" x 31.49" (57cm x 60cm x 80cm)
Recommended Use	Chair
Special Feature	Durable
Closure Type	Elastic
Manufacturer	Qiaoben
UPC	786443944896

WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. For inquiries regarding warranty coverage or returns, please refer to the retailer's return policy or contact the seller directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or encounter issues not covered in this manual, please contact the seller, GeorgeBen, through the platform where the product was purchased. Please provide your order number and a detailed description of your inquiry for prompt assistance.

Seller: [GeorgeBen \(A2RFHN32MQFUP1\)](#)