

[Manuals.plus](#) /

› [ZACME](#) /

› ZACME 7.4QT Household Stand Mixer Instruction Manual

ZACME 7.4QT Stand Mixer

ZACME 7.4QT Household Stand Mixer Instruction Manual

Model: 7.4QT Stand Mixer

Brand: ZACME

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your ZACME 7.4QT Household Stand Mixer. Please read all instructions carefully before first use and retain for future reference.

The ZACME 7.4QT Stand Mixer is designed for high capacity and high efficiency, featuring an 800W motor and 11 levels of speed adjustment. Its 7.4-quart stainless steel bowl can handle up to 3 kg (6.6 lbs) of dough, making it suitable for large family needs. Key features include an LED display with a countdown timer, a tilt-head design for easy access, and low noise operation (48-68 dBa).

SETUP

Before initial use, ensure all packaging materials are removed. Place the mixer on a clean, dry, and stable surface.

Attaching the Bowl and Accessories

1. Ensure the mixer is unplugged and the speed control is set to 'OFF'.
2. Lift the tilt-head by pushing the release lever located on the side of the mixer.
3. Place the stainless steel mixing bowl onto the base, aligning the tabs on the bowl with the slots on the base. Twist clockwise until it locks securely.
4. Select the desired attachment (dough hook, whisk, or flat beater). Insert the attachment shaft into the accessory port and twist to secure.
5. Lower the tilt-head until it locks into place.



Image: ZACME 7.4QT Stand Mixer with its primary attachments (dough hook, whisk, beater) and stainless steel bowl.

Initial Cleaning

Before first use, wash the mixing bowl, dough hook, whisk, flat beater, and splash guard in warm, soapy water. Rinse thoroughly and dry. The bowl and attachments are dishwasher safe. Wipe the main unit with a damp cloth.

Unboxing and Overview Video

Your browser does not support the video tag.

Video: An overview of the ZACME 7.4QT Stand Mixer, demonstrating its features and components.

OPERATING INSTRUCTIONS

The ZACME Stand Mixer offers precise control for various culinary tasks.

Speed Control and LED Display

- The mixer features 11 speed settings, controlled by a rotary knob. Turn the knob clockwise to increase speed.
- The integrated LED display shows the current operation time.
- Use the up/down arrows next to the display to set a countdown timer. The mixer will automatically stop when the timer reaches zero.

POWERFUL MOTOR

360° Mixing

Planetary action ensures thorough mixing

48~68 dB Low Noise

800 W High Power

Overheat Protection



Image: The mixer's control panel showing the rotary speed knob and LED display with timer functions.

Planetary Mixing Action

The planetary mixing action ensures thorough and uniform mixing by rotating the attachment around the entire interior of the 7.4-quart stainless steel bowl.

HOUSEHOLD STAND MIXER



Image: Illustration of the mixer's planetary action, highlighting its 800W motor and low noise operation.

ATTACHMENTS

The mixer comes with three essential attachments for various tasks:

- **Dough Hook:** Ideal for kneading heavy mixtures like bread dough, pizza dough, and pasta. Use speeds 1-6.
- **Flat Beater:** Suitable for medium-heavy mixtures such as cakes, cookies, mashed potatoes, and salads. Use speeds 2-7.
- **Wire Whisk:** Perfect for light mixtures like whipping cream, egg whites, meringues, and light batters. Use speeds 8-11.



Dough Hook



1-6 Speed

Knead the dough for bread, cookies, pizza, etc



Beater



2-7 Speed

Mixing salad, crepes, mashed potatoes, etc



Whisk



8-11 Speed

Cream, egg white, butter, etc



Image: Visual guide for each attachment (dough hook, beater, whisk) and their recommended speed ranges for different food preparations.

Splash Guard with Feeding Port

The included splash guard helps prevent ingredients from splattering during mixing. It features a convenient feeding port to add ingredients while the mixer is in operation.

7.4 QT LARGE CAPACITY

Meet daily needs in your kitchen



Lift Lock- Adjustable Tilt Design



Splash Guard with Feeding Port

Image: The mixer's 7.4QT capacity bowl, tilt-head design, and splash guard with a feeding port for adding ingredients during operation.

Optional Accessories

The ZACME Stand Mixer is compatible with various optional accessories (sold separately) that can be attached to the front power hub, expanding its versatility for tasks such as meat grinding, noodle making, slicing, and juicing.

VERSATILE ZACME ACCESSORIES

Make More Tasty Food



Meat Grinders



Noodle Maker Set



Slicer



Juice Extractor

Image: The ZACME Stand Mixer displayed with optional attachments like a meat grinder, noodle maker set, slicer, and juice extractor.

MAINTENANCE

Cleaning

- Always unplug the mixer before cleaning.
- The stainless steel mixing bowl, dough hook, flat beater, wire whisk, and splash guard are dishwasher safe.
- Wipe the main unit, including the motor housing and control panel, with a soft, damp cloth. Do not immerse the main unit in water.
- Ensure all parts are completely dry before reassembling or storing.

ENJOY COOKING WITH FAMILY



Image: The stainless steel bowl and attachments are shown being cleaned in a dishwasher, highlighting their ease of maintenance.

TROUBLESHOOTING

- **Mixer stops during operation:** The mixer may have activated its overload protection. Unplug the unit, allow it to cool down for 15-20 minutes, and reduce the load before restarting.
- **Excessive noise:** Ensure the mixing bowl and attachments are correctly installed and locked into place. The mixer is designed for low noise operation, but heavy loads may produce slightly more sound.
- **Dough sticking to the hook:** This can occur with very heavy or sticky doughs. Stop the mixer, scrape the dough off the hook, and continue mixing. Adjusting the dough's consistency slightly may also help.
- **Attachments not reaching ingredients:** Ensure the bowl is properly seated and locked. The planetary action is designed to reach all areas of the bowl.

SPECIFICATIONS

Feature	Detail
Brand	ZACME
Model Name	7.4QT Stand Mixer
Capacity	7.4 Quarts (7L)
Wattage	800 watts
Voltage	120 Volts (AC)
Product Dimensions	18.11"D x 12.2"W x 16.3"H
Item Weight	33 pounds
Material	Aluminum, Stainless Steel
Special Features	Adjustable Speed Control, Anti-Skid, Digital Display, Heavy Duty, Low Noise, Overload Protection, Removable Bowl, Tilt Head, Time Setting Function

WARRANTY AND SUPPORT

Your ZACME 7.4QT Household Stand Mixer comes with a 2-year after-sale service guarantee. For any issues or inquiries, our customer service team is available 24 hours a day to provide effective resolution to your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

