

[Manuals.plus](#) /

› [Aquasonic](#) /

› Aquasonic Vibe Series PRO Ultra-Whitening Electric Toothbrush User Manual

Aquasonic Vibe-Pro

Aquasonic Vibe Series PRO Ultra-Whitening Electric Toothbrush User Manual

Brand: Aquasonic

Model: Vibe-Pro

INTRODUCTION

The Aquasonic Vibe Series PRO is an advanced electric toothbrush designed for comprehensive oral care. Featuring a powerful motor, multiple brushing modes, smart timers, and a UV sanitizing base, it aims to provide an effective and hygienic brushing experience. This manual provides essential information for the proper setup, operation, and maintenance of your device.

WHAT'S IN THE BOX

- 1 Aquasonic Vibe Series Pro Toothbrush Handle
- 1 UV Sanitizing & Wireless Charging Dock
- 6 ProFlex Brush Heads
- 1 Travel Case
- 1 User Manual
- 1 Warranty Card



Image: All components included with the Aquasonic Vibe Series PRO electric toothbrush.

PRODUCT FEATURES

- **Powerful Motor:** Delivers 50,000 vibrations per minute for effective cleaning.
- **5 Brushing Modes:** Includes Clean, Soft, Whiten, Massage, and Deep Clean for customized oral care.
- **Smart Timers:** Features a 30-second notification timer to guide brushing quadrants and a 2-minute auto-timer for recommended brushing duration.
- **UV Sanitizing Base:** Utilizes auto-timed UV lights to sanitize brush bristles between uses, promoting hygiene.
- **ProFlex Brush Heads:** Designed with firmer bristles at the center for stain removal and softer bristles along the perimeter for gum gentleness.
- **ADA Accepted:** Recognized by the American Dental Association for efficacy in removing plaque and preventing gingivitis.
- **IPX7 Waterproof Rating:** Ensures durability and safe use in wet environments.



Image: Internal components and key technological features of the Aquasonic Vibe Series PRO.

SETUP

1. **Initial Charge:** Before first use, place the toothbrush handle onto the UV Sanitizing & Wireless Charging Dock. Ensure the dock is plugged into a power source. Allow the toothbrush to charge fully. The battery indicator light on the handle will show charging status.
2. **Attach Brush Head:** Align the ProFlex brush head with the metal shaft on the toothbrush handle. Push the brush head down firmly until it clicks into place.

Pro Performance



Helps whiten teeth
in as little as 2 weeks



Clinically proven to
reduce plaque and
prevent and reduce
gingivitis



State-of-the-art dental
technology & superior
customer service



Developed and Perfected
in Los Angeles,
Loved Worldwide




Image: The Aquasonic Vibe Series PRO with its accessories, including the travel case, charging dock, and brush heads.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the On/Off button to turn the toothbrush on or off.
2. **Select Brushing Mode:** After powering on, press the mode selection button repeatedly to cycle through the 5 available modes: Clean, Soft, Whiten, Massage, and Deep Clean. The indicator light next to the selected mode will illuminate.
3. **Brushing Technique:** Apply a small amount of toothpaste to the brush head. Place the bristles against your teeth at a slight angle towards the gum line. Move the brush slowly across your teeth, allowing the sonic vibrations to clean each surface.
4. **Smart Timers:** The toothbrush will pause briefly every 30 seconds to indicate when to move to a different quadrant of your mouth. After 2 minutes, the toothbrush will automatically turn off, signaling the completion of the recommended brushing time.
5. **Pressure Sensor:** The toothbrush is equipped with a pressure sensor. If excessive pressure is applied, the vibration intensity may change or an indicator may light up (refer to specific model indicators if available) to prevent damage to gums and teeth.



Intelligent Brushing

5 Custom Modes

CLEAN
standard brushing mode

SOFT
gentle mode for sensitive teeth

WHITEN
helps remove daily surface stains

MESSAGE
delivers vibrating microbursts to gums

DEEP CLEAN
targets stubborn discoloration & polishes teeth

Image: The toothbrush handle displaying the power button and various brushing modes.

MODES OVERVIEW

Mode	Description
Clean	Standard brushing mode for daily plaque removal.
Soft	Gentle mode for sensitive teeth and gums.
Whiten	Helps remove daily surface stains for brighter teeth.
Massage	Delivers vibrating microbursts to gently stimulate gums.
Deep Clean	Targets stubborn discoloration and polishes teeth for an intensive clean.

Exceptional Value

Premium
Travel Case

UV Sanitizing
Charging Base



**6 DuPont ProFlex Brush
Heads Included**
for 1.5+ Years of Brushing

Image: Explanation of each brushing mode available on the Aquasonic Vibe Series PRO.

UV SANITIZING BASE

The UV Sanitizing Base is designed to maintain the hygiene of your brush heads. After each brushing session, rinse your brush head and place it into the designated slot within the UV sanitizing chamber. The auto-timed UV lights will activate to help sanitize the bristles, reducing germs and bacteria.



Whitens While You Brush

50,000 Vibrations Per
Minute Technology

**Removes up to 10x
more plaque
than a manual toothbrush**

Image: The UV sanitizing chamber in action, ensuring brush head hygiene.

CHARGING

The Aquasonic Vibe Series PRO features a wireless charging dock. Simply place the toothbrush handle into the dock when not in use. The battery indicator on the handle will show the charging status. A full charge provides approximately 14 days of battery life, allowing for convenient travel without the need for frequent recharging.

For travel, the included travel case protects your toothbrush and prevents accidental activation.

MAINTENANCE

- **Cleaning the Brush Head:** After each use, rinse the brush head thoroughly under running water to remove any toothpaste residue.
- **Cleaning the Handle:** Wipe the toothbrush handle with a damp cloth as needed. Do not submerge the entire handle in water for extended periods, despite its waterproof rating.
- **Replacing Brush Heads:** For optimal performance and hygiene, replace your ProFlex brush head every 3 months. The Vibe Series PRO includes 6 brush heads, providing a 1.5-year supply.

TROUBLESHOOTING

- **Toothbrush not turning on:** Ensure the toothbrush is fully charged. Place it on the charging dock for several hours.
- **Reduced vibration or cleaning performance:** The brush head may be worn out. Replace it with a new ProFlex brush head.
- **Excessive pressure indication:** If the toothbrush indicates too much pressure, lighten your grip and allow the sonic vibrations to do the work. Avoid scrubbing aggressively.

SPECIFICATIONS

Feature	Detail
Model Number	Vibe-Pro
Vibrations Per Minute	50,000 VPM
Brushing Modes	5 (Clean, Soft, Whiten, Massage, Deep Clean)
Timers	30-second quadrant timer, 2-minute auto-timer
Waterproof Rating	IPX7
Battery Life	Up to 14 days (Lithium-ion)
Brush Head Type	ProFlex (Medium firmness)
Age Range	Adult
Manufacturer	Aquasonic

SAFETY INFORMATION

For oral use only. Not suitable for children. Consult a dental professional if you experience any discomfort or adverse reactions while using this product.

WARRANTY AND SUPPORT

Your Aquasonic Vibe Series PRO includes a Warranty Card in the packaging. Please refer to this card for detailed warranty terms and conditions. For product support, troubleshooting assistance, or to inquire about replacement parts, please contact Aquasonic customer service directly. Contact information can typically be found on the product packaging or the official Aquasonic website.