

[Manuals.plus](#) /

› [Earbay](#) /

› Earbay Wireless Bluetooth Headset BT783 User Manual

Earbay BT783

Earbay Wireless Bluetooth Headset BT783 User Manual

Model: BT783

1. INTRODUCTION

Thank you for choosing the Earbay Wireless Bluetooth Headset BT783. This headset is designed to provide clear audio communication with a noise-canceling microphone, suitable for various professional and personal environments. It offers flexible connectivity options via Bluetooth and a USB dongle, along with a convenient charging base.

This manual provides detailed instructions for setting up, operating, and maintaining your headset to ensure optimal performance and longevity.



Image 1.1: The Earbay headset features AI Environmental Noise Cancellation Technology for clear calls.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Earbay Wireless Bluetooth Headset (BT783)

- USB Dongle
- Charging Base
- USB-C Charging Cable
- User Manual
- Ear Cushions (pre-installed or spare)

3. PRODUCT OVERVIEW

Familiarize yourself with the headset's components and controls.



Image 3.1: Detailed view of the headset showing adjustable headband, soft protein leather ear cushions, 270° rotatable mic, 180° rotation earmuff, LED indicator, Volume-/Previous Track, Volume+/Next Track, MFB Button, Type C Charging Port, and Mute Button.

Key Components:

- **Adjustable Headband:** For a comfortable fit.
- **Soft Protein Leather Ear Cushions:** Designed for extended wear.
- **270° Rotatable Microphone:** Allows for use on either left or right ear, and precise positioning.
- **180° Rotation Earmuff:** For flexible storage and fit.

Controls:

- **MFB Button (Multi-Function Button):** Power on/off, play/pause, answer/end calls.
- **Volume - / Previous Track Button:** Decrease volume, skip to previous track.
- **Volume + / Next Track Button:** Increase volume, skip to next track.
- **Mute Button:** Mute/unmute the microphone.
- **LED Indicator:** Displays status (power, pairing, charging).
- **Type C Charging Port:** For direct charging.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the headset. Place the headset on the charging base or connect the USB-C cable directly to the headset's charging port. The LED indicator will show charging status.




Image 4.1: The headset on its charging base, illustrating its superior battery life with up to 200+ hours standby, 2 hours charge time, and 26 hours talk time.

4.2 Connecting via USB Dongle

1. Insert the USB dongle into an available USB port on your computer.
2. The dongle's LED light will flash, indicating it is searching for the headset.
3. Power on your headset. It will automatically attempt to connect to the dongle.
4. Once connected, the dongle's LED will turn solid blue.
5. On your computer, navigate to Sound Settings and ensure "BT-68 Dongle" is selected as both the input and output device.

4.3 Connecting via Bluetooth

1. Ensure the headset is powered off. Press and hold the MFB button until the LED indicator flashes blue and red alternately, indicating pairing mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for new devices.
3. Select "BT-68" from the list of available devices.
4. Once paired, the headset's LED will flash blue periodically.
5. On your computer, navigate to Sound Settings and ensure "BT-68" is selected as both the input and output device.

USERS WORLDWIDE
They are Using Earbay Wireless Bluetooth Earpiece.

Image 4.2: Flowchart illustrating PC connection settings for Bluetooth and USB Dongle. For Bluetooth, pair with 'BT-68' and set as input/output. For USB Dongle, insert, wait for solid blue LED, and set 'BT-68-DONGLE' as input/output.

4.4 Simultaneous Connection

The headset supports connecting to two devices simultaneously (e.g., a computer via USB dongle and a smartphone via Bluetooth). This allows seamless switching between calls on your phone and audio from your computer.



Image 4.3: The headset demonstrating its ability to connect to two devices simultaneously: a laptop via USB dongle and a smartphone via Bluetooth.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the MFB button for approximately 3 seconds until the LED indicator flashes blue.
- **Power Off:** Press and hold the MFB button for approximately 5 seconds until the LED indicator flashes red and then turns off.

5.2 Call Functions

- **Answer Call:** Press the MFB button once.
- **End Call:** Press the MFB button once during a call.
- **Reject Call:** Press and hold the MFB button for 2 seconds when an incoming call rings.
- **Mute/Unmute Microphone:** Press the dedicated Mute button on the microphone boom. The LED indicator on the microphone will show mute status.

5.3 Volume Control

- **Increase Volume:** Press the Volume + button.
- **Decrease Volume:** Press the Volume - button.

5.4 Music Playback

- **Play/Pause:** Press the MFB button once.
- **Next Track:** Press and hold the Volume + button for 2 seconds.
- **Previous Track:** Press and hold the Volume - button for 2 seconds.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your headset.

- **Cleaning:** Use a soft, dry cloth to clean the headset and charging base. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in use for extended periods.
- **Avoid Moisture:** The headset is not water-resistant. Keep it away from liquids.

7. TROUBLESHOOTING

If you encounter issues with your headset, refer to the following common problems and solutions:

Problem	Possible Solution
Headset does not power on.	Ensure the headset is fully charged. Connect it to the charging base or directly via USB-C cable.
Cannot pair via Bluetooth.	Ensure the headset is in pairing mode (LED flashing blue and red). Turn off and on your device's Bluetooth. Move closer to the device.
No audio or poor audio quality.	Check device's volume settings. Ensure the headset is selected as the default audio output device in your computer's sound settings. Reconnect the headset.
Microphone not working.	Ensure the microphone is not muted (check the mute button LED). Verify the headset is selected as the default input device in your computer's sound settings or meeting application. Adjust microphone position.
USB dongle not connecting.	Try inserting the dongle into a different USB port. Ensure the headset is powered on and within range. Check computer's sound settings for "BT-68 Dongle".
Short battery life.	Ensure the headset is fully charged before use. Battery performance may degrade over time with extensive use.

8. SPECIFICATIONS

Detailed technical specifications for the Earbay Wireless Bluetooth Headset BT783:

Feature	Detail
Model Number	BT783
Brand	Earbay
Connectivity Technology	Wireless (Bluetooth)

Feature	Detail
Wireless Technology	Bluetooth
Headphone Jack	USB (for dongle)
Ear Placement	Open Ear
Form Factor	In Ear
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 millimeters
Microphone	Noise Canceling
Control Type	Media Control
Control Method	Touch (buttons)
Battery Charge Time	2 hours
Battery Average Life (Talk Time)	43 hours (Talk Time)
Item Weight	0.44 kg
Compatible Devices	Laptops, Desktops, Smartphones, Tablets
Additional Features	Lightweight

9. WARRANTY AND SUPPORT

Earbay products are designed for reliability and performance. For warranty information, please refer to the warranty card included in your package or visit the official Earbay website. If you require technical assistance or have questions not covered in this manual, please contact Earbay customer support through the contact information provided on the product packaging or website.

10. SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to your headset and ensure your safety:

- Do not expose the headset to extreme temperatures, humidity, or corrosive environments.
- Avoid dropping or subjecting the headset to strong impacts.
- Do not attempt to disassemble or modify the headset. This may void the warranty and cause damage.
- Keep the headset away from children and pets.
- Use only the provided charging cable and base.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C3B11V7W>

More documents and user manuals: <https://manuals.plus/>