

[manuals.plus](#) /

› [FORSINING](#) /

› [FORSINING Luxury Men's Automatic Mechanical Wristwatch User Manual - Model 2304241](#)

## **FORSINING 2304241**

# **FORSINING Luxury Men's Automatic Mechanical Wristwatch User Manual**

Model: 2304241

## **INTRODUCTION**

Thank you for choosing the FORSINING Luxury Men's Automatic Mechanical Wristwatch. This timepiece combines classic design with intricate mechanical functions, including a moon phase display and a tourbillon. This manual provides essential information for the proper setup, operation, and maintenance of your watch to ensure its longevity and accurate performance.



*Image: Front view of the FORSINING Luxury Men's Automatic Mechanical Wristwatch, showcasing its skeleton dial and moon phase complication.*

## KEY FEATURES

- **Automatic Mechanical Movement:** This watch is powered by the motion of your wrist, eliminating the need for batteries.
- **Skeleton Hollow Design:** The transparent dial reveals the intricate inner workings of the watch movement.

- **Moon Phase Display:** A sub-dial indicates the current phase of the moon.
- **Tourbillon Function:** Designed to enhance timekeeping precision by counteracting gravitational effects on the balance wheel.
- **Genuine Leather Strap:** Provides comfort and durability.
- **Transparent Case Back:** Allows observation of the mechanical movement from the rear.
- **Water Resistance:** Designed for daily life water exposure (e.g., hand washing, light rain). It is **not** suitable for swimming or diving.



*Image: Close-up view highlighting the moon phase and tourbillon complications on the watch dial.*

## SETUP AND INITIAL WINDING

As an automatic mechanical watch, it requires initial winding if it has stopped. The watch is powered by the movement of your wrist during wear. If not worn for an extended period, it will stop.

1. **Manual Winding:** To start the watch or if it has stopped, rotate the crown (located on the side of the watch) clockwise approximately 30-40 times while it is in its normal, pushed-in position. This will build up a power reserve.
2. **Automatic Winding:** Once manually wound, wearing the watch for at least 8-10 hours a day will keep it wound through your natural arm movements.



**CLASSIC NON-SLIP CROWN**

*Image: Close-up of the watch crown, used for winding and setting the time.*

## OPERATING INSTRUCTIONS

### Setting the Time:

1. Pull the crown out to the first position.
2. Rotate the crown to move the hour and minute hands clockwise or counter-clockwise until the desired time is set.
3. Push the crown back into its normal position to engage the movement.

### Setting the Moon Phase:

The moon phase display is typically adjusted using a small recessed pusher on the side of the watch case, or by rotating the crown in a specific position. Refer to the specific instructions for your model if a pusher is present. If no pusher is visible, the moon phase may advance automatically with the time or be adjusted via the crown in a second pulled-out position (if available).

**Note:** Avoid setting the moon phase or date functions between 9 PM and 3 AM, as this can damage the movement.

## CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch case and strap with a soft, dry cloth regularly to remove dust and oils. For the leather strap, avoid excessive moisture.
- **Water Resistance:** This watch is rated for 30M (3 ATM) water resistance, suitable for daily splashes, rain, and hand washing. It is **not** designed for showering, swimming, diving, or any water sports. Ensure the crown is fully pushed in before any contact with water.
- **Avoid Extreme Conditions:** Protect your watch from extreme temperatures, strong magnetic fields, and harsh chemicals.
- **Storage:** When not wearing the watch, store it in a dry, cool place away from direct sunlight.
- **Servicing:** Mechanical watches benefit from periodic servicing (every 3-5 years) by a qualified watchmaker to maintain optimal performance.

# LUXURIOUS



## ***Fashion black Stainless steel***

*Image: The FORSINING watch shown with water splashes, illustrating its daily life water resistance.*

### **TROUBLESHOOTING**

Problem	Possible Cause	Solution
Watch has stopped or is running slow.	Insufficient power reserve.	Manually wind the watch by rotating the crown 30-40 times clockwise. Wear the watch regularly for at least 8-10 hours a day.
Time is inaccurate.	Watch is not fully wound, exposed to strong magnetic fields, or requires servicing.	Ensure the watch is fully wound. Keep away from magnets. If the problem persists, consult a qualified watchmaker.
Condensation under the crystal.	Exposure to extreme temperature changes or water ingress.	Immediately take the watch to a watchmaker for inspection and repair to prevent internal damage.

### **SPECIFICATIONS**

**Brand:** FORSINING

**Model Number:** 2304241

**Movement:** Automatic Mechanical

**Case Material:** Stainless Steel

**Band Material:** Genuine Leather

**Dial Diameter:** 44mm

**Case Thickness:** 13mm

**Band Width:** 24mm

**Total Length:** 24cm

**Water Resistance:** 30M (3 ATM) - Daily life waterproof

**Special Functions:** Moon Phase, Tourbillon



*Image: Diagram illustrating the key dimensions and materials of the FORSINING watch.*

## PRODUCT OVERVIEW VIDEO

Watch this video for a visual overview of the FORSINING Luxury Men's Automatic Mechanical Wristwatch, demonstrating its design and features.

Your browser does not support the video tag.

*Video: An official product video showcasing the FORSINING Luxury Men's Retro Skeleton Watch with Moon Phase & Tourbillon. This video highlights the watch's aesthetic and functional aspects.*

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

For further assistance, you may visit the [FORSINING Store on Amazon](#).