

EMOOR Reon

EMOOR Reon Swivel High-Back Chair with Safety Stopper Instruction Manual

Model: Reon (Black)

1. INTRODUCTION

Thank you for purchasing the EMOOR Reon Swivel High-Back Chair with Safety Stopper. This manual provides essential information for the safe and effective use of your new chair. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INFORMATION

- Ensure the chair is placed on a stable, level surface to prevent tipping.
- Do not stand on the chair or use it for purposes other than sitting.
- Keep hands and fingers clear of moving parts during adjustment to prevent injury.
- When reclining, be aware of the force required and the speed of return. Elderly users should exercise caution.
- Do not exceed the maximum load capacity of approximately 100 kg.
- Regularly inspect all parts for wear or damage. Discontinue use if any damage is found and contact customer support.

3. PRODUCT FEATURES

- **Material Combination:** Features durable faux leather upholstery and natural wood armrests, offering both comfort and aesthetic appeal.
- **Pocket Coil Seating:** The seat is equipped with pocket coils, providing excellent support and reducing fatigue during prolonged use. This design also enhances durability.
- **Swivel Seat with Safety Stopper:** The seat can swivel, and a safety stopper mechanism allows for locking at 90-degree intervals. It can also be set for full 360-degree rotation.
- **Adjustable Backrest:** A lever-type mechanism allows for stepless reclining adjustment of the

backrest.

- **Adjustable Headrest:** The headrest can be adjusted to 14 different angles for personalized comfort.
- **Adjustable Seat Height:** The seat height can be adjusted to two levels (approximately 38 cm and 41 cm) using the included hex wrench.
- **Pre-assembled:** The chair arrives fully assembled, ready for immediate use.

ポケットコイルを使用

体を支えて 疲れにくい座り心地

最も負荷のかかる座面にポケットコイルを使用し、
長時間使用しても疲れにくい座り心地と
長くご愛用いただける高い耐久性を兼ね備えました。



Figure 1: Detail of the pocket coil seating and a user enjoying the chair's comfort.

4. SETUP

This EMOOR Reon chair is delivered fully assembled. No assembly is required.

1. **Unpacking:** Carefully remove the chair from its packaging.
2. **Placement:** Place the chair on a flat, stable surface in your desired location. Ensure there is enough space around the chair for reclining and swiveling.



Figure 2: EMOOR Reon Swivel High-Back Chair (Black) as it appears when unpacked.

5. OPERATING INSTRUCTIONS

5.1 Swivel Function and Safety Stopper

The chair features a swivel seat with a safety stopper mechanism located underneath the seat.

- **To Unlock Swivel:** Push the stopper lever downwards to release the lock. The seat can then rotate.
- **90-Degree Auto-Lock:** When the stopper is engaged, the seat will automatically lock at 90-degree

intervals as you swivel, providing stability.

- **360-Degree Rotation:** To enable continuous 360-degree rotation without the 90-degree locks, ensure the stopper lever is in the unlocked position.



Figure 3: Illustration of the swivel function and safety stopper lever.

5.2 Backrest Reclining Adjustment

The backrest can be adjusted to any angle using the lever-type stepless reclining mechanism.

- **To Recline:** While seated, pull the lever located on the side of the chair and lean back to your desired angle. Release the lever to lock the backrest in position.
- **To Return Upright:** While seated, pull the lever and lean forward slightly. The backrest will return to an upright position. Release the lever to lock.

座面高、背もたれ、首角度 調節

使いやすく安全で便利な機能

2段階に高さ調節できる座面は、安全ストッパー付きの回転式。ロック機能を使わず、くるくる回転高座椅子としても使用できます。

背もたれは無段階調節、ヘッドレストは14段階に調節が可能。

シーンに合わせてお好みに調節していただけます。



Figure 4: Visual guide for backrest, headrest, and seat height adjustments.

5.3 Headrest Angle Adjustment

The headrest offers 14 levels of angle adjustment.

- **To Adjust:** Manually push or pull the headrest to your preferred angle. It will click into place at each of the 14 positions.

5.4 Seat Height Adjustment

The seat height can be adjusted to two levels.

- **To Adjust:** Use the included hex wrench to adjust the seat height to either approximately 38 cm or 41 cm. Refer to the diagram for the adjustment points.

6. MAINTENANCE

- **Cleaning Faux Leather:** Wipe the faux leather upholstery with a soft, damp cloth. For stubborn stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Natural Wood:** Wipe natural wood armrests with a dry or slightly damp cloth. Avoid excessive moisture.
- **General Care:** Periodically check all screws and bolts to ensure they are tight. Retighten if

necessary.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or damage to the upholstery and wood.

ファブレッザと天然木を使用

リビング・書斎・和室に 品のある佇まいを

革の風合いを感じられ、手入れが簡単な
ファブレッザと天然木を組み合わせました。
高級感とぬくもりを感じる見た目が、日常を彩ります。



Figure 5: Detail of the faux leather and natural wood materials.

7. TROUBLESHOOTING

- **Difficulty Reclining:** If the backrest is difficult to recline or return to an upright position, ensure the lever is fully engaged and there is no obstruction. Applying gentle pressure while adjusting may help.
- **Squeaking Noises:** If the chair develops squeaking noises, particularly during rotation or reclining, it may indicate a need for lubrication of moving parts. Contact customer support for guidance on appropriate lubricants and application methods.
- **Unstable Swivel:** Ensure the safety stopper is correctly engaged or disengaged according to your desired swivel mode. Check for any loose connections under the seat.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Model Name	Reon
Color	Black (Note: Not pure black)
Chair Dimensions (Upright)	Approx. W62 x D60 x H77-99 cm
Chair Dimensions (Full Flat)	Approx. W62 x D103 x H74-77 cm
Seat Dimensions	Approx. W47 x D46 x H38/41 cm
Backrest Dimensions	Approx. W47 x L62 cm
Frame Material	Steel
Upholstery Material	100% Polyester (Faux Leather)
Cushioning Material	Pocket Coil, Urethane Foam
Armrest Material	Natural Wood (Poplar)
Headrest Adjustment	14 levels
Backrest Adjustment	Stepless lever-type reclining
Seat Height Adjustment	2 levels (approx. 38 cm, 41 cm)
Seat Function	Swivel with safety stopper
Product Weight	Approx. 13.5 kg
Load Capacity	Approx. 100 kg

SIZE & SPEC

単位：約cm

重量
約 **13.5**kg

耐荷重
約 **100**kg



Figure 6: Comprehensive size and specification diagram.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support needs regarding your EMOOR Reon Swivel High-Back Chair, please contact EMOOR customer service. Details can typically be found on the product packaging or the official EMOOR website.

Please retain your proof of purchase for warranty claims.