

[Manuals.plus](#) /

> [Top Treasures](#) /

> Top Treasures Noel Nativity Set - Outdoor Pre-Lit Christmas Decoration Instruction Manual

Top Treasures S20/1F-06-53A

Top Treasures Noel Nativity Set - Outdoor Pre-Lit Christmas Decoration Instruction Manual

MODEL: S20/1F-06-53A

Introduction

Thank you for choosing the Top Treasures Noel Nativity Set. This pre-lit outdoor Christmas decoration is designed to enhance your holiday display with its festive illumination and durable construction. This manual provides essential information for safe setup, operation, and maintenance of your product.




Safety Information

- Ensure the product is unplugged before assembly, disassembly, or maintenance.
- Do not overload electrical outlets.
- Keep away from open flames or heat sources.
- This product is UL Listed for indoor/outdoor use. However, avoid submerging electrical components in water.
- Use only the provided stakes and fasteners to secure the decoration to prevent tipping in windy conditions.
- Inspect the product for damage before each use. Do not use if wires are frayed or bulbs are broken.

Package Contents

Your Noel Nativity Set package includes the following items:

- 1 x Noel Sign Set (4 pieces: N, O, E, L)
- 2 x Spare Bulbs
- 2 x Fuses
- 16 x Lawn Stakes
- 10 x Cable Ties



All components included in the Noel Nativity Set package.

Setup and Assembly

The Noel Nativity Set is designed for easy assembly without tools. Follow these steps for a secure and beautiful display:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Ensure all items listed in the 'Package Contents' section are present.
2. **Assemble Letters:** Each letter (N, O, E, L) is a separate piece. The 'O' letter features a star at the top. Position the letters to spell 'NOEL'.
3. **Secure with Stakes:** Insert the provided lawn stakes into the ground through the designated loops at the base of each letter. Use multiple stakes per letter for stability.
4. **Connect Lighting:** Connect the electrical cords between the letters. Ensure all connections are secure and protected from moisture. The set features 70 clear incandescent bulbs.

5. **Final Positioning:** Adjust the position of each letter to achieve the desired display. Use cable ties if needed to tidy up wiring or further secure components.



The sturdy build of the Noel sign, featuring a wire frame and included stakes for stability.

Your browser does not support the video tag.


Video demonstrating the assembly and display of the Noel Nativity Set.

Operating Instructions

Once assembled and secured, plug the power cord into a suitable outdoor-rated electrical outlet. The 70 clear incandescent bulbs will illuminate, providing a warm and festive glow. There are no additional operating modes or settings for this product.

UL LISTED LIGHTS

70 LIGHTS – This is a Prelit Christmas Noel Sign Set with 70 clear incandescent bulbs.



Bright Light



Cool to the Touch



Easy Setup



Stakes & Tether

Detail of the 'O' letter, showcasing the 70 clear incandescent bulbs.

Maintenance

- **Cleaning:** To clean, gently wipe the surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** If a bulb burns out, replace it with one of the provided spare bulbs. Ensure the power is disconnected before replacing bulbs.
- **Storage:** After the holiday season, disassemble the set and store it in its original packaging or a dry, protected area to prevent damage and prolong its lifespan.
- **Weather Resistance:** The set is crafted from high-quality, weather-resistant materials designed to withstand harsh weather conditions. However, extreme weather events may require temporary indoor storage.



Weather Friendly

Premium Quality Material



Weather Resistant



Tinsel Fabric



The Noel sign is constructed with weather-resistant materials, suitable for outdoor use.

Troubleshooting


- **Lights Not Working:** Check if the power cord is securely plugged into a working outlet. Inspect the fuse in the plug and replace if blown (spare fuses are included). Check for any loose or broken bulbs and replace them.
- **Instability:** Ensure all lawn stakes are fully inserted into the ground. If the ground is too soft, consider adding additional support or relocating the decoration to a firmer area.
- **Flickering Lights:** This may indicate a loose connection or a faulty bulb. Check all connections and replace any flickering bulbs.

Specifications




Feature	Detail
Model Number	S20/1F-06-53A
Product Dimensions (L x W x H)	17.72 x 6.69 x 13.39 inches

Item Weight	5.57 pounds
Number of Items	4 (letters N, O, E, L)
Light Color	White
Number of Light Sources	70 Incandescent Bulbs
Frame Material	Metal
Material	Metal
Color	Red (as per product details, though images show blue)
Manufacturer	GOLDEN VESSEL ELECTRONIC & LIGHTING INC

PRODUCT DIMENSIONS



**Perfect for
Indoor & Outdoor**



Detailed dimensions for each letter of the Noel sign.

Warranty and Support

No specific warranty information is provided with this product. For any support inquiries, please refer to the retailer or manufacturer's customer service channels.

