

[Manuals.plus](#) /

› [Raysfung](#) /

› Raysfung 6x3ft Outdoor Storage Shed Instruction Manual CWG001

Raysfung CWG001

Raysfung 6x3ft Outdoor Storage Shed Instruction Manual

Model: CWG001

1. INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Raysfung 6x3ft Outdoor Storage Shed, Model CWG001. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product.

The Raysfung portable storage shelter is designed to protect various outdoor items such as bicycles, motorcycles, small lawnmowers, garden tools, and firewood from environmental elements like rain and UV radiation.



Image 1.1: The Raysfung 6x3ft Outdoor Storage Shed, shown with two bicycles stored inside, demonstrating its primary use for protecting outdoor equipment.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure the shed is assembled on a level and stable surface.
- Secure the shed firmly to the ground using the provided ground stakes and ropes to prevent displacement by wind.
- Do not store flammable materials or hazardous chemicals inside the shed.
- Keep children and pets away from the assembly area during installation.
- Regularly inspect the frame and cover for any signs of wear or damage. Replace damaged parts immediately.
- Avoid hanging heavy objects from the frame, as this may compromise its structural integrity.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
Galvanized Steel Frame Pipes	Various lengths and shapes for the main structure	Set
Polyethylene Fabric Cover	Waterproof and UV-resistant tarp with roll-up zipper door	1
Connectors/Joints	For connecting frame pipes	Set
Ground Stakes	For securing the shed to the ground	4+
Ropes	For additional stability	4+
Bungee Balls	For securing the cover to the frame	Set

PRODUCT DETAILS




Image 3.1: Detailed view of key components: door buckle, smooth zipper, elastic bungee balls for securing the cover, and a sturdy frame

4. SETUP AND ASSEMBLY INSTRUCTIONS

No tools are required for the assembly of this storage shed. Follow these steps carefully:

1. **Prepare the Site:** Choose a level, clear area for assembly. Ensure there is enough space around the shed for access and securing.
2. **Assemble the Base Frame:** Connect the appropriate galvanized steel pipes to form the rectangular base of the shed. Ensure all connections are secure.
3. **Erect the Side and Roof Frames:** Attach the vertical pipes to the base frame, then connect them with the roof frame pipes using the provided connectors. The frame is made of thick galvanized steel for stability and rust resistance.
4. **Install the Fabric Cover:** Carefully drape the polyethylene fabric cover over the assembled frame. Ensure the roll-up zipper door is positioned correctly at the front.
5. **Secure the Cover:** Use the elastic bungee balls to firmly attach the fabric cover to the frame pipes. Ensure the cover is taut to prevent water pooling.
6. **Anchor the Shed:** Drive the ground stakes through the designated loops at the base of the shed into the ground. Attach the ropes to the frame and secure them to additional ground stakes or other stable anchor points for enhanced stability, especially in windy conditions.

Add Stability



Ground Stake



Rope



High Quality Steel Pipes

Durable Frame



Image 4.1: Illustration of how to add stability to the shed using ground stakes and ropes, highlighting the durable galvanized steel pipe frame.

5. OPERATING INSTRUCTIONS

Using your Raysfung Outdoor Storage Shed is straightforward:

- **Accessing Contents:** Unzip the roll-up door to open the front of the shed.
- **Ventilation:** For improved air circulation, roll up the zippered door and secure it using the buckles located at the top of the shed. The shed also features a unique vent design on the back for airflow.
- **Securing Contents:** After placing or removing items, ensure the zipper door is fully closed to protect contents from weather and dust.
- **Storage Capacity:** The shed is versatile and can store bicycles, motorcycles, small lawnmowers, firewood, and various garden tools.



Image 5.1: The shed with its roll-up door open, demonstrating easy access and ventilation. The door can be secured at the top with buckles.

UNIQUE VENTS DESIGN

The window on the backdoor to help air flow



Vent details




Image 5.2: Detail of the unique vent design on the back of the shed, which facilitates airflow to prevent condensation and maintain freshness inside.

6. MAINTENANCE

Regular maintenance will extend the life of your storage shed:

- **Cleaning the Cover:** Wipe the polyethylene fabric cover with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners.
- **Frame Inspection:** Periodically check the galvanized steel frame for any signs of rust, bending, or loose connections. Tighten any loose wing nuts or connections.
- **Anchoring Check:** Ensure ground stakes and ropes remain securely anchored, especially after strong winds or heavy rain. Re-secure if necessary.
- **Zipper Care:** Keep the zipper clean and free of debris. Lubricate with a silicone-based spray if it becomes stiff.
- **Snow Removal:** In areas with heavy snowfall, regularly remove snow from the roof to prevent excessive weight.

accumulation, which could damage the frame.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Shed is unstable or sways in wind.	Insufficient anchoring; loose frame connections.	Ensure all ground stakes and ropes are firmly secured. Check and tighten all frame connections. Relocate to a more sheltered area if possible.
Water pooling on the roof.	Cover not taut enough; improper assembly.	Re-adjust the cover and bungee balls to ensure it is stretched tightly over the frame. Verify frame assembly is correct.
Zipper is difficult to open/close.	Dirt/debris in zipper teeth; lack of lubrication.	Clean the zipper teeth with a small brush. Apply a silicone-based lubricant to the zipper.
Condensation inside the shed.	Lack of ventilation.	Ensure the rear vent is clear. Periodically open the roll-up door for extended periods to allow air exchange, especially on dry days.

8. SPECIFICATIONS

- **Brand:** Raysfung
- **Model Number:** CWG001
- **Dimensions (Approximate):** Height: 61.8 inches (157 cm), Width: 37 inches (94 cm), Depth: 70.8 inches (180 cm)
- **Material:** Galvanized Steel Frame, Premium Polyethylene Fabric Cover
- **Color:** Gray
- **Item Weight:** Approximately 12 kg (26.46 pounds)
- **Features:** Waterproof, UV Protection, Roll-Up Zipper Door, Unique Vent Design
- **Recommended Use:** Outdoor storage for bicycles, motorcycles, lawnmowers, garden tools, firewood.

PRODUCT DIMENSION



Garden Tools



Bicycle



Firewood

Image 8.1: Product dimension diagram, providing key measurements for the storage shed.



Image 8.2: Visual representation of the shed's sturdy frame and its protective features, including UV protection and waterproofing.

9. WARRANTY AND SUPPORT

Raysfung is committed to providing high-quality products and customer satisfaction. If you encounter any issues or have questions regarding your Raysfung Outdoor Storage Shed, please contact our customer support team.

Customer Support: For assistance, please refer to the contact information provided at the point of purchase or visit the official Raysfung website. We aim to respond to all inquiries within 24 hours.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question