

[Manuals.plus](#) /

› [Gabba Goods](#) /

› Gabba Goods Bud Light Bladeless Handheld Fan Instruction Manual

Gabba Goods Bud Light

Gabba Goods Bud Light Bladeless Handheld Fan Instruction Manual

Model: Bud Light (18d8855c-4d5d-4c4c-a1d1-feaffc440ef5)

INTRODUCTION

Thank you for purchasing the Gabba Goods Bud Light Bladeless Handheld Fan. This portable fan is designed to provide personal cooling with three adjustable speeds, powered by a rechargeable USB battery. Please read this manual carefully before using the product to ensure proper operation and maintenance.

PRODUCT OVERVIEW

Key Features:

- Bladeless design for safety and easy cleaning.
- Portable and handheld for convenience.
- USB rechargeable battery for cordless operation.
- Three adjustable speed settings.
- Button control for easy operation.
- Compact and lightweight, suitable for travel, office, and home use.

Components:

- Bladeless Handheld Fan Unit
- USB Charging Cable
- Speed Control Mechanism (integrated)







Image: The Gabba Goods Bud Light Bladeless Handheld Fan, showing its compact design and the bladeless air outlet.

SETUP

Charging the Fan:

1. Before first use, fully charge the fan's internal battery.
2. Connect the small end of the provided USB charging cable to the charging port on the fan.
3. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer's USB port.
4. The charging indicator light (if present) will illuminate during charging and typically turn off or change color when fully charged.
5. A full charge usually takes approximately 2-3 hours.

OPERATING INSTRUCTIONS

Power On/Off and Speed Adjustment:

1. To turn the fan **ON**, press the power button located on the handle. The fan will start at the lowest speed setting.
2. To increase the fan speed, press the power button again. Each press will cycle through the available speed settings (Low, Medium, High).
3. To turn the fan **OFF**, press the power button after the highest speed setting. The fan will power down.

Note: The fan is designed for indoor use and personal cooling. Avoid prolonged exposure to direct sunlight or extreme temperatures.

MAINTENANCE

Cleaning the Fan:

- Ensure the fan is turned **OFF** and disconnected from any power source before cleaning.
- Wipe the exterior of the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- The bladeless design allows for easier cleaning of the air inlet and outlet. Use a soft brush or cotton swab to gently remove any dust accumulation.
- Do not immerse the fan in water or any other liquid.
- Allow the fan to dry completely before next use.

Storage:

- When not in use for extended periods, store the fan in a cool, dry place.
- It is recommended to charge the battery every 3 months to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB cable.
Fan runs at low power.	Battery is low.	Recharge the fan.
Weak airflow.	Air inlet/outlet blocked or dirty.	Clean the air inlet and outlet as described in the Maintenance section. Ensure nothing is obstructing the airflow.
Charging indicator not working.	Cable or power source issue.	Try a different USB cable or power adapter. Ensure connections are secure.

SPECIFICATIONS

Brand: Gabba Goods

Model Name: Bud Light

Model Number: 18d8855c-4d5d-4c4c-a1d1-feaffc440ef5

Power Source: Battery Powered (USB Rechargeable)

Number of Speeds: 3

Control Method: Button Control (Touch)

Material: Plastic

Voltage: 5 Volts

Indoor/Outdoor Usage: Indoor

Included Components: USB Cable, Speed Control Mechanism

GTIN (UPC): 840286402828

ASIN: B0C3DZK8PM

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For warranty claims or technical support, please contact the retailer or Gabba Goods customer service directly. Keep your purchase receipt as proof of purchase.

You may find additional support information on the official Gabba Goods website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question