

[manuals.plus](#) /

› [LIORQUE](#) /

› [LIORQUE 60-Minute Visual Timer User Manual \(Model TM021\)](#)

LIORQUE TM021

LIORQUE 60-Minute Visual Timer User Manual

MODEL: TM021

1. Introduction

The LIORQUE 60-Minute Visual Timer is designed to help individuals, especially children, understand and manage time effectively. Its unique rainbow pattern and silent operation make it suitable for various environments such as classrooms, offices, and kitchens. This manual provides detailed instructions for setup, operation, and maintenance of your visual timer.



Image 1.1: The LIORQUE 60-Minute Visual Timer, featuring a blue casing and a clear white dial with a colorful rainbow countdown display.

2. Product Features

- **Visual Countdown:** The timer displays time visually with a disappearing rainbow pattern, making it easy to grasp remaining time at a glance.
- **Silent Operation:** Designed with a sophisticated internal structure to ensure minimal sound during operation, preventing distractions.
- **Adjustable Alarm:** Features an adjustable ringer volume and a mute function to suit different needs and environments.
- **Easy to Use:** Simple knob operation for setting and adjusting time.
- **Versatile Application:** Ideal for classroom activities, kitchen cooking, office tasks, beauty routines, yoga, exercise, and time management for children.




Image 2.1: Visual representation of the timer's core features: time visibility, silent operation, ease of use, and adjustable alarm.

3. Package Contents

- 1 x LIORQUE 60-Minute Visual Timer (Model TM021)
- 2 x AAA Batteries

4. Setup

To begin using your LIORQUE Visual Timer, follow these steps to install the batteries:

1. Locate the battery compartment on the back of the timer.
2. Open the battery compartment cover.
3. Insert the two included AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image 4.1: The visual timer displayed with two AAA batteries, indicating where batteries are placed and providing product dimensions.

5. Operation

Operating the LIORQUE Visual Timer is straightforward:

- 1. Setting the Timer:** Turn the central knob clockwise to increase the time. The rainbow-colored disk will appear, indicating the set duration.
- 2. Decreasing Time:** Turn the knob counter-clockwise to decrease the set time.
- 3. Starting the Countdown:** Once the desired time is set, the timer will automatically begin counting down. The colored disk will gradually disappear as time elapses.
- 4. Alarm Function:** When the time expires, the timer will emit an audible alarm.
- 5. Silencing the Ringer:** To turn off the ringer, turn the knob clockwise slightly past the zero mark, then immediately turn it back to the zero position. This action resets the alarm mechanism.




Image 5.1: A user's hand demonstrating how to turn the central knob to set the desired countdown time.

The visual timer is suitable for a variety of activities:




Image 5.2: Examples of the timer's versatility, including use in cooking, educational settings, relaxation, and personal care.

6. Maintenance

- **Cleaning:** Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Battery Replacement:** Replace batteries when the timer's performance diminishes or if the alarm becomes weak. Ensure to use 2 new AAA batteries.
- **Storage:** Store the timer in a cool, dry place when not in use for extended periods.

7. Troubleshooting

- **Timer not moving or inaccurate:**
 - Ensure batteries are correctly installed and not depleted.
 - Verify the knob has been turned past the zero mark to engage the mechanism.
 - For longer durations, slight inaccuracies may occur due to the mechanical nature of the timer.
- **Alarm not sounding or too quiet:**
 - Check if the ringer has been accidentally muted (refer to 'Silencing the Ringer' in Section 5).
 - Ensure batteries are not low, as this can affect alarm volume.

8. Specifications




Attribute	Detail
Brand	LIORQUE
Model Number	TM021
Color	Blue
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	1.77"D x 3"W x 2.83"H
Item Weight	2.72 ounces (0.17 Pounds)
Power Source	2 x AAA batteries (included)
Maximum Time Setting	60 Minutes


9. Safety Information

- Keep the device away from water and high humidity.
- Do not attempt to disassemble or repair the timer yourself. Contact customer support for assistance.
- Keep batteries out of reach of small children to prevent accidental ingestion.
- Dispose of used batteries according to local regulations.

10. Warranty and Support

LIORQUE products are designed for reliability and performance. For any questions, concerns, or warranty claims, please contact LIORQUE customer support through the retailer's platform or the official brand website. Please retain your proof of purchase for warranty service.

	<p>Secura 60-Minute Visual Countdown Timer (Model TM021) - Instruction Manual</p> <p>Instruction manual for the Secura 60-Minute Visual Countdown Timer (Model TM021). Covers setup, usage, parts list, tips, care instructions, and warranty information.</p>
	<p>LIORQUE Kitchen Timer Model TM021 User Manual</p> <p>User manual for the LIORQUE Kitchen Timer, Model TM021. Learn how to install batteries, set the timer, use its features, and understand its disposal instructions.</p>
	<p>LIORQUE Visual Timer Model TM027 User Guide</p> <p>Comprehensive guide for the LIORQUE Visual Timer (Model TM027). Learn about its features, alarm modes (sound, light, vibration), setting instructions, low battery indicators, and proper disposal. Contact support for assistance.</p>
	<p>LIORQUE Kitchen Timer and Clock User Manual</p> <p>User manual for the LIORQUE Kitchen Timer and Clock, detailing its features, operation, and specifications. This digital timer is suitable for cooking, learning, and various other activities.</p>
	<p>ThermoPro TM021 Digital Kitchen Timer Instruction Manual</p> <p>This manual provides instructions for using the ThermoPro TM021 digital kitchen timer, including how to insert batteries, set the timer, and understand its features. It also outlines the limited one-year warranty and customer service contact information.</p>



[LIORQUE Radiowa Stacja pogodowa z czujnikiem zewnętrznym: Termometr, Higrometr, Prognoza pogody, Zasilana Bateriami](#)

Wielofunkcyjna radiowa stacja pogodowa LIORQUE z czujnikiem zewnętrznym do monitorowania temperatury, wilgotności i prognozy pogody wewnętrz i na zewnątrz. Wyposażona w 4,3-calowy ekran LCD, funkcje alarmu, drzemki i kalendarza. Łatwa w konfiguracji, zasilana bateriami.