Buoan YL-98-black-2pc

Buoan Keyless Entry Door Lock Instruction Manual

Model: YL-98-black-2pc | Brand: Buoan

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Buoan Keyless Entry Door Lock. Designed for convenience and security, this electronic door knob offers multiple unlocking methods and robust weather resistance. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your device.

Setup and Installation

The Buoan Keyless Entry Door Lock is designed for easy installation, typically requiring only a screwdriver. It is suitable for most standard doors in the United States.

Included Components

Component	Description
Lock Unit	Keypad door knob assembly
Keys	Mechanical backup keys
Screws	Various screws for mounting
USB Cable	For emergency power supply
Instruction Manual	This document

Installation Steps

1. **Prepare the Door:** Ensure your door thickness and bore holes are compatible with the lock's dimensions. The lock is designed to fit most standard doors.
2. **Install the Latch:** Insert the latch into the door edge and secure it with screws. Ensure the latch bolt faces the correct direction for your door's swing.

3. **Assemble the Exterior Knob:** Connect the exterior keypad knob to the latch assembly.
4. **Install Batteries:** Open the battery compartment on the interior knob. Insert 1.5V AA alkaline batteries (not included), ensuring correct polarity.
5. **Attach the Interior Knob:** Connect the interior knob to the exterior assembly, aligning the spindle with the latch mechanism. Secure with the provided screws.
6. **Test Functionality:** After installation, test the lock's operation using the default code or a mechanical key to ensure it locks and unlocks smoothly.



Figure 1: Easy Installation Steps



Figure 2: Door Thickness and Adjustable Lock Cylinder



Figure 3: Packaging Details and Included Components

Operating Instructions

Unlocking Methods

- **Passcode Entry:** Enter your programmed passcode on the keypad. The keypad features a backlight for use in low light conditions and an anti-peeping function to deter onlookers.
- **Mechanical Key:** Use the provided mechanical keys as a backup unlocking method. The keyhole is discreetly located for security.

Automatic Locking

For enhanced security, the door will automatically lock approximately 2.5 seconds after it is closed. This feature ensures your door is always secured behind you.

Silent Mode

To activate Silent Mode, long press the '*' key for 5 seconds. This will disable audible feedback from the lock. To deactivate, long press the '*' key again for 5 seconds.

Passage Mode

Passage Mode allows the door to remain unlocked for continuous access. To enable or disable Passage Mode, enter your master password, wait for the beep, then quickly press the '#' key.



Figure 4: Multi-function and Easy Operation



Figure 5: Silent Mode and Passage Mode



Figure 6: Convenient Passcode Sharing

Maintenance

Battery Replacement

The lock requires 1.5V AA alkaline batteries. When the batteries are low, the lock will provide a low battery alert. For emergency unlocking when batteries are completely dead, the lock can be temporarily powered via a USB cable connected to the USB charging port.

Cleaning

To clean the lock, use a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or electronic components.

Weather Resistance

The Buoan Keyless Entry Door Lock is IP65 weatherproof, ensuring reliable operation in various weather conditions, including rain and extreme temperatures ranging from -4°F to 167°F.



Figure 7: Weatherproof Design and Reset Key Location

Troubleshooting

Common Issues and Solutions

- **Lock not responding:** Check battery levels. If batteries are depleted, use the mechanical key or connect a USB cable for emergency power.
- **Forgotten Passcode:** If you forget your master code, press and hold the reset button for 5 seconds until three beeps are heard. The master code will revert to the manufacturer's default code.
- **Keypad not lighting up:** This typically indicates low or dead batteries. Replace the batteries or use the USB emergency power feature.
- **Door does not lock automatically:** Ensure the door is fully closed and the latch is properly aligned with the strike plate. Check if Passage Mode is accidentally activated.

Specifications

Feature	Detail
Brand	Buoan

Feature	Detail
Model	YL-98-black-2pc
Material	Zinc
Lock Type	Keypad
Special Feature	Waterproof
Dimensions (L x W x H)	7.32 x 3.23 x 3.23 inches
Item Weight	5.61 pounds
Power Source	Batteries (1.5V AA required, not included)
Control Method	Touch, Mechanical knob
UPC	780669095936

Warranty and Support

Buoan provides a free replacement service for 12 months for non-human caused damage, along with lifelong service support for your product.
For further assistance, please visit the official Buoan Store on Amazon.

© 2024 Buoan. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question