

Ltinist BX29

Ltinist BX29 Wireless Bluetooth Earbud Sport Instruction Manual

Model: BX29

1. INTRODUCTION

Thank you for choosing the Ltinist BX29 Wireless Bluetooth Earbud Sport. This manual provides essential information for setting up, operating, and maintaining your new earbuds to ensure optimal performance and longevity. Please read these instructions carefully before use.

2. PACKAGE CONTENTS

- 2x Wireless Earbuds (Left/Right)
- 1x Type-C Charging Cable
- 1x Charging Case
- 3x Eartips (S/M/L)
- 1x User Manual

ONE-STEP PAIRING

Open the earphone box and take out the earphone, turn on the bluetooth of the mobile phone and select "BX29" to start enjoying your music time




Image: The Ltinist BX29 earbuds, charging case, and accessories as typically found in the product package.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C charging cable to the charging port on the case and a power source. The LED display on the charging case will indicate the battery level of both the case and the individual earbuds. A full charge provides up to 75 hours of total music time with the charging case.

MUSIC NEVER STOP

 **15Hrs**
Single Charge

 **60Hrs**
Charging Case

 **75Hrs**
Long Playtime



Image: The charging case with earbuds, displaying the battery percentage for the case and each earbud.

3.2 Pairing with a Device

1. Ensure the earbuds are charged.
2. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "BX29" from the list of found devices to connect.
5. Once connected, the earbuds will automatically pair with this device in the future when removed from the case.

ONE-STEP PAIRING

Open the earphone box and take out the earphone, turn on the bluetooth of the mobile phone and select "BX29" to start enjoying your music time




Image: A visual representation of the one-step pairing process, showing the earbuds and a smartphone connecting via Bluetooth.

3.3 Achieving a Secure Fit

The BX29 earbuds feature an ergonomic over-ear hook design for stability, especially during physical activity. Select the appropriate ear tip size (S/M/L) for a comfortable and secure fit. The ear tips should create a gentle seal in your ear canal for optimal sound quality and noise isolation.

DESIGN FOR SPORTS

Flexible Earhooks



Light-Weight



3 Soft Eartips (S/M/L)




Image: Illustration of the ergonomic design with flexible earhooks and interchangeable soft eartips for a secure fit during sports.

4. OPERATING INSTRUCTIONS

4.1 Button Controls

Each earbud is equipped with a multi-function button for easy control of audio playback and calls. Refer to the diagram below for specific functions:

EASY BUTTON CONTROL



Image: Detailed guide to the button controls on the earbuds, showing single-click, double-click, and long-press functions for various operations.

- **Volume Control:** Click once on the designated button (refer to diagram).
- **Play/Pause:** Click once on the designated button (refer to diagram).
- **Next Track:** Hold for 2 seconds on the designated button (refer to diagram).
- **Previous Track:** Hold for 2 seconds on the designated button (refer to diagram).
- **Answer/End Call:** Click once on the designated button.
- **Reject Call:** Hold for 2 seconds on the designated button.
- **Activate Voice Assistant:** Double-click on the designated button.
- **Power On/Off:** Hold for 5 seconds on the designated button.

4.2 Sound Quality and Calls

The BX29 earbuds are equipped with 14.2mm dynamic drivers for balanced audio and clarity. Environmental Noise Cancellation (ENC) technology helps reduce background noise during calls, providing a clearer communication experience.

PUNCHY BASS AROUND YOUR EARS

14.2mm dynamic drivers can produce punchy bass, allowing you to enjoy the ultimate listening experience




Image: An exploded view highlighting the 14.2mm dynamic driver for enhanced bass and the ENC noise cancelling microphone.

5. MAINTENANCE

5.1 Cleaning and Care

Regular cleaning helps maintain the performance and hygiene of your earbuds. Use a soft, dry cloth to wipe the earbuds and charging case. For ear tips, remove them and clean with a mild soap solution, then rinse and dry thoroughly before reattaching.

5.2 Water Resistance

The earbuds have an IP7 waterproof rating, meaning they are protected against the effects of temporary immersion in water. This makes them suitable for use during workouts and in light rain. However, the charging case is not waterproof. Avoid submerging the earbuds or exposing the charging case to water.

IP7 WATERPROOF

Nano-coated to resist sweat damage, ideal for outwork, gym, cycling, or taking a jog



Rainy Day



Sweatproof



Splashproof

Image: The earbuds are shown with water droplets, illustrating their IP7 waterproof capability for various activities.

6. TROUBLESHOOTING

If you encounter issues with your Ltinist BX29 earbuds, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are in the charging case, then open the lid. Check that Bluetooth is enabled on your device and select "BX29". If issues persist, try forgetting the device on your phone and re-pairing.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, and then open it again. This often resets the connection between the two earbuds.
- **No sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly paired and selected as the audio output device.
- **Charging issues:** Verify that the USB-C cable is securely connected to both the charging case and the power source. Clean the charging contacts on the earbuds and inside the case with a dry cotton swab.
- **Uncomfortable fit:** Experiment with the different sizes of ear tips (S/M/L) provided to find the most comfortable and secure fit for your ears.

7. SPECIFICATIONS

Feature	Detail
Model Name	BX29
Bluetooth Version	5.3
Connectivity Technology	Wireless
Audio Driver Type	Dynamic Driver (14.2mm)
Noise Control	Environmental Noise Cancellation (ENC)
Battery Life (Single Charge)	15 Hours
Total Playtime (with Charging Case)	75 Hours
Charging Time	1.5 Hours
Charging Port	USB-C
Water Resistance Level	IP7 Waterproof
Control Type	Button Control
Ear Placement	Over Ear
Material	Plastic
Item Weight	0.13 Kilograms (4.6 ounces)

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Ltinist customer service. Refer to the product packaging or the official Ltinist website for contact details. Keep your purchase receipt as proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question