

[Manuals.plus](#) /

› [Nu Republic](#) /

› Nu Republic Party Box 16 Bluetooth Soundbar Instruction Manual

Nu Republic Party Box 16 (NSB101)

Nu Republic Party Box 16 Bluetooth Soundbar Instruction Manual

Model: Party Box 16 (NSB101)

INTRODUCTION

Thank you for choosing the Nu Republic Party Box 16 Bluetooth Soundbar. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use to ensure optimal performance and longevity.

Key Features:

- **16W X-Bass Immersive Sound:** Dual 8W drivers with X-Bass Technology for clear audio and deep bass.
- **Dual Bass Reflex Ports:** Enhances low-frequency response for cinematic bass.
- **Dynamic RGB LED Lights:** Multi-color lights for ambient effects.
- **Bluetooth 5.0 + AUX In:** Seamless wireless and wired connectivity options.
- **10 Hours Playtime:** Extended battery life for continuous audio playback.

WHAT'S IN THE BOX

- Main Unit (Nu Republic Party Box 16 Soundbar)
- Charging Cable



Image: The Nu Republic Party Box 16 Soundbar shown with its retail packaging, indicating included items.

PRODUCT OVERVIEW

Controls and Ports:

Familiarize yourself with the control buttons and connection ports on your soundbar.

**packed with beats
powered by bass**



Image: Top view of the soundbar highlighting the soft control buttons for power, volume, and mode selection.




Image: An exploded view of the soundbar showing internal components like 52mm dynamic drivers, LED lights, and

control buttons.

The soundbar features a metal mesh board and titanium silver metal texture for durability and aesthetics. The RGB LED lights are located at both ends of the soundbar.



Image: Close-up of the soundbar's end, showcasing the RGB LED lights and listing various color modes such as multi-color, rhythm, bright, breathing, wild, and solid.

SETUP

Charging the Soundbar:

1. Connect the provided charging cable to the charging port on the soundbar.
2. Connect the other end of the charging cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge takes approximately 2 hours.

Placement:

Place the soundbar on a stable, flat surface, such as a tabletop or desk, for optimal audio projection. Ensure it is not obstructed by other objects.

OPERATING INSTRUCTIONS

Power On/Off:

- To power on, press and hold the Power button until the indicator light illuminates.
- To power off, press and hold the Power button again until the indicator light turns off.

Bluetooth Pairing:

1. Ensure the soundbar is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, press the Mode button to switch to Bluetooth.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "Nu Republic Party Box 16" from the list.
4. Once paired, the LED indicator will turn solid blue, and you will hear a confirmation tone.

AUX Input Mode:

- Connect one end of a 3.5mm audio cable (not included) to the AUX port on the soundbar.
- Connect the other end to the audio output jack of your external device.
- Press the Mode button on the soundbar until the AUX indicator light illuminates.

USB Playback Mode:

- Insert a USB flash drive containing MP3 audio files into the USB port.
- The soundbar will automatically switch to USB mode and begin playing audio. If not, press the Mode button to select USB mode.

Adjusting Volume:

- Press the Volume Up (+) button to increase the volume.
- Press the Volume Down (-) button to decrease the volume.

Controlling RGB LED Lights:

- Use the dedicated RGB light control button (if available, or refer to the manual for specific button) to cycle through different light modes.
- Available modes include multi-color, rhythm, bright, breathing, wild, and solid colors.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Solution
No power	Ensure the soundbar is charged. Connect the charging cable and allow it to charge for a while before attempting to power on.
Cannot pair via Bluetooth	◦ Ensure the soundbar is in Bluetooth pairing mode (flashing LED). ◦ Make sure your device's Bluetooth is enabled and within range (up to 10 meters). ◦ Forget previously paired devices on your phone and try pairing again. ◦ Restart both the soundbar and your device.
No sound from AUX/USB	◦ Ensure the correct mode (AUX or USB) is selected on the soundbar. ◦ Check if the audio cable is securely connected for AUX mode. ◦ Verify that the USB drive contains compatible audio files (MP3). ◦ Increase the volume on both the soundbar and the connected device.
Sound distortion at high volume	Reduce the volume on both the soundbar and the connected device. Ensure audio source quality is good.

SPECIFICATIONS

Feature	Detail
Brand	Nu Republic
Model Name	Party Box 16
Model Number	NSB101
Speaker Maximum Output Power	16 Watts
Frequency Response	20 KHz
Connectivity Technology	Auxiliary, Bluetooth, USB
Bluetooth Range	10 Metres
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
Enclosure Material	Acrylonitrile Butadiene Styrene (ABS)
Speaker Type	Soundbar
Product Features	Bass Boost, Hi Res Audio, USB Port
Colour	Black
Control Method	Touch
Speaker Size	41.5 Centimetres (Length)
Woofer Driver Diameter	50 Millimetres
Battery Average Life	10 Hours
Battery Charge Time	2 Hours
Battery Capacity	2000 Milliamp Hours
Item Dimensions (D x W x H)	5.5D x 38W x 6.5H Centimeters
Item Weight	500 Grams
Is Waterproof	No
Country of Origin	India

WARRANTY AND SUPPORT

Warranty Information:

The Nu Republic Party Box 16 Bluetooth Soundbar comes with a **6 Months Replacement Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims.

Customer Support:

For any queries, technical assistance, or warranty claims, please contact Nu Republic customer support. You can find more information on the official Nu Republic website or refer to the contact details provided with your product

packaging.

Manufacturer Contact: Nuworld Retail Private Limited, plot No.17-18, Pole No.9, PO Dhoolsiras, Dwarka, Sector-28, New Delhi - 110077.