

[Manuals.plus](#) /

> [FALK](#) /

> FALK Farm Lander Pedal Tractor with Trailer - Model 2054L Instruction Manual

FALK 2054L

FALK Farm Lander Pedal Tractor with Trailer - Model 2054L Instruction Manual

Brand: FALK | Model: 2054L

1. INTRODUCTION

Thank you for choosing the FALK Farm Lander Pedal Tractor with Trailer, Model 2054L. This durable and engaging ride-on toy is designed for children aged 2 to 5 years, encouraging outdoor play and imaginative activities. Manufactured in France with a commitment to sustainability, this tractor is made from at least 50% recycled plastic.

This manual provides essential information for the safe assembly, operation, and maintenance of your new pedal tractor. Please read all instructions carefully before assembly and use to ensure your child's safety and the longevity of the product.



Image 1.1: The FALK Farm Lander Pedal Tractor with its detachable trailer, ready for play.

2. SAFETY WARNINGS AND GUIDELINES

WARNING: Not suitable for children over 36 months due to its design, which may not support older children safely. Maximum user weight: 30 kg.

- **Adult Supervision Required:** Always supervise children when they are using the pedal tractor.
- **Age Range:** This product is intended for children aged 2 to 5 years.
- **Protective Equipment:** Ensure the child wears appropriate protective gear, such as a helmet, especially when riding on uneven surfaces or near traffic.
- **Safe Riding Environment:** Use the tractor on flat, level surfaces away from roads, steep inclines, stairs, swimming pools, and other hazards.
- **Avoid Obstacles:** Instruct children to avoid obstacles, walls, and furniture to prevent accidents.
- **One Rider Only:** The tractor is designed for one child at a time. Do not allow multiple riders.
- **Trailer Use:** The trailer is for light loads only (e.g., sand, leaves, small toys). Do not overload the trailer or allow children to ride in it.
- **Regular Checks:** Before each use, check that all parts are securely fastened and that the steering and pedals function correctly.

3. ASSEMBLY INSTRUCTIONS

Assembly of the FALK Farm Lander Pedal Tractor requires adult supervision and may take approximately 30-60 minutes. Please ensure all components are present before beginning.

3.1. Unpacking and Component Check

Carefully remove all parts from the packaging. Lay them out on a clean, flat surface. Refer to the parts diagram (if included in your physical manual) to identify each component.



Image 3.1: Various components of the pedal tractor, including wheels, chassis, and steering column, laid out for assembly.

3.2. Step-by-Step Assembly

1. **Attach the Wheels:** Securely attach the front and rear wheels to the tractor chassis using the provided axles and fasteners. Ensure they rotate freely.
2. **Install the Steering Column:** Insert the steering column into the designated opening on the tractor body. Connect the steering linkage to the front axle mechanism.
3. **Mount the Steering Wheel:** Place the steering wheel onto the top of the steering column and secure it firmly. Ensure the horn (if integrated) is functional.
4. **Assemble the Seat:** Attach the seat to the tractor body. Ensure it is stable and securely fastened.
5. **Connect the Pedals:** Install the pedal mechanism, ensuring the chain or drive belt is correctly aligned and tensioned. Test the pedals for smooth operation.
6. **Attach the Trailer:** Connect the trailer hitch to the rear of the tractor. Ensure the trailer can be easily attached and

detached.

7. **Apply Customization Stickers:** Use the provided customizable license plate and stickers to personalize the tractor.

After assembly, double-check all connections and fasteners to ensure they are tight and secure before allowing a child to use the tractor.

4. OPERATING INSTRUCTIONS

The FALK Farm Lander Pedal Tractor is designed for intuitive use by young children. Follow these guidelines for safe and enjoyable operation.

4.1. Getting Started

- **Seating:** Help your child sit comfortably on the seat, ensuring their feet can reach the pedals.
- **Pedaling:** Instruct your child to push the pedals in a circular motion to move the tractor forward.
- **Steering:** The steering wheel controls the front wheels. Teach your child to turn the wheel left to go left and right to go right. The steering is directional for easy maneuverability.
- **Horn:** The steering wheel includes a functional horn. Show your child how to use it.
- **Trailer Use:** The detachable trailer can be used to transport light items like sand, leaves, or small toys. Ensure the trailer is securely attached before use.



Image 4.1: A child demonstrates the directional steering and the use of the trailer on the FALK Farm Lander tractor.



Packaging en carton 100% recyclé
100% recycled cardboard packaging

Image 4.2: A child enjoying the FALK Farm Lander Pedal Tractor in an outdoor setting.

5. CARE AND MAINTENANCE

Proper care will extend the life of your FALK Farm Lander Pedal Tractor and ensure continued safe operation.

- **Cleaning:** Wipe down the tractor with a damp cloth and mild soap as needed. Avoid harsh chemicals or abrasive cleaners. Rinse thoroughly and dry.
- **Storage:** Store the tractor in a dry, sheltered area when not in use to protect it from extreme weather conditions and prolonged sun exposure, which can degrade plastic components.
- **Inspections:** Periodically check all nuts, bolts, and fasteners to ensure they are tight. Inspect the wheels, pedals, and steering mechanism for any signs of wear or damage.
- **Lubrication:** The pedal mechanism may benefit from occasional lubrication with a silicone-based spray to ensure smooth operation.
- **Damaged Parts:** If any part is damaged or broken, discontinue use immediately and contact customer support for replacement parts. Do not attempt to repair with non-original parts.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter with your pedal tractor:

- **Tractor is difficult to pedal:**
 - Check the pedal chain/belt for proper tension and alignment.
 - Ensure there is no debris obstructing the pedal mechanism.
 - Apply a small amount of lubricant to the moving parts of the pedal system.
- **Steering is stiff or unresponsive:**
 - Verify that the steering column and linkage are correctly assembled and not obstructed.
 - Check for any loose connections in the steering mechanism.
- **Wheels are not turning smoothly:**
 - Inspect wheels for debris (e.g., grass, string) wrapped around the axles.
 - Ensure wheel fasteners are not overtightened, allowing free rotation.
- **Trailer detaches easily:**
 - Ensure the trailer hitch is fully engaged and secured to the tractor's attachment point.
 - Check for any damage to the hitch mechanism.

If you experience persistent issues not covered here, please contact FALK customer support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	FALK
Model Number	2054L
Recommended Age	24 months - 5 years
Product Dimensions (L x W x H)	123 x 42 x 53 cm
Item Weight	6.8 Kilograms
Material	Plastic (at least 50% recycled)
Color	Dark Green
Educational Value	Promotes creativity, imagination, and motor skill development.
Assembly Required	Yes
Country of Origin	France



Image 7.1: Visual representation of the FALK Farm Lander Pedal Tractor's dimensions (123 cm length, 42 cm width, 53 cm height).



Image 7.2: The FALK Farm Lander Pedal Tractor highlighting its construction from over 50% recycled plastic.

8. WARRANTY AND CUSTOMER SUPPORT

8.1. Warranty Information

Specific warranty details for the FALK Farm Lander Pedal Tractor are typically provided with the product packaging or can be obtained from your retailer at the time of purchase. Please retain your proof of purchase for any warranty claims.

8.2. Customer Support

For any questions regarding assembly, operation, maintenance, or replacement parts, please contact FALK customer support:

- **Website:** www.falk-toys.com (Please check the official website for contact details specific to your region.)

- **Manufacturer Address:** FALK SAS, 100 Rue du Jura, 01100 Oyonnax, France

When contacting support, please have your product model number (2054L) and purchase date available.