

HW3

# Generic HW3 Ultra Max Smartwatch User Manual

Model: HW3

## INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your Generic HW3 Ultra Max Smartwatch. Please read this manual thoroughly before using the device to ensure proper function and to maximize your user experience.



Image: The HW3 Ultra Max Smartwatch in black, showcasing its round display and textured band.

## PACKAGE CONTENTS

Ensure all items are present in the package:

- HW3 Ultra Max Smartwatch
- Watch Band (as specified in product details)
- Charging Cable
- User Manual



Image: Contents of the HW3 Ultra Max Smartwatch package, including the watch and its box.

## PRODUCT OVERVIEW

The HW3 Ultra Max Smartwatch features a 1.52-inch round display, designed for clear visibility and intuitive interaction. It integrates various functions including NFC, Bluetooth calling, and extensive sport tracking capabilities. The watch is crafted with durability in mind, ensuring robust performance.

# HW3

## ULTRA MAX

Voice assistant | Dock | Multiple sports functions | NFC



Image: Overview of the HW3 Ultra Max Smartwatch, emphasizing its key features.



# TOUGH STRONG

To create this super sports watch, we have carefully polished it. Every design, repeatedly delving into every detail, and striving to bring it performance that pushes the limits.

Image: The HW3 Ultra Max Smartwatch highlighting its durable construction and design.

## Key Features:

- **Display:** 1.52-inch Round Screen, 360\*360 resolution.
- **Connectivity:** Bluetooth for calls and data sync, NFC for various functions.
- **Sports Modes:** Over 90 integrated sport modes.
- **Fitness Tracking:** Heart rate, calorie tracking, and more.
- **Additional:** Voice assistant, customizable dials.



## Unbounded Aesthetics Soft and flexible.

Reinventing the shape of a round classic watch, the integrated design of lustrous glass and zinc alloy body is both rigid and soft, and it is light and thin to wear. With a 1.52-inch, 360\*360 resolution, and ultra-retina high-definition screen, the display effect is vivid and delicate.

Image: Detailed view of the 1.52-inch display and its high-definition resolution.

## SETUP

### 1. Charging the Smartwatch

Before initial use, fully charge your smartwatch. Connect the charging cable to the charging port on the back of the watch and plug the other end into a USB power adapter (not included).

- A charging indicator will appear on the screen.
- Charging typically takes 1-2 hours.

### 2. Powering On/Off

- **Power On:** Press and hold the side button until the screen lights up.
- **Power Off:** Press and hold the side button, then select "Power Off" on the screen.

### 3. App Installation and Pairing

To unlock the full functionality of your smartwatch, download the companion application on your smartphone. Refer to the QR code in the watch's settings or the manual for the specific app name (e.g., "WearFit" as suggested by product images).

1. Download and install the app from your smartphone's app store (Google Play Store or Apple App Store).
2. Open the app and create an account or log in.
3. Enable Bluetooth on your smartphone.
4. In the app, navigate to "Device" or "Add Device" and select your HW3 Ultra Max Smartwatch from the list of available devices.
5. Confirm the pairing request on both your smartphone and smartwatch.

#### 4. NFC Setup

The smartwatch supports NFC functionality. Specific setup instructions for NFC features (e.g., access control, payment) will depend on the compatible services and applications. Consult the companion app for detailed guidance on configuring NFC.

## OPERATING INSTRUCTIONS

---

### Basic Navigation

- **Touchscreen:** Swipe left/right, up/down to navigate through menus and notifications. Tap to select.
- **Side Button:** Press to return to the home screen or wake the device. Long press for power options.
- **Rotating Crown:** Rotate to scroll through lists or adjust settings (functionality may vary by watch face/app).

### Making and Receiving Calls

Once paired via Bluetooth, your smartwatch can handle calls:

- **Making Calls:** Access the dialer or contacts list on your watch to initiate a call.
- **Receiving Calls:** When a call comes in, you can answer or reject it directly from your watch screen.

### Sport Modes and Fitness Tracking

The HW3 Ultra Max offers over 90 sport modes to track your activities. Access these modes through the "Sports" or "Workout" menu on your watch.



# SPORTS

## Love sports Never stop

### 90+ modes

Meet all your choices for sports, It is even possible to track data such as heart rate, calories, and more.

Image: The smartwatch tracking various sport activities with over 90 available modes.

During a workout, the watch tracks metrics such as:

- Heart Rate
- Calories Burned
- Distance
- Duration
- Steps (daily activity)

All tracked data can be synchronized and viewed in detail within the companion app.

### Notifications

Receive notifications from your smartphone directly on your watch. Ensure notification permissions are enabled in both your phone's settings and the companion app.

### Customizing Watch Faces

Personalize your smartwatch with various watch faces. You can change them directly on the watch by long-pressing the home screen or through the companion app for more options.

# Stylish dial Good temperament

Dynamic dials, integrated dials, no matter how unique your style is, there is always one of the many styles that will make you more stylish.



Image: Examples of customizable watch faces available for the HW3 Ultra Max Smartwatch.

## MAINTENANCE

### Cleaning

- Wipe the watch screen and body with a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals.
- Clean the charging contacts regularly to ensure efficient charging.

### Water Resistance

While the smartwatch is designed for daily use and may withstand splashes, it is not recommended for swimming or showering unless explicitly stated otherwise in the product specifications. Avoid exposing the watch to hot water or steam.

### Battery Care

- Avoid fully discharging the battery frequently.
- Store the watch in a cool, dry place if not used for extended periods.
- Use only the provided or recommended charging cable.

## TROUBLESHOOTING

Problem	Possible Solution
Watch does not power on.	Ensure the watch is fully charged. Connect to the charger for at least 30 minutes.
Cannot pair with smartphone.	<ul style="list-style-type: none"><li>• Ensure Bluetooth is enabled on your phone and watch.</li><li>• Restart both the watch and the phone.</li><li>• Make sure the watch is within Bluetooth range.</li><li>• Check if the correct companion app is installed and updated.</li></ul>
Notifications are not received.	<ul style="list-style-type: none"><li>• Verify notification permissions are granted to the companion app on your phone.</li><li>• Ensure the watch is connected via Bluetooth.</li><li>• Check the app's settings for notification preferences.</li></ul>
Screen is unresponsive.	Restart the smartwatch by long-pressing the side button. If the issue persists, ensure the screen is clean and dry.

## SPECIFICATIONS

Feature	Detail
Model Number	HW3
Brand	Generic
Screen Size	1.52 Inches (Round)
Connectivity	Bluetooth
Special Features	NFC, Bluetooth Call, 90+ Sport Modes, Fitness Tracking, GPS Via Smartphone
Item Weight	10.6 ounces
Dimensions	3.94 x 3.94 x 3.94 inches (Package)
Target Audience	Men
Color	Black

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Specific warranty terms may vary by region and seller.

For further assistance, please visit the manufacturer's website or contact their customer service department. Keep your purchase receipt as proof of purchase.

