

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BODEGA](#) /

› [BODEGACOOLER Wine and Beverage Refrigerator User Manual](#)

BODEGA JC-170DR-FD

BODEGACOOLER Wine and Beverage Refrigerator User Manual

Model: JC-170DR-FD

[Introduction](#)

[Safety Information](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Warranty &](#)

[Support](#)

[Specifications](#)

1. INTRODUCTION

Thank you for choosing the BODEGACOOLER Wine and Beverage Refrigerator. This appliance is designed to provide optimal storage conditions for both your wine collection and various beverages, featuring independent dual-zone temperature control and a versatile design for built-in or freestanding installation.

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new refrigerator. Please read it thoroughly before use and retain it for future reference.



Figure 1: Front view of the BODEGACOOLER Wine and Beverage Refrigerator, showcasing its dual doors and sleek stainless steel finish.

2. SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not allow children to climb, stand, or hang on the shelves or doors of the refrigerator.
- Do not clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Ensure the appliance is properly grounded.
- Unplug the appliance before cleaning or making any repairs.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

- Do not damage the refrigerant circuit.
- This appliance uses R600a refrigerant, which is flammable. Handle with care.
- The appliance is equipped with a lock and keys. Keep keys out of reach of children.

3. SETUP AND INSTALLATION

Your BODEGACOOLER is designed for both under-counter built-in installation and freestanding use. Proper installation is crucial for optimal performance and longevity.

3.1 Unpacking

- Remove all packaging materials, including the foam base and adhesive tape.
- Inspect the appliance for any damage. Report any damage to your dealer immediately.
- Allow the appliance to stand upright for at least 24 hours before plugging it in. This allows the refrigerant fluids to settle.

3.2 Location Requirements

- Place the refrigerator on a flat, solid surface strong enough to support it when fully loaded.
- Avoid placing the appliance in direct sunlight or near heat sources (e.g., stoves, heaters, radiators).
- Ensure adequate ventilation. For freestanding installation, allow at least 2 inches of space on the sides and back. For built-in installation, ensure the front ventilation grilles are unobstructed.
- The unit measures 29.7"W x 34.2"H x 22.8"D. Ensure your space accommodates these dimensions.

WINE AND BEVERAGE COOLER 2 IN 1 EITHER WAY TO INSTALL, YOUR CHOICE.



Figure 2: Illustration of the refrigerator's versatility, showing both built-in under-counter and freestanding placement options.



Figure 3: The refrigerator seamlessly integrated as a built-in unit under a kitchen counter, demonstrating its compact design.



Figure 4: The refrigerator positioned as a freestanding unit in a kitchen setting, highlighting its portability and flexible placement.

3.3 Leveling the Appliance

- Adjust the leveling legs at the bottom of the appliance to ensure it is perfectly level. This is important for proper door alignment and efficient cooling.



Figure 5: Detail of the adjustable leveling feet, which can be rotated to ensure the refrigerator is stable and level on any surface.

3.4 Electrical Connection

- Plug the appliance into a dedicated, grounded 115 Volt AC, 60 Hz electrical outlet. Do not use extension cords or adapter plugs.

4. OPERATING INSTRUCTIONS

Your BODEGACOOLER features independent dual-zone temperature control, allowing you to store wines and beverages at their ideal temperatures.

4.1 Control Panel

The intuitive LED touchscreen control panel is located at the top of the interior for easy access and temperature adjustment.



Figure 6: Detailed view of the LED touchscreen control panel, showing temperature display and control buttons.



Figure 7: The wine zone interior with its blue LED lighting and the accessible control panel above the bottles.

4.2 Temperature Settings

- **Wine Zone (Left):** Temperature range from 41°F to 68°F (5°C to 20°C). Use the '+' and '-' buttons to adjust.
- **Beverage Zone (Right):** Temperature range from 35.6°F to 50°F (2°C to 10°C). Use the '+' and '-' buttons to adjust.
- Press the °C/°F button to switch between Celsius and Fahrenheit display.



Figure 8: Visual representation of the dual temperature zones, showing the optimal temperature ranges for wine (41-68°F) and beverages (35.6-50°F).

4.3 Interior Lighting

- Press the light bulb icon on the control panel to turn the interior LED lighting on or off.



Figure 9: The beverage zone interior illuminated by LED lights, making contents easily visible.

4.4 Shelving and Capacity

- The wine zone features 9 adjustable beech shelves, accommodating up to 31 standard 750ml bottles.
- The beverage zone can hold up to 92 standard 12oz cans.
- Shelves are removable to adjust for different bottle or can sizes.

LARGE CAPACITY ADJUSTABLE SHELVES



Figure 10: The refrigerator's interior, demonstrating its large capacity for both wine bottles (31) and beverage cans (100), with adjustable shelves for flexible storage.

4.5 Door Lock

- The appliance includes a lock and keys for securing contents. Insert the key into the lock located at the bottom of the door and turn to lock or unlock.



Figure 11: Detail of the sturdy stainless steel door handles and the integrated lock mechanism at the base of the door.

5. MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your BODEGACOOLER.

5.1 Cleaning the Interior

- Always unplug the appliance before cleaning.
- Wash the interior surfaces and removable shelves with a mild detergent and warm water solution.
- Wipe dry thoroughly with a soft cloth.
- Do not use abrasive cleaners or solvents.

5.2 Cleaning the Exterior

- Clean the exterior with a soft cloth and a mild, non-abrasive cleaner.
- For stainless steel surfaces, use a stainless steel cleaner and polish.

5.3 Activated Carbon Filtration System

- The built-in activated charcoal filtration system helps eliminate odors. Replace the filter periodically as recommended by the manufacturer (refer to product packaging or BODEGA support for replacement intervals).

DIFFERENT DOOR BUT SAME SEALESS FOR COOLING




Figure 12: Depiction of the wine zone's 2-layer glass door for insulation and display, the beverage zone's foaming door for superior insulation, and the activated carbon filter for odor elimination.

5.4 Power Outage

- In case of a power outage, keep the refrigerator doors closed to maintain internal temperature for as long as possible.

6. TROUBLESHOOTING

Before contacting customer service, review this section for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Temperature is not cold enough.	Door not closed properly; excessive door openings; warm items added; poor ventilation; direct sunlight.	Check door seal; reduce door openings; allow new items to cool; ensure proper clearance; relocate appliance.

Problem	Possible Cause	Solution
Appliance is noisy.	Appliance not level; vibrating against wall/cabinet; normal compressor operation.	Adjust leveling legs; move appliance away from contact points; normal operation includes slight hum.
Vibration.	Appliance not level.	Adjust leveling legs.
Moisture buildup on interior.	High humidity; frequent door openings.	Ensure door is sealed; reduce door openings.

If the problem persists after checking the above, please contact BODEGA customer support.

Your browser does not support the video tag.

Video: A detailed overview of the BODEGACOOLER Dual Zone Wine Cooler, demonstrating its features, capacity, and touch control panel. This video highlights the product's design and functionality, including the safety locks.

7. SPECIFICATIONS

Feature	Detail
Brand	BODEGA
Model Number	JC-170DR-FD
Dimensions (D x W x H)	22.8" x 29.7" x 34.2"
Item Weight	141.9 pounds
Capacity	175 Liters (approx. 6 cubic feet)
Wine Bottle Capacity	31 standard 750ml bottles
Beverage Can Capacity	92 standard 12oz cans
Installation Type	Under-Counter/Built-in/Freestanding
Wine Zone Temperature Range	41°F - 68°F (5°C - 20°C)
Beverage Zone Temperature Range	35.6°F - 50°F (2°C - 10°C)
Voltage	115 Volts
Wattage	95.00 W
Number of Shelves	9 (Wood)
Defrost System	Automatic
Special Features	Easy to Install, Quiet (42 dB), Lockable, Adjustable Shelves, Activated Carbon Filter
Door Material Type	Stainless Steel/Glass (Wine Zone), Foaming (Beverage Zone)

SPECIFICATION

Model	JC-175DR-2
Body dimension	W30"x D22.6"x H34"
Certificate	ETL, DOE
Capacity	175L hold 31 bottles wine+100 cans drinks
Net weight	148 lbs/67 kgs



Figure 13: A visual summary of the product's key specifications, including model number, dimensions, capacity, and certifications.

8. WARRANTY AND CUSTOMER SUPPORT

BODEGA is committed to providing high-quality refrigeration products and excellent customer service.

- **Product Support:** We offer 12 months of product support from the date of purchase.
- **Contact Us:** If you have any questions before or after purchase, or encounter any issues with your appliance, please feel free to contact our professional technical and customer service team. Refer to your purchase documentation or the BODEGA website for contact details.

