

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [oneisall](#) /

› [oneisall RFC-676+P20 Dog Grooming Kit Instruction Manual](#)

oneisall RFC-676+P20

oneisall RFC-676+P20 Dog Grooming Kit Instruction Manual

Model: RFC-676+P20 | Brand: oneisall

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your oneisall Dog Grooming Kit. Designed for grooming pets with heavy and thick hair, this kit includes a powerful cordless clipper and a specialized paw trimmer, both featuring low-noise operation and waterproof design for a stress-free grooming experience.

SAFETY INFORMATION

- Use with caution to avoid skin irritation and eye injury to your pet.
- Keep the device away from water sources when charging or in use.
- Ensure the device is fully charged before use to maintain optimal performance.
- Always use the appropriate guide comb for the desired hair length to prevent accidental cuts.
- Do not attempt to disassemble the product for maintenance beyond recommended cleaning procedures.
- Keep out of reach of children and pets when not in use.

PACKAGE CONTENTS

Your oneisall Dog Grooming Kit includes the following items:

- oneisall Cordless Dog Clipper (Main Unit)
- oneisall Pet Paw Trimmer (Smaller Unit)
- Guide Combs (Various Sizes: 3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm)
- Charging Cables (for both main clipper and paw trimmer)
- Stainless Steel Comb
- Grooming Scissors
- Cleaning Brush
- Lubricating Oil
- User Manuals



Figure 1: Complete oneisall Dog Grooming Kit contents.

SETUP

1. Charging the Clippers

Before first use, fully charge both the main dog clipper and the paw trimmer. The main clipper features an LED display indicating battery percentage, while the paw trimmer uses LED indicator lights.

- Connect the appropriate charging cable to each device and a suitable power source.

- The main clipper's LED display will show charging progress. The paw trimmer's indicator lights will illuminate.
- Once fully charged, disconnect the devices from the power source.



Figure 2: Main clipper LED display showing battery level.

2. Attaching Guide Combs

Select the desired guide comb based on the hair length you wish to achieve. The kit includes various sizes for different grooming needs.

- Align the chosen guide comb with the clipper blade.

- Gently push the comb onto the blade until it clicks securely into place.
- To remove, gently lift the comb from the back and slide it off.



Figure 3: Detachable guide combs for precise hair length control.

OPERATING INSTRUCTIONS

1. General Grooming Steps

1. **Prepare Your Pet:** Bathe and thoroughly dry your pet. Brush their fur to remove any tangles or mats before clipping.
2. **Select Comb:** Attach the appropriate guide comb to the main clipper. For very thick or matted hair, consider using grooming scissors to pre-trim longer sections.
3. **Power On:** Press the power button on the clipper. The main clipper has a security lock feature; long-press the power button to activate/deactivate it.
4. **Clipping:** Hold the clipper firmly and move it gently against the direction of hair growth. Use smooth, even strokes. Avoid pressing too hard against the skin.
5. **Sensitive Areas:** Use the smaller paw trimmer for delicate areas such as paws, ears, and around the face. This trimmer also comes with interchangeable heads for different precision needs.
6. **Check Progress:** Regularly check the hair length and adjust the comb or technique as needed.

Keep Your Pet **Calm**



Figure 4: Demonstrating the main clipper in use on a dog.

With 2 Cutter Head Ideal for Shaving Smaller Areas



Figure 5: The paw trimmer is ideal for sensitive and smaller areas.

2. Security Lock Feature

The main clipper is equipped with a security lock to prevent accidental activation, especially useful during storage or travel. To activate or deactivate the lock, long-press the power button for 3 seconds. A lock icon will appear or disappear on the LED display.

5,882,662 Customers Choose Us

Avg. Annual Social Media Exposure
220 Million+



Number of Followers
70K+

Video Sharing
56 Million+



Countries Sold
26+

Video Likes
12 Million+



Collaborating Celebrities
70K+



Figure 6: The security lock prevents unintended operation.

3. Low Noise Operation

Both clippers operate at a low noise level (below 55dB), designed to keep pets calm and reduce anxiety during grooming sessions.

How to Maintain the Blade?

Tips: Please don't disassemble the product.



Clean the Hair with a Brush



Rinse under the Faucet



Wipe Clean



Dripping oil

Figure 7: Low noise design ensures a calm grooming environment.

MAINTENANCE

1. Cleaning the Blades

The oneisall grooming kit features an IPX7 waterproof design, allowing for easy cleaning under running water. Regular cleaning is crucial for maintaining blade sharpness and hygiene.

- Brush Off Hair:** After each use, use the provided cleaning brush to remove any loose hair from the blades.
- Rinse:** Rinse the blades under running water. Ensure the entire device is dry before storage or next use.
- Wipe Dry:** Use a soft cloth to thoroughly wipe the blades and clipper body dry.
- Oil Blades:** Apply a few drops of the lubricating oil to the blades. This helps maintain sharpness and prevents rust.

Great for All Small Medium Large Dogs



Figure 8: Step-by-step guide for blade maintenance.

2. Storage

Store the clippers and all accessories in a dry, cool place, away from direct sunlight and moisture. Ensure the security lock is activated on the main clipper before storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper not turning on.	Low battery; Security lock activated.	Charge the clipper fully. Deactivate the security lock by long-pressing the power button.
Hair pulling or uneven cut.	Blades are dull or clogged; Incorrect comb size; Hair is matted or tangled.	Clean and oil the blades. Use a smaller comb or pre-trim matted areas with scissors. Ensure hair is clean and dry.
Clipper gets hot during use.	Prolonged use; Blades need lubrication.	Allow the clipper to cool down. Apply lubricating oil to the blades.

SPECIFICATIONS

Feature	Detail
Model Number	RFC-676+P20
Brand	oneisall
Main Clipper Battery	2000mAh Lithium Polymer (approx. 240 min operating time)
Paw Trimmer Battery	800mAh Lithium Polymer
Motor Speed	6800 rpm (main clipper)
Noise Level	< 55dB
Waterproof Rating	IPX7 (Whole Body Washable)
Blade Material	Stainless Steel

Feature	Detail
Item Weight	0.82 Kilograms (approx. 1.8 pounds)
Dimensions	9 x 7 x 2.3 inches

WARRANTY AND SUPPORT

The oneisall Dog Grooming Kit comes with a **2-Year Manufacturer Warranty**. For any questions, concerns, or support needs, please contact oneisall customer service. They offer 24/7 support to assist you.

For more information or to contact support, please visit the official oneisall store or refer to the contact details provided in your product packaging.



Figure 9: oneisall customer support information.

OFFICIAL PRODUCT VIDEOS

oneisall Dog Grooming Kit for Heavy Thick Hair&Coats/

Your browser does not support the video tag.


This video provides an overview of the oneisall Dog Grooming Kit, highlighting its features and components for grooming pets with thick hair.


Product features of oneisall Dog Grooming Kit

Your browser does not support the video tag.

A detailed look at the key features and functionalities of the oneisall Dog Grooming Kit, including its low noise and waterproof design.

Related Documents - RFC-676+P20

	<p>Oneisall DTJ-001 Professional Pet Grooming Clippers User Manual</p> <p>Comprehensive user manual for the Oneisall DTJ-001 cordless pet grooming clippers. Learn about features, charging, operation, cleaning, maintenance, safety, and troubleshooting for professional pet grooming at home.</p>
---	---

 <p>Dog Clippers Model RFC-676</p> <p>If you have any questions, you can contact us: support@oneisall.com</p>	<p><u>Oneisall RFC-676 Dog Clippers User Manual and Safety Guide</u></p> <p>Comprehensive guide for the Oneisall RFC-676 Dog Clippers, covering safety instructions, product overview, usage methods, maintenance, charging, troubleshooting, and warranty information.</p>
	<p><u>Oneisall Professional Pet Clippers RFC-676 User Manual</u></p> <p>Comprehensive user manual for the Oneisall Professional Pet Clippers, Model RFC-676. Learn about features, usage, maintenance, and troubleshooting for optimal pet grooming.</p>
 <p>Pet Clippers and Paw Trimmer Model X2/C61</p> <p>Any problems you have, please contact us: support@oneisall.com</p>	<p><u>Oneisall X2/C61 Pet Clippers and Paw Trimmer User Manual & Guide</u></p> <p>Comprehensive guide for the Oneisall X2/C61 Pet Clippers and Paw Trimmer, covering safety instructions, parts identification, specifications, usage, cleaning, maintenance, and troubleshooting. Learn how to groom your pets safely and effectively.</p>
	<p><u>oneisall Pet Paw Clipper C61 User Manual and Safety Guide</u></p> <p>Comprehensive guide for the oneisall Pet Paw Clipper C61, covering safety instructions, usage, cleaning, and product information. Learn how to use and maintain your pet grooming tool.</p>
 <p>Metal Dog Clippers for Thick Coats Operation Manual</p> <p>ON-G-HD20</p>	<p><u>Oneisall K52NTS Cordless Metal Dog Clippers for Thick Coats - User Manual</u></p> <p>Comprehensive user manual for the Oneisall K52NTS cordless metal dog clippers. Learn about features, specifications, operation, maintenance, and safety for grooming thick-coated dogs.</p>