HCDZ B0C3LS187H

HCDZ Replacement Remote Control Instruction Manual

Model: B0C3LS187H

Product Overview

This manual provides instructions for the HCDZ Replacement Remote Control, designed for use with various Perfect Aire portable air conditioner models. This remote is an infrared (IR) replacement and requires no programming.
Compatible Perfect Aire Models: 2PAMSDH09, 2PAMSDH12, 2PAMSDH18, 2PAMSDH24, 2PAMSHQC12, 2PAMSHQC18, 2PAMSHQC24, 2PAMSHQC36, 2PAMSHQC18-16.



Figure 1: Front view of the HCDZ Replacement Remote Control, displaying its buttons and LCD screen.

Setup

The remote control requires two AAA batteries (not included). No programming is needed; the remote will function immediately after battery installation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new AAA batteries, ensuring correct polarity (+ and -).
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery cover removed, showing the two AAA battery slots.



Figure 3: Back view of the remote control with the battery cover installed.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

- **ON/OFF:** Press to power the air conditioner on or off.
- **MODE:** Press to cycle through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲ / ▼:** Press to increase or decrease the set temperature.
- **FAN:** Press to adjust the fan speed.
- **TIMER ON:** Press to set a timer for the unit to turn on.
- **TIMER OFF:** Press to set a timer for the unit to turn off.
- **SLEEP:** Activates or deactivates sleep mode for energy-efficient operation during sleep.
- **SWING:** Controls the louver swing function.
- **DIRECT:** Adjusts the louver direction.
- **TURBO:** Activates or deactivates rapid cooling/heating.
- **LED:** Turns the display light on the air conditioner unit on or off.
- **SHORT CUT:** (Function may vary by air conditioner model) Typically recalls a favorite setting.

Switching Between Celsius and Fahrenheit

To switch the temperature display between Celsius (°C) and Fahrenheit (°F), press the**TEMP ▲** and **TEMP ▼** buttons simultaneously.

Maintenance

- **Storage:** Do not leave the remote control in areas with extremely high temperatures or high humidity.
- **Battery Replacement:** When replacing batteries, always use two new AAA batteries. Do not mix new batteries with old ones.
- **Long-Term Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent potential damage from battery leakage and corrosion.

Troubleshooting

- **Remote Not Responding:**
  - Ensure new AAA batteries are correctly installed.
  - Check if the remote control is pointed directly at the air conditioner's infrared receiver.
  - Verify there are no obstructions between the remote and the air conditioner.
- **Interference:** Do not expose the remote control's sensor to direct sunlight or strong lighting apparatuses, as this may cause a malfunction.

Specifications

Brand	HCDZ
Model Number	B0C3LS187H
Connectivity Technology	Infrared (IR)
Compatible Devices	Perfect Aire Air Conditioners (models listed in Product Overview)

Batteries Required	2 x AAA (not included)
Programming	Not required

Warranty and Support

Specific warranty information for this replacement remote control is not provided in the product details. For support or further inquiries, please refer to the seller or the original product documentation of your Perfect Aire air conditioner.

© 2023 HCDZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question