

[Manuals.plus](#) /

› [Feikeer](#) /

› Feikeer RMF-TX520U Remote Control User Manual for Sony Smart & Bravia TVs

Feikeer RMF-TX520U

Feikeer RMF-TX520U Remote Control User Manual

Model: RMF-TX520U

Brand: Feikeer

1. INTRODUCTION

This manual provides detailed instructions for the Feikeer RMF-TX520U replacement remote control, designed for Sony Smart TVs. It covers essential information regarding compatibility, setup, operation, and troubleshooting to ensure optimal use of your new remote.



Image 1.1: The Feikeer RMF-TX520U remote control, highlighting its voice control and dedicated hotkey buttons.

2. COMPATIBILITY

The RMF-TX520U remote is specifically designed for Sony Smart TVs with voice command capabilities, manufactured between 2019 and 2023. It is compatible with various Sony BRAVIA XBR, XR, and KD series models. Please note that this remote is generally not suitable for TVs manufactured before 2018 and cannot control external TV boxes.

Compatible Sony TV Series and Models:



RMF-TX520U remote for
All Sony TVs that support Voice control

SONY XR Series 8K/4K HD LED OLED TVs

SONY Bravia XBR Series 4K Ultra HD Smart TV

SONY KD Series Full Array LED TVs

All other SONY Google/Android TVs from 2019-2023 support voice control

Image 2.1: The RMF-TX520U remote is compatible with various Sony TV series that support voice control.

This remote supports models including, but not limited to:

- **KD Series:** KD-43X80J, KD-43X85J, KD-50X80J, KD-55X80CJ, KD-65X79J, KD-75X81J, KD-85X91J, and other KD series models from 2019-2023.
- **XR Series:** XR-50X90J, XR-50X94J, XR-55A80J, XR-55A84J, XR-55A90J, and other XR series models from 2019-2023.
- **XBR Series:** Compatible XBR series models from 2019-2023.

Compatible with the following TV models

KD Series

43in

KD-43X80J
KD-43X85J
KD43X80J
KD43X85J

50in

KD-50X80J
KD-50X85J
KD50X80J
KD50X85J

55in

KD-55X79J
KD-55X80CJ
KD-55X80J
KD55X80J
KD55X85J
KD-55X85J
KD55X79J
KD55X80CJ

65in

KD-65X79J
KD-65X80CJ
KD-65X80J
KD-65X85J
KD65X79J
KD65X80CJ
KD65X80J
KD65X85J

75in

KD-75X79J
KD-75X80CJ
KD-75X80J
KD-75X81J
KD-75X85J
KD75X79J

85in

KD-85X85J
KD85X85J
KD85X91J

XR Series

50in

XR-50X90J
XR-50X94J
XR50X90J
XR50X94J

55in

XR-55A80J
XR-55A84J
XR-55A90J
XR-55X90J
XR-55X94J
XR55A80J
XR55A84J
XR55A90J
XR55X90J
XR55X94J

65in

XR-65A80CJ
XR-65A80J
XR-65A84J
XR-65A90J
XR-65X90J
XR-65X94J
XR-65X95J
XR65A80CJ
XR65A80J
XR65A84J
XR65A90J
XR65X90J
XR65X94J
XR65X95J

75in

XR-75X90J
XR-75X94J
XR-75X95J
XR-75Z9J
XR75X90J
XR75X94J
XR75X95J
XR75Z9J

77in

XR-77A80CJ
XR-77A80J
XR-77A84J
XR77A84J
XR77A80J

83in

XR-83A90J
XR83A90J

85in

XR-85X95J
XR-85Z9J
XR85X95J

XBR Series

**For more models
press Ctrl+F**

Image 2.2: A comprehensive list of compatible Sony TV models.

3. SETUP AND PAIRING

The RMF-TX520U remote is designed for easy and fast pairing with your Sony Smart TV. Follow these steps for initial setup:

- Step 1: Power On TV.** Press the **Power** button on the remote to turn on your Sony TV.
- Step 2: Initiate Pairing.** Once the TV is on, simultaneously press and hold the **VOL(-)** button and the **Google Assistant** button (voice button) for 2 seconds. The remote will begin the pairing process with your Sony Smart TV.
- Step 3: Wait for Connection.** No further operation is required. Simply wait patiently for approximately two minutes for the remote to establish a connection with your TV.

Remote control and TV pairing steps

Controlling your TV



Step 1

Press the **power button** to turn on the TV.



Step 2

Press and hold the **[VOL(-)] key** and **[Google Assistant]** key for **2 seconds** to initiate pairing with your TV. Pair with the TV.



Step 3

Just wait patiently for **two minutes**, no other operations required.



Image 3.1: Visual guide for the remote control and TV pairing steps.

If you encounter any difficulties during the matching process, refer to the Troubleshooting section or contact customer support.

4. OPERATING INSTRUCTIONS

The RMF-TX520U remote offers intuitive controls and advanced features for an enhanced viewing experience.

4.1 Basic Functions

- **Power Button:** Turns the TV on or off.
- **Navigation Pad:** Use the directional arrows to navigate menus and select options. The central button confirms selections.
- **Volume Control (VOL +/-):** Adjusts the TV volume.
- **Channel Control (CH +/-):** Changes TV channels.
- **Mute:** Mutes or unmutes the TV audio.
- **Back:** Returns to the previous screen or menu.

- **Home:** Accesses the TV's home screen or smart hub.
- **Input:** Changes the input source (HDMI, AV, etc.).

4.2 Voice Control

The remote features a dedicated Google Assistant button for voice commands. Press and hold the [Google Assistant](#) button and speak into the remote's microphone to:

- Search for programs or movies.
- Play music.
- Ask for weather updates.
- Control smart home devices (if configured).


4.3 Hotkeys

Quickly access popular streaming services with the dedicated hotkey buttons:

- **Netflix**
- **Disney+**
- **Prime Video**
- **YouTube**



Hotkey to the most popular streaming channels



*How is the weather?
Open YouTube
Find Super Bowl 7 video clips
Open NETFLIX
play Extraction 2*

Image 4.1: Hotkeys provide direct access to popular streaming channels, and voice control allows for quick searches and commands.

5. TROUBLESHOOTING

If you experience issues with your RMF-TX520U remote, consider the following common solutions:

- **Remote Not Responding:**

- Ensure batteries are correctly inserted and have sufficient charge. Replace batteries if necessary.
- Verify there are no obstructions between the remote and the TV's infrared receiver.

- **Pairing Failure:**

- Repeat the pairing steps (Section 3). Ensure you hold the **VOL(-)** and **Google Assistant** buttons simultaneously for the required 2 seconds.
- Ensure your TV is a compatible model (Section 2) and supports voice control.
- Try restarting your TV by unplugging it from the power outlet for a few minutes, then plugging it back in and attempting pairing again.

- **Voice Control Not Working:**

- Ensure the remote is successfully paired via Bluetooth, as voice control typically relies on Bluetooth connectivity.
- Speak clearly and directly into the remote's microphone.
- Check your TV's settings to ensure voice control features are enabled.

• **Slow Response:**

- Ensure the remote is properly paired. Some users report improved responsiveness after pairing the remote through the TV's settings, rather than just using it out of the box.
- Check for any potential interference from other electronic devices.

6. SPECIFICATIONS

Model Number	RMF-TX520U
Brand	Feikeer
Connectivity Technology	Infrared (IR) and Bluetooth (for voice control)
Compatible Devices	Sony Smart TVs (2019-2023 XBR/KD/XR Series with voice control)
Item Weight	3.84 ounces
Package Dimensions	11.5 x 4.96 x 0.91 inches
Special Feature	Ergonomic design, Voice Control, Dedicated Hotkeys

7. WARRANTY AND SUPPORT

The Feikeer RMF-TX520U remote control comes with a **1-year warranty**. Feikeer is committed to customer satisfaction and product quality.

If you encounter any problems or are not satisfied with your purchase for any reason, please contact Feikeer customer support. We aim to provide a satisfactory solution within 12-24 hours.

For support, please refer to the contact information provided with your product packaging or visit the official Feikeer store on Amazon.