

AIRTHEREAL VacTide V2

AIRTHEREAL VacTide V2 Cordless Wet Dry Vacuum Cleaner Instruction Manual

Model: VacTide V2

1. INTRODUCTION

Thank you for choosing the AIRTHEREAL VacTide V2 Cordless Wet Dry Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance, including the following:

- Read all instructions before using the appliance.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not immerse the appliance in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters in place.
- Exercise extra care when cleaning on stairs.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only the charging adapter supplied by the manufacturer.

3. PACKAGE CONTENTS

Ensure all items are present upon unpacking:

- AIRTHEREAL VacTide V2 Wet Dry Vacuum Cleaner
- Rolling Brush
- Cleaning Brush
- Cleaning Fluid
- HEPA Filter
- HEPA Filter Storage Base
- Rolling Brush Storage Base
- Charging Base




Brush Cleaning with Air Drying

The combination of spin-drying and hot air drying ensures thorough self-cleaning of the roller brush.

Figure 3.1: Overview of the AIRTHEREAL VacTide V2 and its included accessories.

4. PRODUCT OVERVIEW

The VacTide V2 features a smart digital display and separate tanks for clean and dirty water, ensuring efficient cleaning.



Innovative Mess Detection

Infrared detection adjusts cleaning settings for every mess

Figure 4.1: The touchable LED control panel provides real-time status and cleaning controls.

Smart Digital Display

Easy to read



Seperate Water Tank

Keep wet & dry debris separate



600ml
Dirty Water Tank

700ml
Clean Water Tank

Figure 4.2: The smart digital display and separate 700ml clean water tank and 600ml dirty water tank.

5. SETUP

5.1 Assembly

Follow the instructions in the quick start guide or product packaging to assemble the main unit, handle, and brush head.

5.2 Charging

Place the main unit onto the charging base. The digital display will indicate charging status. A full charge takes approximately 240 minutes and provides up to 40 minutes of runtime.

5.3 Filling the Clean Water Tank

Remove the clean water tank. Fill it with clean water and add 12ml (approximately two bottle caps) of floor cleaning solution for deep cleaning. Ensure the tank is securely reattached.

6. OPERATING THE VACUUM CLEANER

The VacTide V2 is designed for efficient cleaning on various hard floor types.

6.1 Power On/Off and Mode Selection

Press the power button to turn the unit on. Use the mode selection button on the handle or the touchable LED control panel to switch between cleaning modes:

- **Auto Mode:** Automatically adjusts suction and water flow based on detected mess.
- **Max Mode:** Provides maximum suction for stubborn stains and heavy debris.
- **Water Suction Mode:** Swiftly removes standing water and wet spots. This mode transitions to auto mode after approximately 15 seconds.

Water Suction Mode

Swiftly completes tasks in 15 seconds,
seamlessly transitioning to auto mode



Figure 6.1: The VacTide V2 vacuums and mops simultaneously, saving cleaning time.

Touchable LED Control Panel

Interactive control panel for easy and intuitive operation.



Auto Mode

Figure 6.2: Water Suction Mode effectively cleans up liquid spills.

6.2 Cleaning Process

- The close-to-floor brush design increases friction for high-performance cleaning on hard floors like hardwood, laminate, linoleum, tile, vinyl, and marble.
- The self-propelling system assists movement, reducing effort during cleaning.
- Innovative infrared detection adjusts cleaning settings for different types of messes.
- The unit stops working when placed in an upright position.



Figure 6.3: Innovative mess detection automatically adjusts cleaning power.

6.3 Voice Assistant and Mute Mode

The smart digital display includes a helpful voice assistant that provides real-time status and warnings. The voice assistant can be muted via the options on the control panel.

Mute Mode

Silence all voice prompts



Cleaning Solution

Low-foaming formulation



Figure 6.4: Activate Mute Mode to silence voice prompts. Use low-foaming cleaning solution.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your VacTide V2.

7.1 Self-Cleaning and Auto-Dry Function

After each use, place the main unit back onto the charging base. The roller brush will automatically start a self-cleaning cycle and air-dry itself with one touch, eliminating manual washing.

Powerful Motor to Handle the Toughest Messes

12000 pa
Suction

550 RPM
Brush Speed




Figure 7.1: The self-cleaning function combines spin-drying and hot air drying for thorough roller brush cleaning.

Hand-Free Self Cleaning

No manual washing required for the roller brush. It utilizes spin cleaning and hot air drying for hassle-free maintenance.



Spin Cleaning



Hot Air Drying



Figure 7.2: Hand-free self-cleaning with spin cleaning and hot air drying for hassle-free maintenance.

7.2 Emptying the Dirty Water Tank

It is recommended to empty the dirty water tank after every use to prevent odors and ensure proper function.

7.3 HEPA Filter Care

The HEPA filter is washable. Clean it regularly and ensure it is thoroughly dried before reinstallation. Replace with a spare filter if necessary.

8. TROUBLESHOOTING

If you encounter issues with your VacTide V2, refer to the following common solutions:

8.1 "Dirty Water Tank is Full" Prompt


If the device repeatedly prompts you to empty the dirty water tank, even if it appears not full, perform the following steps:

- 1. Clean the dirty water tank thoroughly.
- 2. Remove the dirty water tank and check the tank pipe for any debris or blockages.
- 3. Disassemble the roller brush and check if it is blocked by any garbage or hair.
- 4. Ensure the HEPA filter is thoroughly dried or replaced with a spare one.

When prompted that the Dirty Water Tank is full:



Clean the dirty water tank.



Remove the dirty water tank and check the tank pipe for debris



Disassemble the roller brush and check if the roller brush is blocked by garbage.

Figure 8.1: Steps to resolve the 'Dirty Water Tank is Full' alert.

9. SPECIFICATIONS

Feature	Specification
Brand	AIRTHEREAL

Feature	Specification
Model Name	VacTide V2
Special Feature	Cordless, HEPA, Portable, Washable Filter, Wet/Dry
Filter Type	HEPA Filter
Surface Recommendation	Hard Floor (Hardwood, Marble floor, Tile Floor)
Power Source	Battery Powered (Lithium-Ion)
Capacity (Dirty Water Tank)	0.6 Liters
Maximum Suction	35.4 Inches
Color	Blue
Noise Level	80 Decibels
Motor Horsepower	0.268 horsepower
Number of Speeds	2
Voltage	120 Volts
Wattage	200 watts
Amperage	1.67 Amps
Battery Charge Time	240 minutes
Runtime	40 minutes
Item Weight	10 Pounds
Item Dimensions L x W x H	12"L x 11.2"W x 48"H
Control Method	Touch, Push Button
Form Factor	Upright
UPC	816621025625

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official AIRTHEREAL website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question