

[Manuals.plus](#) /

› [KIZJORYA](#) /

› KIZJORYA Space Train Track Set Model 7508 Instruction Manual

KIZJORYA 7508

KIZJORYA Space Train Track Set Model 7508 Instruction Manual

Model: 7508 | Brand: KIZJORYA

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your KIZJORYA Space Train Track Set, Model 7508. Please read this manual thoroughly before use to ensure safe and optimal performance of the product. This set is designed to inspire curiosity in space exploration and develop fine motor skills through interactive play.

SAFETY INFORMATION

WARNING:

- Not suitable for children under 3 years old due to small parts which may present a choking hazard.
- Adult supervision is recommended during assembly and play.
- Ensure all track pieces are securely connected before operating the space car.
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries from the space car if it will not be used for an extended period.

PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- Space Track pieces (176 pieces)
- Space Tunnel (1 piece)
- Tower (1 piece)
- Star Projector (1 piece)
- Space Gate (1 piece)

- Space Station (1 piece)
- Signal Receiver (1 piece)
- Astronaut Doll (2 pieces)
- Space Car (1 piece)
- Crossbar (4 pieces)
- Y-Shaped Track (1 piece)
- Bridge (4 pieces)
- 360° Loop (1 piece)
- Batteries: 3 LR44 batteries (included for the space car)



Image: All components included in the KIZJORYA Space Train Track Set.

SETUP INSTRUCTIONS

1. **Unpack Components:** Carefully remove all track pieces, the space car, and accessories from the packaging.

2. **Install Batteries in Space Car:** Locate the battery compartment on the underside of the space car. Using a small screwdriver (not included), open the compartment and insert 3 LR44 batteries, ensuring correct polarity (+/-). Close the compartment securely.
3. **Assemble Track Pieces:** The track pieces are flexible and can be connected in various configurations.
 - Connect the straight and curved track pieces by aligning the connectors and pressing them firmly together until they click.
 - Integrate special pieces such as the Space Tunnel, Space Gate, Y-Shaped Track, and 360° Loop into your desired layout.
 - Use the Crossbars and Bridge pieces to create elevated sections and overpasses.



Image: Examples of various track combinations possible with the flexible track pieces.

4. **Position Accessories:** Place the Space Station, Tower, Star Projector, Signal Receiver, and Astronaut Dolls around the track layout as desired. The Space Station can serve as a starting or stopping point for the space car.

OPERATING INSTRUCTIONS

1. **Power On the Space Car:** Locate the power switch on the space car (usually on the bottom or side). Flip the switch

to the "ON" position. The space car's lights will illuminate.

2. **Place Car on Track:** Carefully place the space car onto the assembled track. Ensure all four wheels are properly seated within the track grooves.



Image: The space car operating on the track, showcasing its illuminated features.

3. **Observe Movement:** The space car will begin to move along the track, navigating turns, inclines, and special features like the 360° Loop. The light-up feature enhances the play experience.



Image: The space car moving uphill on a track section.



Image: The space car completing a 360-degree loop.

4. **Interactive Play:** Use the astronaut dolls and other space-themed accessories to create imaginative scenarios and enhance storytelling during play.
5. **Power Off:** When play is complete, turn off the space car using the power switch to conserve battery life.

Your browser does not support the video tag.

Video: Demonstration of the KIZJORYA Space Train Track Set in operation, showing the space car moving along the track and interacting with various elements.

MAINTENANCE

- **Cleaning:** Wipe all components with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the track set in a cool, dry place away from direct sunlight when not in use. Disassemble the track for compact storage if desired.
- **Battery Care:** Remove batteries from the space car if it will not be used for extended periods to prevent leakage.

TROUBLESHOOTING

Problem	Solution
Space car does not move.	◦ Ensure the power switch on the space car is in the "ON" position. ◦ Check if the batteries are correctly installed with the proper polarity. ◦ Replace old or depleted batteries with new LR44 batteries. ◦ Verify that the space car's wheels are properly seated on the track.
Space car stops or slows down on the track.	◦ Batteries may be low; replace them. ◦ Ensure all track connections are secure and smooth. ◦ Check for any obstructions on the track.
Track pieces do not connect securely.	◦ Ensure the connectors are aligned correctly. ◦ Apply firm, even pressure until you hear a click. ◦ Inspect track pieces for any damage or deformities.

SPECIFICATIONS

- **Model Number:** 7508
- **Brand:** KIZJORYA
- **Product Dimensions:** 0.1 x 0.1 x 0.1 inches (assembled dimensions vary based on layout)
- **Item Weight:** 3.01 pounds
- **Recommended Age:** 36 months - 12 years
- **Batteries Required:** 3 x LR44 (included for space car)
- **Material:** High-quality ABS plastic
- **Number of Pieces:** 205

WARRANTY AND SUPPORT

KIZJORYA products are manufactured with quality and safety in mind. For any questions, concerns, or support regarding your Space Train Track Set Model 7508, please contact KIZJORYA customer service. Please retain your purchase receipt for warranty claims.

For further assistance, visit the official KIZJORYA store on Amazon:[KIZJORYA Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question