



[Manuals.plus](#) /

› [Snuza](#) /

› Snuza Hero SE Baby Movement Monitor Instruction Manual

Snuza 10SUH23

Snuza Hero SE Baby Movement Monitor Instruction Manual

Brand: Snuza | Model: 10SUH23

INTRODUCTION

The Snuza Hero SE is a portable and wireless baby movement monitor designed to provide reassurance by detecting your baby's abdominal movement. It attaches directly to your baby's diaper, offering a simple and effective way to monitor movement without the need for cords, sensor pads, or Wi-Fi connections. This manual provides essential information for the safe and proper use of your Snuza Hero SE monitor.

PRODUCT OVERVIEW

The Snuza Hero SE utilizes patented direct-touch sensor technology for improved movement detection. It features an intuitive alarm system that provides alerts if no movement is detected, giving you valuable time to respond. Visual and audible indicators offer additional reassurance regarding your baby's movement status.



Image: Front view of the Snuza Hero SE monitor, highlighting its operational icons.

SETUP

1. **Power On:** Press the 'on' button located on the side of the device once. A green blinking light indicates that the monitor is active and detecting movement.
2. **Attachment:** Securely clip the Snuza Hero SE directly onto your baby's diaper. Ensure the sensor at the top of the device is in direct contact with your baby's abdomen. The monitor is designed to be worn comfortably and discreetly.
3. **Positioning:** For optimal performance, position the monitor so that the sensor maintains consistent contact with your baby's skin. It can be used with swaddles and sleepwear, ensuring the monitor remains snug against the diaper.

Safe & easy to use

Easy setup—no app connection required.

Monitors your baby's movements while they sleep.

If no movement is detected for 15 seconds, a Pre-Alert Notification with Vibration will activate.

If the period of no movement detected reaches the period of 20 seconds, an audible alarm will sound.

Portable—no cords or complicated sensor pads required.

Clips directly onto diaper.

Replaceable CR2 battery.



Image: Snuza Hero SE monitor attached to a baby's diaper, demonstrating proper placement.



Image: Close-up view of the Snuza Hero SE monitor clipped onto a baby's diaper.

OPERATING INSTRUCTIONS

Movement Monitoring

- A **green indicator light** will flash with each detected movement, providing visual confirmation that the monitor is working.
- You can activate an **optional ticking sound** by pressing the 'mode' button. This allows you to audibly confirm

movement detection, which some parents find provides additional peace of mind.

Alarm System

1. **Vibration Alert:** If the Snuzo Hero SE detects no movement for 15 seconds, it will gently vibrate to rouse your baby.
2. **Audible Alarm:** If movement is still not detected after a further 5 seconds (total of 20 seconds of no movement), an audible alarm will sound to alert you.
3. **Alarm Reset:** To turn off the audible alarm, press both side buttons simultaneously.

The Snuzo Hero^{SE} monitors your baby's slightest movements and alerts you if no movement is detected for whatever reason.



When your baby **sleeps safely**,
you can sleep **soundly**.

Image: A baby sleeping, illustrating the monitor's use during rest.

MAINTENANCE

Battery

- The Snuzo Hero SE operates on a replaceable Lithium-Ion battery.
- The battery typically lasts up to 6 months with regular use.
- A low battery indicator will alert you when the battery needs to be replaced.
- To replace the battery, open the battery compartment located on the back of the device. Insert a new CR2 battery, ensuring correct polarity.

Cleaning

- Wipe the monitor with a soft, damp cloth.
- Do not immerse the device in water or use harsh cleaning agents.

TROUBLESHOOTING

- **False Alarms:** Ensure the monitor is securely clipped to the diaper and the sensor is in firm contact with the baby's abdomen. Loose attachment or movement of the monitor itself can sometimes trigger false alarms.
- **Red Light Indication:** If the indicator light flashes red, it signifies that a vibration or audible alarm has been activated due to a lack of detected movement. Check on your baby immediately.
- **No Green Light:** If the green light is not flashing, ensure the device is turned on and properly positioned. If the issue persists, check the battery.

SPECIFICATIONS

Feature	Detail
Brand	Snuza
Model Number	10SUH23
Material	Plastic, Silicone
Color	Grey, White
Compatible Devices	No Bluetooth or WiFi
Product Dimensions	2.76"L x 1.57"W x 0.79"H
Item Weight	1.38 Ounces
Battery Life	6 months
Sensor Type	Movement
Battery Description	Lithium-Ion

WARRANTY AND SUPPORT

The Snuza Hero SE Baby Movement Monitor comes with a **Limited 12-month guarantee**. For support or warranty claims, please refer to the contact information provided with your product packaging or visit the official Snuza website.