Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WOOX R5104

WOOX R5104 Smart Power Strip with Energy Meter User Manual

Model: R5104

1. Introduction

Thank you for choosing the WOOX R5104 Smart Power Strip with Energy Meter. This device allows you to control connected appliances remotely, set schedules, and monitor energy consumption through the WOOX Home app. This manual provides essential information for the safe and efficient use of your smart power strip.

2. Safety Information

- Ensure the power strip is connected to a grounded outlet.
- Do not exceed the maximum load capacity (3600W / 16A).
- Avoid exposing the device to water, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the device yourself. Contact qualified service personnel.
- Keep out of reach of children.
- Unplug the power strip from the wall outlet before cleaning.

3. Package Contents

- WOOX R5104 Smart Power Strip
- User Manual

4. Product Overview

The WOOX R5104 Smart Power Strip features three AC outlets and four USB charging ports, along with a main power button and Wi-Fi indicator.



Image 1: WOOX R5104 Smart Power Strip. This image displays the white smart power strip with three Type F AC outlets and four USB-A ports. The packaging

- **AC Outlets (x3):** Individually controllable Type F outlets for connecting appliances.
- **USB Ports (x4):** For charging mobile devices. Total output 5V/4.2A Max.
- **Power Button/Indicator:** Controls the power strip and indicates Wi-Fi status.
- **Power Cable:** 1.8 meters in length.

5. Setup

5.1 Download the WOOX Home App

Search for "WOOX Home" in the Apple App Store or Google Play Store and download the application. Alternatively, scan the QR code provided in the product packaging (if available) to download the app.

Google Play Store

Apple App Store

5.2 Connect to Power

Plug the WOOX R5104 Smart Power Strip into a standard 230V~50Hz wall outlet. The power indicator light will turn on.

5.3 Pairing with WOOX Home App

1. Open the WOOX Home app and register or log in to your account.
2. Tap the "+" icon in the top right corner to add a new device.
3. Select "Power Strip" or "Smart Plug" from the device list.
4. Follow the on-screen instructions to put the device into pairing mode. This usually involves pressing and holding the main power button for 5-10 seconds until the indicator light blinks rapidly.
5. Enter your Wi-Fi network credentials (2.4GHz Wi-Fi only, IEEE 802.11 b/g/n).
6. Wait for the app to detect and connect to the power strip. Once connected, you can rename the device and assign it to a room.

5.4 Voice Assistant Integration

The WOOX R5104 is compatible with Amazon Alexa and Google Home. Refer to the WOOX Home app's integration guide or the respective voice assistant app for detailed setup instructions.

6. Operating the Smart Power Strip

6.1 Manual Control

Press the main power button on the power strip to manually turn all connected AC outlets on or off. The USB ports are typically always on when the power strip is powered.

6.2 App Control

Within the WOOX Home app, you can:

- **Turn On/Off:** Individually control each AC outlet.
- **Set Schedules/Timers:** Program outlets to turn on or off at specific times or after a set duration.
- **Energy Monitoring:** View real-time and historical energy consumption data for the entire power strip. This feature helps you track and manage your energy usage.
- **Automation:** Create smart scenes and automations based on conditions like time, weather, or other smart devices.

7. Maintenance

- **Cleaning:** Disconnect the power strip from the wall outlet. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight when not in use for extended periods.

8. Troubleshooting

Problem	Possible Cause	Solution
Device not powering on.	No power from wall outlet; power strip damaged.	Check wall outlet with another device; contact support if power strip is unresponsive.
Cannot connect to Wi-Fi.	Incorrect Wi-Fi password; 5GHz Wi-Fi network; device too far from router.	Ensure correct 2.4GHz Wi-Fi password; move device closer to router; reset power strip and try pairing again.
Appliance not responding to app control.	Power strip offline; appliance not properly plugged in; appliance itself is off.	Check Wi-Fi connection; ensure appliance is securely plugged into the power strip and turned on.

9. Specifications

Feature	Detail
Model	R5104
AC Outlets	3 (Type F)
USB Ports	4 (Type A)
Rated Voltage	230V~50Hz
Rated Current	16A Max
Rated Power	3600W Max
Each USB Output	5V/2.4A Max
Total USB Output	5V/4.2A Max
Wi-Fi Standard	IEEE 802.11 b/g/n 2.4GHz
Working Temperature	-10°C to 40°C
Dimensions	350 x 71 x 42 mm
Cable Length	1.8 meters
Material	Plastic
Plug Type	Type F - 2-pin (German)
Special Features	Energy Meter
Compatible Devices	Computer, TV, Refrigerator, Air Conditioning, Game Console, Fan, Hair Dryer, Coffee Machine, Freezer, Fax, etc.

10. Warranty and Support

WOOX products are designed and manufactured to the highest quality standards. For warranty information, technical support, or service inquiries, please visit the official WOOX website or contact your local retailer.
Visit WOOX Official Website

© 2023 WOOX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C3MZSJK1

More documents and user manuals: **https://manuals.plus/**