Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Dyson /
- > Dyson Zone™ Noise-Cancelling Headphones User Manual

Dyson WP01

Dyson Zone™ Noise-Cancelling Headphones User Manual

Model: WP01 | Brand: Dyson

Introduction

The Dyson Zone™ noise-cancelling headphones are engineered for realistic, detailed audio with up to 50 hours of audio playback with Active Noise Cancellation (ANC) enabled. This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Dyson Zone™ headphones.



Image: Dyson Zone™ Noise-Cancelling Headphones with their distinctive design in Ultra Blue/Prussian Blue.

WHAT'S IN THE BOX

Your Dyson Zone™ Noise-Cancelling Headphones package includes the following components:

- Protective Case
- · Visor sleeve
- · Visor cleaning brush
- Two electrostatic carbon filters
- USB-C charging cable

KEY FEATURES

- Pure Dyson audio with advanced noise cancellation.
- Intelligent signal processing combined with active noise cancellation ensuring realistic, detailed audio.

- Eight active noise-cancelling microphones monitor surrounding noise, with two additional microphones for telephony and transparency systems.
- Integrated air purification system with electrostatic carbon filters.
- Up to 50 hours audio with ANC (battery life varies with air purification usage).
- · Bluetooth 5.0 connectivity.
- Control via dedicated mobile application.

SETUP

1. Initial Charging

Before first use, fully charge your Dyson Zone™ headphones using the provided USB-C charging cable. Connect the USB-C cable to the charging port on the headphones and to a compatible USB power adapter. The charging indicator light will show the charging status.

2. Attaching the Visor

The air purification visor attaches magnetically to the earcups. Align the magnetic connectors on the visor with those on the earcups and gently bring them together until they click into place. Ensure a secure fit for optimal air purification performance.

3. Bluetooth Pairing

- 1. Ensure your headphones are charged and powered on.
- 2. Activate Bluetooth on your device (smartphone, tablet, etc.).
- 3. On your device, search for available Bluetooth devices and select "Dyson Zone" from the list.
- 4. Once connected, the headphones will indicate successful pairing.

4. Dyson Link App

Download the Dyson Link app from your device's app store. The app allows for advanced control, monitoring of air quality, and customization of audio and air purification settings.

OPERATING INSTRUCTIONS

Power On/Off

Press and hold the power button located on the earcup for 3 seconds to power the headphones on or off.

Audio Controls

- Volume: Use the dedicated volume control dial on the earcup.
- Play/Pause: Single press the multi-function button.
- Skip Track: Double press the multi-function button for next track, triple press for previous track.

Active Noise Cancellation (ANC) & Transparency Mode

Double-tap anywhere on the earcups to switch between ANC mode (for immersive audio) and Transparency mode (to hear your surroundings). ANC can also be managed via the Dyson Link app.

Air Purification System

- The air purification system activates automatically when the visor is attached and positioned correctly.
- Adjust fan speed (low, medium, high) via the Dyson Link app. Note that higher fan speeds may introduce audible noise.
- To pause air purification and noise cancellation for conversation, simply pull the visor downwards. The bottom magnetic attachments swivel to allow this.

Call Functions

- Answer/End Call: Single press the multi-function button.
- Reject Call: Press and hold the multi-function button.

MAINTENANCE

Cleaning

- Wipe the headphones and visor with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- Use the provided visor cleaning brush to gently clean the air inlets and outlets on the visor.

Filter Replacement

The electrostatic carbon filters are replaceable. The Dyson Link app will notify you when filter replacement is recommended based on usage and air quality data. To replace filters:

- 1. Gently twist and remove the outer grilles from the earcups.
- 2. Remove the old filters.
- 3. Insert new electrostatic carbon filters, ensuring they are correctly seated.
- 4. Reattach the outer grilles by twisting them back into place.

Battery Care

To prolong battery life, avoid fully discharging the headphones frequently. Store in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Low battery; Power button not pressed correctly.	Charge the headphones fully. Press and hold the power button for 3 seconds.
Cannot Pair Bluetooth	Headphones not in pairing mode; Device Bluetooth off; Interference.	Ensure headphones are discoverable. Turn device Bluetooth off and on. Move closer to device.
Air Purifier Noise is Loud	Fan speed set to high.	Reduce fan speed via the Dyson Link app.
No Airflow from Visor	Visor not properly attached; Filters blocked.	Ensure visor is securely attached. Check and clean/replace filters.

SPECIFICATIONS

Feature	Detail
Model Name	Zone™
Connectivity Technology	Wireless (Bluetooth 5.0)
Noise Control	Active Noise Cancellation
Battery Life (Audio with ANC)	Up to 50 Hours

Feature	Detail
Charging Time	50 Hours
Frequency Range	20Hz - 20kHz
Item Weight	1.4 Pounds (approx. 0.64 kg)
Product Dimensions	3.98 x 11.81 x 7.24 inches
Material	Plastic
Control Method	App (Dyson Link)

WARRANTY & SUPPORT

For detailed warranty information and product support, please refer to the official Dyson website or contact Dyson customer service. Keep your proof of purchase for warranty claims.

You can visit the official Dyson Store for more information: Dyson Store on Amazon

© 2024 Dyson. All rights reserved.

Related Documents - WP01



