

Syvio B0C3Q2W997

Syvio Automatic Pet Food Dispenser User Manual

Model: B0C3Q2W997

INTRODUCTION

Thank you for choosing the Syvio Automatic Pet Food Dispenser. This device is designed to provide convenient and scheduled feeding for your cats and dogs, ensuring they receive appropriate portions at regular intervals. With features like programmable meal times, voice recording, and dual power supply, this feeder offers reliability and ease of use for pet owners.

Please read this manual thoroughly before operating the device to ensure proper setup, optimal performance, and longevity of your feeder.

PRODUCT OVERVIEW



Figure 1: Syvio Automatic Pet Food Dispenser

Key Features:

- **Programmable Feeding:** Schedule up to 6 meals per day with 0-36 portions per meal.
- **Voice Recorder:** Record a 10-second message to call your pet at meal times.
- **Dual Power Supply:** Operates via USB-C power adapter or 4 x AA batteries (not included) for backup.
- **Anti-Clog Design:** Ensures smooth food dispensing and prevents blockages.
- **Double Locking Lid:** Securely keeps food fresh and prevents pets from accessing the hopper.

- **Easy to Clean:** Detachable stainless steel bowl and other components for convenient cleaning.
- **Desiccant Bag Compartment:** Maintains food freshness and prevents moisture.
- **User-Friendly Interface:** Large LCD screen and unique scroll wheel for easy programming.
- **8° Tilted Bowl Design:** Ergonomically designed for comfortable feeding.

COMPONENTS

The Syvio Automatic Pet Food Dispenser includes the following components:

- Main Feeder Unit (with food hopper and control panel)
- Stainless Steel Food Bowl
- USB-C Power Cable
- Instruction Manual (this document)
- Desiccant Bag (pre-installed or included separately)




Figure 2: Automatic Feeding Schedule Example

SETUP

1. **Unpack and Clean:** Carefully remove all components from the packaging. Wash the stainless steel bowl and the food hopper (if detachable) with mild soap and water. Ensure all parts are completely dry before assembly. **Note: Do not wash the main feeder unit or the base. Wipe clean with a damp cloth only.**
2. **Install Desiccant Bag:** Locate the desiccant bag compartment under the lid. Insert the desiccant bag to help keep the food fresh and dry. It is recommended to replace the desiccant bag every 2 weeks.




Figure 3: Desiccant Bag Installation and Bowl Design

3. **Fill Food Hopper:** Open the top lid by pressing the locking lid button. Pour dry pet food into the hopper. The feeder has a capacity of 3L (approximately 13 cups). Ensure the kibble size is between 2-15mm to prevent clogging. Close the lid securely until it clicks.

DOUBLE LOCKING DESIGN TO PREVENT OBESITY



Figure 4: Detachable Parts for Cleaning

4. Power Supply:

- **Primary Power:** Connect the USB-C cable to the feeder and plug the adapter into a wall outlet.
- **Backup Power:** For power outage protection, install 4 x AA batteries (not included) into the battery compartment at the bottom of the feeder.



Figure 5: Dual Power Supply Setup

5. **Place the Bowl:** Position the stainless steel food bowl in front of the dispenser outlet.

OPERATING INSTRUCTIONS

Control Panel Overview:

UNIQUE SCROLL WHEEL DESIGN

Choose the best feed plan with a ease scrolling



Figure 6: Control Panel with Scroll Wheel

- **LCD Screen:** Displays time, meal plan, and recording status.
- **Scroll Wheel:** Used to navigate menus and adjust settings.
- **Check Button (✓):** Confirms selections.
- **Manual Feed Button:** Dispenses food instantly.
- **Screen Lock Button:** Prevents accidental changes to settings.

Setting Current Time:

1. Press and hold the "TIME SET" button until the hour digit flashes.
2. Use the scroll wheel to adjust the hour. Press the "Check" button to confirm.
3. Repeat for minutes.

Programming Meal Plans:

The feeder supports up to 6 meals per day. Each meal can be set with a specific time and portion size (0-36 portions).

1. Press and hold the "FEED PLAN" button until the meal number flashes.
2. Use the scroll wheel to select the meal number (1-6) you wish to program. Press "Check".
3. The hour digit for the selected meal will flash. Use the scroll wheel to set the desired feeding hour. Press "Check".
4. Repeat for minutes. Press "Check".
5. The portion size will flash. Use the scroll wheel to set the number of portions (0-36) for this meal. Press "Check".
6. Repeat for all desired meals. The feeder will save settings automatically.

Your browser does not support the video tag.

Video 1: Syvio Automatic Cat Feeder with Dual Power Supply. This video demonstrates the features of the feeder, including the display, stainless steel bowl, locking lid, desiccant bag, voice recording, anti-jamming design, dual power supply, and screen lock function.

Voice Recording:

You can record a 10-second voice message that will play at each scheduled meal time.

1. Press and hold the "FEED REC" button until the microphone icon appears on the screen.
2. Speak your message clearly into the microphone located on the feeder.
3. Release the "FEED REC" button to save the recording.
4. To play back the recording, briefly press the "FEED REC" button.

ENABLE A MEAL CALL FEATURE FOR YOUR PET'S FEEDING ROUTINE

10s voice message



Figure 7: Voice Recording Feature

Manual Feeding:

To dispense food manually, briefly press the manual feed button. One portion will be dispensed each time the button is pressed.

Screen Lock Function:

To prevent accidental changes to settings by pets or children, activate the screen lock.

1. Press and hold the "Check" button for 3 seconds to lock the screen. A lock icon will appear.
2. To unlock, press and hold the "Check" button again for 3 seconds. The lock icon will disappear.

A BREEZE TO DETACH&CLEAN



Figure 8: Double Locking Design for Security

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your pet feeder.

- **Food Bowl:** The stainless steel bowl is dishwasher safe. For manual cleaning, wash with mild soap and water, then rinse thoroughly and dry completely.
- **Food Hopper and Dispenser:** The food hopper and dispenser components are detachable for easy cleaning. Wash with mild soap and water, rinse, and ensure they are completely dry before reassembling.
- **Main Unit:** Do not immerse the main feeder unit in water. Wipe the exterior with a soft, damp cloth. Ensure no water enters the battery compartment or control panel.
- **Desiccant Bag:** Replace the desiccant bag every 2 weeks to maintain optimal food freshness and prevent moisture buildup.
- **Kibble Check:** Periodically check the food hopper for any stuck kibble or debris, especially around the anti-clog mechanism.

EXCLUSIVE ANTI CLOG DESIGN



Figure 9: Anti-Clog Mechanism

TROUBLESHOOTING

Problem	Possible Cause	Solution
Feeder not dispensing food.	◦ Food hopper is empty. ◦ Kibble is jammed in the dispenser. ◦ Power supply issue. ◦ Screen is locked.	◦ Refill the food hopper. ◦ Check and clear any jammed kibble from the dispenser outlet. Ensure kibble size is 2-15mm. ◦ Check USB-C connection and ensure batteries are installed correctly and have charge. ◦ Unlock the screen by pressing and holding the "Check" button for 3 seconds.

Problem	Possible Cause	Solution
Voice recording not playing.	- No message recorded. - Volume too low.	- Record a new message following the instructions. - Ensure the volume is set appropriately (if adjustable, refer to advanced settings).
Feeder not turning on.	- No power. - Batteries are dead or incorrectly installed.	- Check USB-C power connection. - Replace AA batteries or ensure they are inserted with correct polarity.
Lid not closing securely.	- Obstruction. - Lid not aligned.	- Check for any food particles or debris preventing the lid from closing. - Ensure the lid is properly aligned with the main unit before pressing down to lock.

SPECIFICATIONS

Feature	Detail
Model	B0C3Q2W997
Capacity	3 Liters / 13 Cups
Meals per Day	1-6 Meals
Portions per Meal	0-36 Portions
Voice Recording	10 seconds
Power Supply	USB-C Adapter (included), 4 x AA Batteries (not included)
Recommended Kibble Size	2-15 mm
Bowl Material	304 Stainless Steel
Dimensions (LxWxH)	11.97 x 8.15 x 6.61 inches
Item Weight	3.94 pounds (1.79 kg)

WARRANTY AND SUPPORT

Sylvio products are designed with quality and reliability in mind. For warranty information, technical support, or any questions regarding your Automatic Pet Food Dispenser, please contact Sylvio customer service through the retailer's platform or visit the official Sylvio website.

Please retain your purchase receipt as proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question