



Manuals.plus /

› Devoko /

› Devoko L-Shaped Gaming Desk 130x130cm with Monitor Stand, Brown (Model 21L) - Instruction Manual

Devoko 21L

Devoko L-Shaped Gaming Desk 130x130cm with Monitor Stand (Model 21L)

Instruction Manual

PRODUCT OVERVIEW

The Devoko L-Shaped Gaming Desk is designed to optimize space and provide a versatile workstation for gaming, studying, or professional tasks. Featuring a robust construction and an ergonomic design, this desk includes a detachable monitor stand and ample storage solutions.



Image: Overall view of the Devoko L-Shaped Gaming Desk in a brown finish, showcasing its design and functionality in a modern office environment.

SAFETY INFORMATION

Attention: This product requires assembly. Please follow the assembly instructions carefully. This desk is designed for adults and has a supported weight limit. Do not place heavy objects on the desk that could damage its structure or cause injury.

- Ensure all screws and fasteners are tightened securely before use.
- Do not stand or sit on the desk.
- Keep small parts away from children during assembly.
- Place the desk on a flat, stable surface to prevent tipping.

ASSEMBLY INSTRUCTIONS

All necessary tools and components for assembly are included in the package. Each part is labeled with letters for easy

identification. No additional tools are required.

Step-by-Step Assembly Video

Your browser does not support the video tag.

Video: A detailed installation guide for a similar L-shaped desk, demonstrating the assembly process from unpacking to final setup. Follow the visual steps for a smooth build.

General Assembly Steps

- 1. Unpack and Identify Parts:** Carefully unpack all components and verify against the parts list in your manual. All parts are labeled for easy identification.
- 2. Assemble the Frame:** Begin by attaching the metal frame components using the provided screws. Ensure all connections are secure.
- 3. Attach Shelves:** Secure the two-tier shelves to the frame. These shelves provide organizational storage for books, gaming accessories, or decorations.
- 4. Install Desktop Panels:** Place the L-shaped desktop panels onto the assembled frame and secure them with the designated fasteners.
- 5. Integrate Power Strip:** Install the integrated power strip with one power outlet and two USB ports into the designated cutout on the desktop.
- 6. Attach Headphone Hook:** Secure the headphone hook to the side of the desk.
- 7. Final Check:** Ensure all screws are tightened and the desk is stable before placing any items on it.

FEATURES AND BENEFITS

- **L-Shaped Design:** Maximizes corner space, creating a large work or gaming area.
- **Detachable Monitor Stand:** Allows for ergonomic screen height adjustment, reducing neck and back strain, and increasing storage space.
- **Spacious Desktop:** The 130 cm x 130 cm L-shaped desktop provides ample room for computers and other equipment.
- **Integrated Power Strip:** Conveniently charge electronic devices with one power outlet and two USB ports directly on the desk.
- **Durable Construction:** Made from high-quality metal frame and MDF board, ensuring stability, durability, and resistance to scratches and water.
- **Versatile Use:** Suitable for various scenarios, including gaming, office work, or studying.

Visualizing Key Features



Structure solide du triangle

Support de moniteur amovible

**Plateau Robuste
Imperméable Facile à nettoyer**

Image: Detailed views highlighting the removable monitor stand, the sturdy triangular frame structure, and the durable, easy-to-clean desktop material.



Image: Illustration demonstrating the flexibility of the detachable monitor stand, which can be positioned on either side of the L-shaped desk.

L-Shaped Desk in Use

Your browser does not support the video tag.

Video: Demonstrates the COMHOMA L-shaped gaming desk, highlighting its spacious design, integrated features, and suitability for various setups.

SPECIFICATIONS

Attribute	Detail
Brand	Devoko
Model Number	21L
Color	Brown
Product Dimensions (L x W x H)	130 x 130 x 75 cm
Material	Wood (MDF), Metal
Special Feature	Ergonomic, Detachable Monitor Stand, Integrated Power Strip
Desktop Design	Floating Desk
Finish Type	Varnished



Image: Detailed dimensions of the L-shaped desk, including overall length, depth, height, and the size of the monitor stand.

OPERATING INSTRUCTIONS

The Devoko L-Shaped Gaming Desk is designed for intuitive use. Once assembled, you can customize your setup to suit your needs.

- **Monitor Stand Adjustment:** The monitor stand can be placed on either side of the L-shaped desk to achieve your preferred ergonomic viewing height. Simply lift and reposition as needed.
- **Power and USB Access:** Utilize the integrated power outlet and USB ports for convenient charging of your devices directly from the desktop.
- **Cable Management:** Use the cable grommet on the desktop to route and organize your cables, keeping your workspace tidy.
- **Storage:** The two-tier shelves provide easy access storage for books, documents, gaming controllers, or decorative items.

MAINTENANCE

To ensure the longevity and appearance of your Devoko L-Shaped Gaming Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desktop surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** The desktop is water-resistant. In case of spills, wipe them up immediately to prevent any potential damage.
- **Tighten Fasteners:** Periodically check all screws and fasteners and tighten them if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or discoloration of the desktop surface.
- **Weight Distribution:** Distribute weight evenly across the desktop and shelves to prevent stress on the frame.

TROUBLESHOOTING

If you encounter any issues with your Devoko L-Shaped Gaming Desk, please refer to the following common troubleshooting tips:

- **Desk Wobbles:**
 - Ensure the desk is placed on a level surface.
 - Check and tighten all assembly screws.
 - Adjust the leveling feet (if present) on the bottom of the desk legs.
- **Parts Missing or Damaged:**
 - Review the parts list in your manual to confirm.
 - Contact Devoko customer support for assistance with replacement parts.
- **Monitor Stand Not Stable:**
 - Ensure the monitor stand is correctly seated in its designated slots.
 - Verify that the monitor stand's support brackets are securely attached.
- **Power Strip Not Working:**
 - Ensure the power strip is properly connected to a working wall outlet.
 - Check if the power strip's circuit breaker (if any) has tripped.

WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact Devoko customer service through the retailer where you purchased the product. Please have your model number (21L) and purchase date available when contacting support.

You can also visit the official Devoko store for more information: [Devoko Store](#)