

PERFEIDY PSULO081KD

PERFEIDY 26.5V Power Cord Instruction Manual

For TOPPIN VC002, VC001, TPVC002, TPVC001 Cordless Vacuum Cleaners

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your PERFEIDY 26.5V Power Cord. This power adapter is designed as a replacement charger for specific TOPPIN cordless vacuum cleaner models. Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

Your PERFEIDY 26.5V Power Cord is designed with multiple safety features to ensure reliable operation. Adhere to the following safety guidelines:

- **UL Listed:** This power adapter is UL Listed (UL file E482416), ensuring it meets recognized safety standards.
- **Multi-Protection System:** Equipped with built-in protections against short circuit, over current, over voltage, over temperature, and over charge.
- **Indoor Use Only:** This product is intended for indoor use in dry locations. Do not expose to water or high humidity.
- **Proper Ventilation:** Ensure the adapter has adequate ventilation during use. Do not cover it.
- **Inspect Before Use:** Before each use, inspect the power cord and adapter for any signs of damage. Do not use if damaged.
- **Keep Away from Children:** Store the power cord and adapter out of reach of children.


Reliable and Durable

10000+

Bend Lifespan —



Image: Multi-Protection features of the PERFEIDY power adapter.



Premium Copper Core

Stabilizes Output Current —

Stronger Tensile Property



Image: The PERFEIDY power adapter is certified by UL, ensuring safety and quality.

3. PRODUCT COMPATIBILITY

This PERFEIDY 26.5V Power Cord is specifically designed for the following TOPPIN cordless vacuum cleaner models:

- TOPPIN VC002
- TOPPIN VC001
- TOPPIN TPVC002
- TOPPIN TPVC001

Important: This power cord is NOT compatible with TOPPIN VC003, TPVC003, VC004, or TPVC004 models. Please verify your vacuum cleaner model before use.

4. SETUP

1. **Unpack:** Carefully remove the power cord from its packaging.
2. **Inspect:** Check the power adapter and cord for any visible damage.
3. **Connect to Vacuum:** Insert the DC barrel connector end of the power cord into the charging port of your compatible TOPPIN cordless vacuum cleaner. Ensure a secure connection.
4. **Connect to Power Outlet:** Plug the AC adapter into a standard 100V-240V AC wall outlet.



Image: Connecting the power adapter to a wall outlet. The pure copper cable ensures stable charging.

5. OPERATING INSTRUCTIONS


Once properly connected, the power cord will begin charging your TOPPIN cordless vacuum cleaner. Observe the charging indicator on your vacuum cleaner (if available) to monitor the charging status.

- **Charging Time:** Refer to your TOPPIN vacuum cleaner's original manual for typical charging times.
- **Disconnecting:** Once charging is complete, first unplug the AC adapter from the wall outlet, then disconnect the DC connector from the vacuum cleaner.
- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures.

6. MAINTENANCE

To ensure the longevity and optimal performance of your PERFEIDY 26.5V Power Cord, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power cord from both the wall outlet and the vacuum cleaner before cleaning. Wipe the adapter and cord with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Cable Care:** Avoid sharp bends, kinks, or excessive pulling on the cable. The cable is designed for durability with a 10,000+ bend lifespan, but proper handling extends its life.
- **Storage:** Coil the cable loosely when storing. Do not wrap it tightly around the adapter.



Product Size

- ✓ 1.3*1.5*2.3 inch -Space Saving
- ✓ 6ft/1.8m -Extra-long cord

Image: The power cord features a durable design with a bend lifespan exceeding 10,000 cycles.

7. TROUBLESHOOTING

If you encounter issues with your PERFEIDY 26.5V Power Cord, refer to the following common solutions:

Problem	Possible Cause	Solution
Vacuum not charging	<ul style="list-style-type: none"> • Loose connection • Power outlet issue • Incompatible vacuum model • Damaged power cord/adaptor 	<ul style="list-style-type: none"> • Ensure both ends of the power cord are securely plugged in. • Test the power outlet with another device. • Verify your vacuum model is listed as compatible (VC001, VC002, TPVC001, TPVC002). • Inspect the cord and adaptor for damage. If damaged, discontinue use and replace.
Adapter feels hot	<ul style="list-style-type: none"> • Normal operation (slight warmth) • Poor ventilation • Overload/Fault 	<ul style="list-style-type: none"> • A slight warmth is normal. • Ensure the adapter is not covered and has adequate airflow. • If excessively hot or emitting smoke/smell, immediately unplug and discontinue use. Contact support.

8. SPECIFICATIONS

Feature	Detail
Model Number	PSULO081KD
Input Voltage	AC 100V-240V
Output Voltage	DC 26.5V
Output Current	1 Amps
Cable Length	6.0 ft (1.8 m)
Connector Type	Barrel Connector

Feature	Detail
Safety Certification	UL Listed (E482416), Energy Efficiency VI
Protection Features	Short circuit, Over current, Over voltage, Over temperature, Over charge
Item Weight	5.6 ounces
Package Dimensions	5.51 x 3.03 x 2.2 inches



Image: Product dimensions and cable length for the PERFEIDY power cord.

9. WARRANTY AND SUPPORT

Your PERFEIDY 26.5V Power Cord comes with a commitment to quality and customer satisfaction.

- **Warranty:** This product includes a 12-month exchange warranty.
- **Returns:** A 30-day refund policy is available.
- **Customer Support:** If you require any assistance or have questions regarding your power cord, please contact PERFEIDY customer support. Refer to your purchase documentation for contact details.