

Wearable4U Wingman Mini

Bushnell Wingman Mini GPS Bluetooth Speaker User Manual

Model: Wingman Mini | Brand: Wearable4U

INTRODUCTION

The Bushnell Wingman Mini is a compact GPS Bluetooth speaker designed for golf enthusiasts. It provides audible GPS distances, premium audio quality for music, and the ability to handle calls. Its integrated BITE magnetic cart mount allows for convenient attachment to a golf cart or bag. The device is built with a waterproof IPX7 construction, ensuring durability in various outdoor conditions.

WHAT'S IN THE BOX

- 1x Wingman Mini Black/Silver GPS Speaker
- 1x Carabiner Clip
- 1x USB-C Cable
- 1x Wearable4U Black EarBuds with Charging E-Bank Case
- 1x Wall Charger
- 1x Car Charger



Image: The complete bundle including the Wingman Mini speaker, earbuds, USB-C cable, wall charger, and car charger.

PRODUCT OVERVIEW



Image: Front view of the Bushnell Wingman Mini GPS Bluetooth Speaker, showcasing its hexagonal design and central 'B' logo.



Image: Multiple views of the Wingman Mini, highlighting the control buttons for volume, power, and GPS functions, as well as the carabiner clip and USB-C port.




Image: The Wingman Mini speaker in use alongside a smartphone displaying the Bushnell Golf app, showing GPS distances and settings.

Wearable4U



**Ultimate Running
Fitness EarBuds
fearless of rain
and sweat**



**Bluetooth 5.0
Power Bank
1500 mAh**



Image: Close-up view of the USB-C charging port on the side of the Bushnell Wingman Mini speaker.



Image: The Wearable4U Ultimate Earbuds with their charging case, highlighting features like Bluetooth 5.0 and 1500 mAh power bank.

SETUP

1. Charging the Device

Before first use, fully charge the Wingman Mini using the provided USB-C cable and either the wall or car charger. The charging port is located on the side of the speaker. A full charge provides approximately 11 hours of battery life.

2. Bluetooth Pairing

1. Power on the Wingman Mini by pressing and holding the power button.
2. Ensure Bluetooth is enabled on your smartphone.
3. Search for available Bluetooth devices and select "Bushnell Wingman Mini" to pair.
4. Once paired, the speaker will confirm the connection.

3. Bushnell Golf App Installation

For full GPS functionality and custom sound bites, download the Bushnell Golf app from your smartphone's app store (Google Play or Apple App Store). Follow the in-app instructions to set up your profile and access golf course data.

OPERATING INSTRUCTIONS

1. Audible GPS Distances

With the Bushnell Golf app running and the Wingman Mini connected, press the 'B' button on the speaker to receive audible distances to the front, center, and back of the green. The speaker comes preloaded with over 38,000 golf courses worldwide.

2. Music Playback

Once paired via Bluetooth, you can stream music from your smartphone or other Bluetooth-enabled devices. Use the volume controls on the speaker or your connected device to adjust audio levels.

3. Hands-Free Calling

The built-in microphone allows you to take and make calls directly through the Wingman Mini when connected to your smartphone. Press the play/pause button to answer or end a call.

4. TWS Speaker Pairing (True Wireless Stereo)

If you have two Wingman Mini speakers, you can pair them together for a True Wireless Stereo experience. Refer to the Bushnell Golf app or the full product manual for detailed instructions on TWS pairing.

5. Attaching to Golf Cart/Bag

Utilize the integrated BITE magnetic cart mount to securely attach the speaker to a golf cart bar. Alternatively, use the provided carabiner clip to attach it to your golf bag.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a cool, dry place when not in use.
- **Water Resistance:** The Wingman Mini features IPX7 waterproof construction, meaning it can withstand immersion in up to 1 meter of water for 30 minutes. Ensure the charging port cover is securely closed before exposure to water.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly.

TROUBLESHOOTING

Problem	Solution
No power/Device won't turn on	Ensure the device is fully charged. Connect to a power source using the provided USB-C cable and charger.
Cannot pair via Bluetooth	Make sure the Wingman Mini is in pairing mode. Ensure Bluetooth is enabled on your smartphone and it is within range. Forget the device from your smartphone's Bluetooth settings and try pairing again. Restart both the speaker and your smartphone.

Problem	Solution
No audible GPS distances	Confirm the Wingman Mini is connected to your smartphone via Bluetooth. Ensure the Bushnell Golf app is open and actively tracking your round. Check that the speaker's volume is turned up. Verify GPS signal strength in your location.
Poor audio quality	Ensure the speaker is within Bluetooth range of your device. Check for obstructions between the speaker and your device. Reduce interference from other wireless devices. Ensure the audio source is of good quality.

SPECIFICATIONS


- **Model Name:** Wingman Mini Black/Silver
- **Item Model Number:** w1
- **Item Weight:** 6 ounces
- **Product Dimensions:** 4 x 3.23 x 1.57 inches
- **Battery Type:** 1 Lithium Ion battery (included)
- **Battery Life:** Approximately 11 Hours
- **Connectivity Technology:** Bluetooth
- **Special Features:** Audible GPS Distances, Built-in Microphone, Mini, TWS Speaker Pairing Technology, Waterproof (IPX7)
- **Mounting Type:** Bite Mount
- **Map Type:** Golf Course (preloaded with over 38,000 courses)
- **Voice Command:** Microphone

WARRANTY AND SUPPORT

The Bushnell Wingman Mini comes with a **2-Year Manufacturer Warranty**. For warranty claims, technical support, or further assistance, please contact Wearable4U customer service or refer to the official Bushnell Golf website for support resources.

Manufacturer: Wearable4U

Related Documents - Wingman Mini

 <p>Bushnell GOLF</p> <p>WINGMAN HD COLOR TOUCHSCREEN • GOLF GPS & SPEAKER</p>	<p>Bushnell Wingman HD Golf GPS Speaker User Manual & Guide</p> <p>Comprehensive user guide for the Bushnell Wingman HD, detailing its features, setup, app connection, operation, MyBag technology, Concert Links, troubleshooting, and technical specifications for golfers.</p>
 <p>Bushnell GOLF</p> <p>WINGMAN BLUETOOTH™ SPEAKER WITH AUDIBLE GPS OWNER'S GUIDE</p>	<p>Bushnell Wingman Bluetooth Speaker with Audible GPS Owner's Guide</p> <p>This owner's guide provides essential information for the Bushnell Wingman, a rugged, high-quality Bluetooth speaker designed for golfers. It offers audible GPS distances and connects seamlessly with the Bushnell Golf app. Learn about the speaker's features, operation, and maintenance to ensure optimal performance and longevity on the course.</p>
 <p>Bushnell GOLF</p> <p>WINGMAN SPEAKER • AUDIBLE GPS</p>	<p>Bushnell Wingman View Golf Speaker with Audible GPS - User Manual</p> <p>Comprehensive user manual for the Bushnell Wingman View Bluetooth golf speaker with audible GPS. Learn about setup, features, operation, troubleshooting, and specifications for models 362210 and 362220.</p>
 <p>Bushnell GOLF</p> <p>WINGMAN 2 SPEAKER • AUDIBLE GPS</p>	<p>Bushnell Wingman 2 GPS Speaker User Manual</p> <p>Comprehensive user manual for the Bushnell Wingman 2 GPS Speaker, detailing features, operation, and care. Learn about Bluetooth pairing, app integration, sound modes, and troubleshooting.</p>
 <p>Bushnell GOLF</p> <p>WINGMAN HD COLOR TOUCHSCREEN • GOLF GPS & SPEAKER</p>	<p>Bushnell Wingman HD: Golf GPS Speaker User Manual</p> <p>User manual for the Bushnell Wingman HD, a high-quality golf GPS speaker with a color touchscreen and surround sound. Learn how to connect, operate, and utilize its features with the Bushnell Golf Mobile App.</p>

