

[Manuals.plus](#) /

› [BRAVEN](#) /

› Braven STRYDE 360 Waterproof Bluetooth Speaker User Manual

BRAVEN STRYDE 360

Braven STRYDE 360 Waterproof Bluetooth Speaker User Manual

Model: STRYDE 360

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Braven STRYDE 360 Waterproof Bluetooth Speaker. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

The Braven STRYDE 360 is designed for portability and durability, featuring a waterproof construction and Bluetooth connectivity for wireless audio streaming.



Image: The Braven STRYDE 360 speaker, showcasing its cylindrical design and speaker grilles.

PRODUCT OVERVIEW

Speaker Components

Familiarize yourself with the main components of your Braven STRYDE 360 speaker:

- **Control Panel:** Located on the top surface, featuring power, play/pause, volume, and Bluetooth pairing buttons.
- **Speaker Grilles:** Covering the audio drivers for sound output.
- **Port Cover:** A sealed cover on the side protecting the charging, auxiliary, and USB output ports.

Control Panel Layout



Image: Detailed view of the speaker's control panel, including the Power button, Play/Pause button, Volume Down (-), Volume Up (+), and LED indicators for Bluetooth and battery status.

1. **Power Button:** Press and hold to turn the speaker on or off.
2. **Play/Pause Button:** Press to play or pause audio.
3. **Volume Down (-) Button:** Press to decrease volume.
4. **Volume Up (+) Button:** Press to increase volume.
5. **Bluetooth Indicator:** LED light indicating Bluetooth connection status.
6. **Battery Indicator:** LED light indicating battery charge level.

Port Panel



Image: The port panel of the speaker with the protective cover open, revealing the USB output port (for charging other devices), AUX input

port, and Micro USB input port (for charging the speaker).

- **USB Output (5V/1A):** For charging external devices.
- **AUX Input:** For wired audio connection using a 3.5mm audio cable.
- **Micro USB Input (5V/1A):** For charging the speaker.

SETUP

1. Charging the Speaker

Before initial use, fully charge your Braven STRYDE 360 speaker.

1. Open the protective port cover on the side of the speaker.
2. Connect the provided Micro USB cable to the speaker's Micro USB input port.
3. Connect the other end of the Micro USB cable to a USB power adapter (not included) or a computer's USB port.
4. The battery indicator LED will show charging status. A full charge is indicated when the LED changes color or turns off (refer to specific LED behavior in the full manual if available).
5. Once fully charged, disconnect the cable and securely close the port cover to maintain waterproofing.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (labeled with a circle and vertical line) for approximately 2-3 seconds until you hear an audible tone and the Bluetooth indicator LED flashes.
- **To Power Off:** Press and hold the Power button for approximately 2-3 seconds until you hear an audible tone and the indicator LEDs turn off.

3. Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered on and the Bluetooth indicator LED is flashing, indicating it is in pairing mode. If not, press and hold the Bluetooth button (if available, otherwise it enters pairing mode automatically on power-on if not connected).
2. On your audio device (smartphone, tablet, computer), navigate to the Bluetooth settings.
3. Search for available devices. You should see "BRAVEN STRYDE 360" in the list.
4. Select "BRAVEN STRYDE 360" to initiate the connection.
5. Once successfully paired, the Bluetooth indicator LED on the speaker will typically turn solid blue or stop flashing, and you will hear a confirmation tone.
6. The speaker will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Audio Playback (Bluetooth Mode)

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Adjustment:** Press the Volume Up (+) button to increase volume, and the Volume Down (-) button to decrease volume.
- **Skip Track:** (Functionality may vary by device and speaker model) Typically, a long press on Volume Up (+) or Volume Down (-) might skip tracks. Refer to your device's Bluetooth controls if this is not directly supported by the speaker buttons.

Using the AUX Input

For devices without Bluetooth capability, you can use the auxiliary input:

1. Open the protective port cover.
2. Connect a 3.5mm audio cable (not included) from your audio source's headphone jack to the speaker's AUX input port.
3. The speaker should automatically switch to AUX mode. If not, ensure no Bluetooth device is actively playing.
4. Adjust volume using the speaker's volume buttons or your audio source.
5. Remember to close the port cover when not in use to maintain waterproofing.

Charging External Devices (Power Bank Function)

The Braven STRYDE 360 can act as a power bank to charge other USB-powered devices.

1. Open the protective port cover.
2. Connect your device's USB charging cable to the speaker's USB Output (5V/1A) port.
3. Charging should begin automatically. The speaker's battery will be used to charge your device.
4. Close the port cover when finished charging to maintain waterproofing.

MAINTENANCE

Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components.
- Ensure all ports are dry before charging or connecting cables.

Waterproofing

The Braven STRYDE 360 is designed to be waterproof. To maintain its waterproof integrity:

- Always ensure the protective port cover is securely and completely closed before exposing the speaker to water.
- Do not submerge the speaker beyond its specified depth or for extended periods.
- If the speaker has been exposed to saltwater, rinse it with fresh water and dry thoroughly before charging or opening the port cover.

Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% to help preserve battery life.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided Micro USB cable.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device is too far; interference; previously paired device connected.	• Ensure speaker is powered on and Bluetooth indicator is flashing. • Move speaker closer to your device. • Turn off other Bluetooth devices nearby. • Forget "BRAVEN STRYDE 360" from your device's Bluetooth list and try pairing again.
No sound from speaker.	Volume too low; incorrect input source; device not playing audio.	• Increase volume on both the speaker and your audio device. • Ensure the correct input (Bluetooth or AUX) is active. • Verify audio is playing on your connected device.
External device not charging from speaker.	Speaker battery too low; incorrect cable; device not compatible.	• Ensure the speaker has sufficient charge. • Use a functional USB charging cable for your device. • Confirm your device is compatible with 5V/1A USB charging.

SPECIFICATIONS

Feature	Detail
Brand	BRAVEN
Model	STRYDE 360
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	10 Watts
Audio Output Mode	Stereo
Mounting Type	Freestanding
Waterproofing	Designed to be waterproof (ensure port cover is sealed)
Power Input	Micro USB (5V/1A)
Power Output	USB (5V/1A) for charging external devices

WARRANTY AND SUPPORT

This product is covered by a limited warranty. For detailed warranty information, please refer to the documentation included with your purchase or visit the official BRAVEN website. Keep your proof of purchase for warranty claims. For technical support or customer service inquiries, please contact BRAVEN customer support through their official channels. Contact information can typically be found on the product packaging or the manufacturer's website.

As this is a renewed product, specific warranty terms may vary. Please consult the Amazon Renewed program details or the seller, Pro Element, for specific warranty coverage related to your purchase.

© 2023 BRAVEN. All rights reserved. STRYDE 360 is a trademark of BRAVEN.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question