

[Manuals.plus](#) /

> [VOCOLinc](#) /

> VOCOLinc Air Card Wallet Tracker VT2202 Instruction Manual

VOCOLinc VT2202

VOCOLinc Air Card Wallet Tracker VT2202 Instruction Manual

Model: VT2202

1. INTRODUCTION

The VOCOLinc Air Card Wallet Tracker VT2202 is a compact item finder designed to help you locate your personal belongings using the Apple Find My network. This device integrates seamlessly with your iOS devices, providing both nearby and distant tracking capabilities, along with left-behind alerts to prevent loss. This manual provides essential instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your tracker.



Image: The VOCOLinc Air Card Wallet Tracker shown alongside an iPhone displaying its location on the Apple Find My app.

2. SETUP AND PAIRING

Follow these steps to set up and pair your VOCOLinc Air Card Wallet Tracker with your iOS device:

1. Ensure your iOS device's Bluetooth is turned on.
2. Open the **Find My** app on your iOS device.
3. Navigate to the **Items** tab.
4. Tap on **Add Item**, then select **Other Supported Item**.
5. Press the power button on your VOCOLinc Air Card Wallet Tracker to turn it on and place it near your iOS device.
6. Follow the on-screen instructions in the Find My app to complete the pairing process.
7. For subsequent pairing with other items, tap the '+' icon and then 'Add Other Item' to pair.



Image: A visual representation of the pairing process, showing the steps within the Find My app.

Video: How to Pair VOCOLinc Wallet Tracker Card

Your browser does not support the video tag.

Video: This video demonstrates the step-by-step process of pairing your VOCOLinc Wallet Tracker Card with an Apple iOS device using the Find My app.

3. OPERATING INSTRUCTIONS

3.1 Finding Nearby Items

When your item is within Bluetooth range (up to 200 feet/60 meters), you can use the Find My app or Siri to locate it. The tracker features a built-in speaker that emits a loud sound (80-100 dB) to help you pinpoint its exact location.

- Open the **Find My** app.
- Select your VOCOLinc Air Card from the **Items** list.
- Tap **Play Sound** to make the tracker emit an audible alert.
- Alternatively, activate Siri and say, "Hey Siri, find my [item name]."

Lost **your item** nearby?

Find it with a tap of a button on your cellphone



Image: An iPhone screen showing the 'Play Sound' function in the Find My app, with a wallet tracker visually indicating sound emission.

3.2 Finding Far Away Items

If your item is outside the Bluetooth range, the Apple Find My network can assist. Millions of iOS devices worldwide contribute to this network, anonymously and securely relaying the location of your tracker to your Find My app. This allows you to view its last known location on a map and get directions.

- Open the **Find My** app.
- Select your VOCOLinc Air Card from the **Items** list.
- The app will display the tracker's last known location on a map.
- Tap **Directions** to receive navigation instructions to the item's location.

Find Far Away

When outside of Bluetooth range, use the Find My app to view it on the map and direct you to the vicinity of VOCOLinc



Image: The Find My app on an iPhone showing map-based directions to a VOCOLinc Air Card Wallet Tracker located at a distance.

3.3 Left-Behind Alerts

To prevent leaving your valuables behind, the Find My app can notify you if your tracker disconnects from your iOS device's Bluetooth. This feature provides an immediate alert, helping you retrieve your item before it's too far away.

- Ensure **Notify When Left Behind** is enabled for your tracker in the Find My app settings.
- You will receive an instant notification on your iOS device if the tracker loses its Bluetooth connection.

Left-Behind **Remind**



Image: A notification on an iPhone screen alerting the user that their tracked item has been left behind.

3.4 Sharing Items (iOS 17 and above)

With iOS 17 or newer, you can share your VOCOLINC Air Card's location with up to five other individuals. This allows multiple users to track the item's location on their own Find My app, without receiving tracking notifications if the item moves with them.

- Ensure your iOS device is updated to iOS 17 or a later version.
- In the **Find My** app, select the VOCOLINC Air Card you wish to share.
- Follow the prompts to add up to 5 borrowers to share the item's location.

3.5 Privacy Protection

The VOCOLINC Air Card Wallet Tracker works with the Apple Find My network, which is designed with privacy in mind. All location information is anonymous and encrypted, ensuring your privacy and security are maintained.

Video: Air Tag Card Wallet Tracker Work with Apple Find My APP

Your browser does not support the video tag.

Video: This video provides an overview of the VOCOLINC Air Card Wallet Tracker's functionality with the Apple Find My app, demonstrating its various features.

4. MAINTENANCE

4.1 Battery Life

The VOCOLinc Air Card Wallet Tracker is equipped with a built-in, non-replaceable battery designed to last up to 3 years under typical usage conditions.

4.2 Water Resistance

The tracker is IP67 water-resistant, meaning it can withstand splashes, rain, and brief immersion in water. However, it is not recommended for prolonged submersion or use in extreme water conditions.



Image: An infographic detailing the physical dimensions and key features of the VOCOLinc Air Card Wallet Tracker, including its water resistance rating.

5. TROUBLESHOOTING

- **Tracker not pairing:** Ensure your iOS device's Bluetooth is active and the tracker is powered on and near your device. If issues persist, try resetting the tracker (refer to manufacturer's specific reset instructions if available, otherwise, long-press the button for 10 seconds until a long beep,

then release).

- **No sound from tracker:** Check if the 'Play Sound' function is activated in the Find My app. Ensure the tracker is within Bluetooth range of your iOS device.
- **Inaccurate location:** For distant tracking, location relies on the Find My network. Ensure there are active iOS devices nearby to relay the signal. For nearby tracking, ensure a clear line of sight for Bluetooth.
- **Left-behind alerts not working:** Verify that 'Notify When Left Behind' is enabled for your tracker in the Find My app settings.
- **Compatibility:** This tracker is only compatible with iOS devices and does not support Android.

6. SPECIFICATIONS

Feature	Detail
Model Number	VT2202
Item Weight	1.44 ounces
Package Dimensions	4.76 x 4.06 x 0.35 inches
Battery Type	2 Lithium Metal batteries (included, non-replaceable)
Battery Life	Up to 3 years
Water Resistance	IP67
Bluetooth Range	Up to 200 feet / 60 meters
Sound Level	80-100 dB
Compatible Devices	Apple Find My (iOS Only)
Material	Plastic, Silicone

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The VOCOLinc Air Card Wallet Tracker VT2202 comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact VOCOLinc customer support through the official website or your retailer's support channels. Provide your model number (VT2202) and a detailed description of the issue for efficient service.

© 2025 VOCOLinc. All rights reserved.