

Umay S8418837

Umay Bluetooth Speaker User Manual

MODEL: S8418837

Introduction

Welcome to the user manual for your Umay Bluetooth Speaker. This guide provides comprehensive instructions for the proper setup, operation, maintenance, and troubleshooting of your device. Please read this manual thoroughly before using the speaker to ensure optimal performance and longevity.

Product Overview

The Umay Bluetooth Speaker is a compact, portable audio device designed for wireless connectivity. Its multi-color design offers a vibrant aesthetic, making it suitable for various environments. The speaker delivers clear audio output for an enhanced listening experience.



This image displays the Umay Bluetooth Speaker in various colors: light blue, mint green, bright yellow, and soft pink. One speaker is shown inside its compact white and grey packaging, highlighting its small size and portability.

Setup

1. Unpacking

Carefully remove the speaker from its packaging. Ensure no components are missing or damaged. Typically, the package includes the Umay Bluetooth Speaker and a charging cable.

2. Charging the Speaker

Before first use, fully charge the speaker. Connect the charging cable to the speaker's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will typically show the charging status and turn off or change color when fully charged.

3. Pairing with a Bluetooth Device

1. Ensure the speaker is charged and powered on.
2. Activate Bluetooth on your device (smartphone, tablet, laptop).
3. The speaker will automatically enter pairing mode or you may need to press a dedicated Bluetooth button. Refer to the speaker's physical buttons for specific instructions.

- On your device, search for available Bluetooth devices. The speaker should appear as "Umay Speaker" or a similar name.
- Select the speaker from the list to initiate pairing. Once connected, you will hear an audible confirmation or see a steady indicator light.

Operating Instructions

1. Power On/Off

Press and hold the power button for a few seconds to turn the speaker on or off. An indicator light will illuminate when the speaker is powered on.

2. Bluetooth Connection

Once paired, the speaker will automatically attempt to connect to the last paired device when powered on and within range. If connection fails, repeat the pairing steps.

3. Audio Playback

After a successful Bluetooth connection, you can play audio from your connected device. The speaker will output the sound wirelessly.

4. Volume Control

Adjust the volume directly from your connected Bluetooth device. Some speaker models may also have physical volume buttons.

Maintenance

1. Cleaning

Wipe the speaker's exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the surface. Avoid getting moisture into any openings.

2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is advisable to partially charge the battery before long-term storage.

3. Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Recharge the battery when the low battery indicator appears. Do not expose the battery to excessive heat or cold.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device Bluetooth is off; Speaker is too far from device.	Ensure speaker is in pairing mode; Turn on Bluetooth on your device; Move speaker closer to device (within 10 meters).

Problem	Possible Cause	Solution
No sound or low volume.	Volume on device is too low; Speaker is not connected; Audio source issue.	Increase volume on your device; Re-establish Bluetooth connection; Check audio source on your device.
Sound distortion.	Volume too high; Interference; Low battery.	Lower volume; Move away from other electronic devices; Charge the speaker.

Specifications

Feature	Detail
Brand	Umay
Model Number	S8418837
Connectivity Technology	Bluetooth
Color	Multi-color
Product Dimensions	27.62 x 22.85 x 19.03 cm
Item Weight	3.06 Kilograms
Speaker Maximum Output Power	6 Watt
Compatible Devices	Laptop, Smartphone, Tablet

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Umay website. Keep your proof of purchase for any warranty claims. If you encounter issues not covered in this manual, please contact Umay customer service for assistance.