Bajaj 251301

Bajaj Pygmy Go 178MM Mini Fan User Manual

Model: Pygmy Go - Blue (251301)

1. Introduction

The Bajaj Pygmy Go 178MM Mini Fan is a portable and versatile personal fan designed for comfort and convenience. It features a rechargeable battery, USB charging, multiple speed settings, and integrated LED lighting, making it suitable for various indoor environments. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your fan.



Figure 1: Front view of the Bajaj Pygmy Go 178MM Mini Fan.

2. Product Components

Your Bajaj Pygmy Go Mini Fan package includes the following items:

- Personal Fan: 1 Unit
- Warranty Card: 1 Unit
- Instruction Manual: 1 Unit
- USB Cable: 1 Unit




Figure 2: Key features and components of the Bajaj Pygmy Go Mini Fan.

3. Setup and Charging

Before first use, ensure the fan is fully charged. The fan is equipped with a 2400 mAh Li-Ion battery for extended use.

1. **Initial Charge:** Connect the provided USB cable to the fan's charging port and to a compatible USB power adapter (not included) or a computer USB port.
2. **Charging Indicator:** The charging indicator light will illuminate during charging. It typically takes approximately 3 hours for a full charge if the battery is completely drained.
3. **Full Charge:** The indicator light will change color (e.g., from red to green) when the battery is fully charged.
4. **Placement:** Place the fan on a stable, flat surface. Its portable oval shape allows for easy placement in various locations.



Figure 3: Charging and portability features.

4. Operating Instructions

The Bajaj Pygmy Go Mini Fan offers adjustable fan speeds and LED lighting for customized comfort.

4.1. Fan Operation

1. **Power On/Off:** Locate the power button on the front of the fan. Press once to turn on the fan at the lowest speed setting.
2. **Adjusting Fan Speed:** Press the power button repeatedly to cycle through the three available fan speeds. Each press will increase the speed, and after the highest speed, it will turn off. The fan operates at a high speed of 2100 RPM for quick comfort.
3. **Airflow Adjustment:** The fan head can be manually tilted vertically to direct airflow as needed.



Figure 4: Fan speed and light brightness controls.

4.2. LED Lighting Operation

The fan includes an integrated LED light with two brightness settings for dual usage.

1. **Turning Light On/Off:** Locate the light button (separate from the fan power button). Press once to turn on the light at the first brightness setting.
2. **Adjusting Light Brightness:** Press the light button again to switch to the second, brighter setting. A third press will turn the light off.



Figure 5: Fan providing seamless and silent airflow in a bedroom setting.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning the Fan:**
  - Ensure the fan is turned off and unplugged before cleaning.
  - The front grill of the fan is detachable for easy cleaning. Gently twist or unclip the grill as per the design to remove it.
  - Use a soft, dry cloth to wipe dust from the fan blades and the interior of the grill. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
  - Do not use abrasive cleaners, solvents, or immerse the fan in water.
  - Reattach the front grill securely after cleaning.
- **Battery Care:**
  - To prolong battery life, avoid completely draining the battery frequently.
  - Charge the fan regularly, even if not in constant use, to maintain battery health.
  - Store the fan in a cool, dry place when not in use for extended periods.

6. Troubleshooting

If you encounter issues with your Bajaj Pygmy Go Mini Fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted. Power button not pressed correctly.	Charge the fan using the provided USB cable. Ensure the power button is pressed firmly.
Fan speed is low or inconsistent.	Low battery charge. Obstruction in fan blades.	Recharge the fan. Turn off and unplug the fan, then check for and remove any obstructions from the blades.
LED light does not work.	Light button not pressed correctly. Battery is depleted.	Ensure the light button is pressed firmly. Recharge the fan.
Fan makes unusual noise.	Dust or debris on blades. Fan not on a stable surface.	Clean the fan blades and grill as per maintenance instructions. Place the fan on a flat, stable surface.
Battery backup is shorter than expected.	Fan used at highest speed setting. Battery degradation over time.	Higher fan speeds consume more power. Use lower speeds for longer battery life. Battery life naturally decreases over time. Ensure proper charging habits.

7. Specifications

Detailed technical specifications for the Bajaj Pygmy Go 178MM Mini Fan:

Feature	Detail
Brand	Bajaj
Model Name	Pygmy Go
Item Model Number	251301
Colour	Cerulean Blue
Electric Fan Design	Table Fan
Power Source	Battery Powered
Product Dimensions	24.5D x 9.6W x 29.7H Centimeters
Special Feature	Portable
Wattage	8 Watts
Number of Blades	3
Blade Length	178 Millimetres
Speed	2100 RPM
Voltage	5 Volts
Switch Type	Push Button

Feature	Detail
Item Weight	670 Grams
Light Type	LED
Blade Material	Plastic
Is It Cordless?	Yes
Number of Power Levels	3
Country of Origin	China



Figure 6: Product dimensions of the Bajaj Pygmy Go Mini Fan.

8. Warranty and Support

Your Bajaj Pygmy Go 178MM Mini Fan comes with a warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of the warranty.
For technical assistance, service, or any inquiries regarding your product, please contact Bajaj customer support. Contact details can typically be found on the Warranty Card or the official Bajaj website.
Important: Keep your purchase receipt and Warranty Card in a safe place as proof of purchase may be required for warranty claims.

© 2025 Bajaj Electricals Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question