

[Manuals.plus](#) /

› [Tayfun](#) /

› Tayfun Keysmart KEY 1211 Air Conditioner Remote Control User Manual

Tayfun KEY 1211

Tayfun Keysmart KEY 1211 Air Conditioner Remote Control User Manual

Model: KEY 1211

1. INTRODUCTION

This manual provides detailed instructions for the proper use, setup, and maintenance of your Tayfun Keysmart KEY 1211 Air Conditioner Remote Control. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

2. SAFETY INFORMATION

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Keep the remote control away from direct sunlight, high temperatures, and moisture.
- Do not drop or subject the remote control to strong impacts.

3. PRODUCT OVERVIEW

The Tayfun Keysmart KEY 1211 remote control is designed for intuitive operation of your air conditioning unit. Familiarize yourself with its layout and functions.





An image showing the front view of the Tayfun Keysmart KEY 1211 air conditioner remote control, displaying its LCD screen and all control buttons.

Button Functions:

Button	Function
--------	----------

Button	Function
Power (ⓘ)	Turns the air conditioner unit On or Off.
Yumuşak Hava (Soft Air)	Activates a gentle, soft airflow mode for enhanced comfort.
Gösterge Aydınlatma (Display Backlight)	Toggles the backlight of the remote's LCD display.
Mod (Mode)	Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
Sıcaklık ▲ (Temperature Up)	Increases the set temperature.
Sıcaklık ▼ (Temperature Down)	Decreases the set temperature.
Fan	Adjusts the fan speed (e.g., Low, Medium, High, Auto).
Enerji Tasarrufu (Energy Saving)	Activates energy-saving operation mode.
Hızlı (Quick)	Initiates a quick cooling or heating function.
Anlık Güç Tüketimi (3sn) (Instant Power Consumption)	Press and hold for 3 seconds to display instant power consumption.
Dikey Hava (Vertical Airflow)	Adjusts the vertical direction of the airflow louvers.
Yatay Hava (Horizontal Airflow)	Adjusts the horizontal direction of the airflow louvers.
Oda Sıcaklığı (Room Temperature)	Displays the current room temperature.
°C ↔ °F (5sn) (Celsius ↔ Fahrenheit)	Press and hold for 5 seconds to switch temperature units between Celsius and Fahrenheit.
IonFresh Sessiz Mod (IonFresh Silent Mode)	Activates the IonFresh function and sets the unit to silent operation.
IA/Clean	Activates the Intelligent Air or self-cleaning function.
Zaman Ayarı (Timer Set)	Sets the ON/OFF timer for the air conditioner.
Ayar İptal (Set / Cancel)	Confirms or cancels current settings, often used with timer functions.
Zaman Ayarı İptal (Timer Cancel)	Cancels any active timer settings.

4. SETUP

4.1 Battery Installation

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries (not included), ensuring the (+) and (-) terminals match the markings inside the compartment.
3. Close the battery compartment cover securely.
4. The remote control is now ready for use.

5. OPERATING INSTRUCTIONS

5.1 Turning On/Off

Press the **Power** (⏻) button once to turn the air conditioner ON. Press it again to turn the unit OFF.

5.2 Selecting Operating Mode

Press the **Mod (Mode)** button repeatedly to cycle through the available operating modes: Auto, Cool, Dry, Fan, Heat (if applicable to your AC unit).

5.3 Adjusting Temperature

In Cool or Heat mode, use the **Sıcaklık ▲ (Temperature Up)** and **Sıcaklık ▼ (Temperature Down)** buttons to set your desired temperature.

5.4 Adjusting Fan Speed

Press the **Fan** button repeatedly to select the desired fan speed: Auto, Low, Medium, or High.

5.5 Airflow Direction

- Press **Dikey Hava (Vertical Airflow)** to adjust the vertical swing of the louvers.
- Press **Yatay Hava (Horizontal Airflow)** to adjust the horizontal swing of the louvers.

5.6 Special Functions

- **Yumuşak Hava (Soft Air)**: Press to activate a gentle airflow.
- **Enerji Tasarrufu (Energy Saving)**: Press to engage the energy-saving mode.
- **Hızlı (Quick)**: Press for rapid cooling or heating.
- **IonFresh Sessiz Mod (IonFresh Silent Mode)**: Press to activate the ionizer and reduce operational noise.
- **IA/Clean**: Press to activate the Intelligent Air or self-cleaning function of the AC unit.

5.7 Timer Settings

- **To Set Timer ON/OFF**: Press **Zaman Ayarı (Timer Set)**, then use temperature arrows to adjust the time. Press **Ayar İptal (Set / Cancel)** to confirm.
- **To Cancel Timer**: Press **Zaman Ayarı İptal (Timer Cancel)**.

6. MAINTENANCE

6.1 Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.

6.2 Battery Replacement

Replace batteries when the display becomes dim or the remote control's range decreases. Follow the battery installation steps in Section 4.1.

7. TROUBLESHOOTING

7.1 Remote Control Not Working

- Check if the batteries are inserted correctly with the correct polarity.

- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Make sure you are within the effective operating range of the air conditioner.

7.2 Display Issues

- If the display is dim, replace the batteries.
- If the display shows incorrect information, try removing the batteries for a few minutes and then reinserting them to reset the remote.

8. SPECIFICATIONS

- **Model:** KEY 1211
- **Power Supply:** DC 3V (2 x AAA batteries)
- **Operating Distance:** Approximately 8 meters (line of sight)
- **Operating Temperature:** 0°C to 40°C (32°F to 104°F)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your air conditioner unit or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2023 Tayfun. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C3XTRGW6>

More documents and user manuals: <https://manuals.plus/>